



[Manuals.plus](#) /

> [Cubehom](#) /

> Cubehom 51-inch Black LED TV Stand Instruction Manual

## Cubehom JCF16-2new

# Cubehom 51-inch Black LED TV Stand Instruction Manual

Model: JCF16-2new | Brand: Cubehom

## 1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Cubehom 51-inch Black LED TV Stand. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The Cubehom LED TV Stand is designed to accommodate televisions up to 65 inches, offering ample storage and integrated LED lighting for an enhanced entertainment experience. It features a durable engineered wood construction with a sleek black finish, clear acrylic supports, and a glass partition.



Image: The Cubehom 51-inch Black LED TV Stand in a living room setting, showcasing its design and ambient orange LED lighting.

## 2. SAFETY INFORMATION

- Always assemble the product according to the provided instructions.
- Ensure that the product is properly secured to the wall to prevent tip-overs, especially when heavy items are placed on it.
- Do not exceed the weight limit of the product.
- Keep small children and pets away from the product during assembly and usage.
- Always unplug and turn off any electrical devices before cleaning the product with a dry cloth.

## 3. PRODUCT DIMENSIONS

The Cubehom 51-inch Black LED TV Stand has the following dimensions:

- **Length:** 51 inches
- **Width:** 16 inches
- **Height:** 21 inches



Image: Visual representation of the TV stand's dimensions and how various TV sizes (50-inch, 55-inch, 65-inch) fit on it.

#### 4. PARTS LIST

Before assembly, verify that all parts and hardware are present. Refer to the included hardware bag and the assembly video for a complete list of components.

##### Key Components:

- Engineered Wood Panels (various sizes for top, bottom, sides, and shelves)
- Clear Acrylic Support Columns (4 pieces)
- Glass Partition (1 piece)
- LED Light Strip Kit (includes LED strip, remote controller, power adapter, and signal receiver)
- Assorted Screws, Dowels, and Cam Locks
- Glass Shelf Supports
- Invisible Stickers (for screw holes)

#### 5. SETUP AND ASSEMBLY

Follow the steps below for proper assembly. It is recommended to have two people for assembly.

## 5.1. Preparation

- Clear a spacious area for assembly.
- Unpack all components and lay them out on a soft, clean surface to prevent scratches.
- Identify each part by its label (e.g., Board 1, Board 2, etc.) and corresponding hardware.

## 5.2. Assembly Steps

1. **Assemble Base Panels:** Attach the side panels to the bottom panel using the specified screws and cam locks. Ensure all connections are secure.
2. **Install Acrylic Supports:** Secure the four clear acrylic support columns to the designated positions on the lower shelf using the provided screws.
3. **Attach Middle Shelf:** Connect the middle shelf to the side panels and the acrylic supports. Use cam locks and screws as indicated in the instructions.
4. **Insert Glass Partition:** Carefully slide the glass partition into the pre-drilled slots in the middle section. Use the glass shelf supports to secure it in place.
5. **Attach Top Panel:** Place the top panel onto the acrylic supports and secure it using the remaining screws and cam locks.
6. **Install Feet/Base:** Attach the base supports (F accessories) to the bottom of the TV stand using the specified screws (G screws).
7. **Apply Invisible Stickers:** Cover any visible screw holes with the provided invisible stickers (L size) for a clean finish.

## 5.3. Assembly Video

For a visual guide, please refer to the official assembly video provided by Cubehom:

Your browser does not support the video tag.

Video: A detailed animation demonstrating the step-by-step assembly process of the Cubehom LED TV Stand.

## 6. OPERATING INSTRUCTIONS (LED LIGHTS)

The TV stand includes an integrated LED lighting system with multiple color options and modes, controlled by a remote.

### 6.1. LED Light Strip Installation

1. **Prepare the LED Strip:** Gently peel off the protective film from the adhesive backing of the LED light strips.
2. **Attach LED Strips:** Carefully paste the two LED light strips onto the back edges of the top panel and the middle shelf (Board 1 and Board 7 as per assembly video). Ensure they are securely attached and positioned to illuminate the shelves.
3. **Connect Power:** Connect the power cord to the signal receiver, then connect the signal receiver to the LED light strip interface. Ensure the arrows on the connectors are aligned.

### 6.2. Using the Remote Control

The included RF Remote Controller allows you to customize the lighting:

- **Power On/Off:** Use the 'ON' and 'OFF' buttons to turn the lights on or off.
- **Color Selection:** Press the colored buttons (R, G, B, W, and other color options) to select a static color.

- **Brightness Control:** Use the sun icons to adjust the brightness of the lights.
- **Mode Selection:** Buttons like 'FLASH', 'STROBE', 'FADE', and 'SMOOTH' allow you to choose dynamic lighting effects.



## MULTIPLE COLORS CHANGE

Multi-colour LED lighting effects - with remote control for easy remote on/off and colour control



16 RGB  
LIGHTS



BRIGHTNESS  
CONTROL



REMOTE  
CONTROLS




Image: The remote control for the LED lights, demonstrating various color and mode options for the TV stand's illumination.

Your browser does not support the video tag.

Video: A short demonstration of the LED lights changing colors on the TV stand, controlled by the remote.

## 7. MAINTENANCE

- **Cleaning:** Wipe the surfaces with a soft, dry cloth. For stubborn marks, use a slightly damp cloth with mild soap and dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Glass Care:** Clean the glass partition with a glass cleaner and a soft, lint-free cloth.
- **LED Lights:** Ensure the LED strips are free from dust. If any issues arise with the lights, check connections before troubleshooting.
- **Stability Check:** Periodically check all screws and connections to ensure they remain tight and secure.

## 8. TROUBLESHOOTING

- **Damaged Parts Upon Arrival:** If any parts are cracked or damaged upon unboxing, do not proceed with assembly. Contact customer support for replacement parts.
- **Difficulty with Assembly:** Review the assembly video and instructions carefully. Ensure all parts are correctly oriented and the correct hardware is used for each step.
- **LED Lights Not Working:** Check that the power adapter is securely plugged into a working outlet and the signal receiver is correctly connected to both the power cord and the LED strips. Ensure the remote control has working batteries.
- **Remote Control Issues:** If the remote is unresponsive, replace its battery. Ensure there are no obstructions between the remote and the signal receiver.

## 9. SPECIFICATIONS

Feature	Specification
Brand	Cubehom
Model Number	JCF16-2new
Color	Black
Size	51 inches (Length)
Product Dimensions	51 x 16 x 21 inches
Item Weight	36 pounds
Material	Engineered Wood
Special Feature	LED Light Stand
Number of Shelves	1 (plus top and bottom surfaces)
Included Components	Instructions and fixings

## 10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your product packaging or contact Cubehom customer service directly. Keep your purchase receipt for warranty claims.