Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Samsung LH43BEAHLGKLXL

Samsung 43-inch 4K UHD Smart LED TV LH43BEAHLGKLXL User Manual

Introduction

This user manual provides comprehensive instructions for the Samsung 43-inch 4K Ultra HD Smart LED TV, model LH43BEAHLGKLXL. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your television. The UHD display with HDR functionality delivers an eye-catching visual experience. Simple, ready-to-use content templates allow users to showcase personalized content alongside TV programming. The Samsung Business TV app enables easy content management and control.

What's in the Box

Upon unboxing your Samsung TV, please verify that all the following components are included:

- 1 LED TV
- 2 Table Top Stands
- 1 Remote Controller
- 1 Power Cable

Your browser does not support the video tag.

Video: This video demonstrates the unboxing process and shows the contents typically found inside the product packaging for the Samsung 43-inch 4K UHD Smart LED TV.

Setup Guide

1. Unpacking and Placement

Carefully remove the TV from its packaging. Place the TV on a stable, flat surface or mount it on a wall using a VESA compatible mount (200 x 200 mm, sold separately). Ensure adequate ventilation around the TV.



Image: Front view of the Samsung 43-inch 4K UHD Smart LED TV with its stand.

2. Attaching the Table Top Stand

If using the included table top stands, align each stand with the corresponding slots at the bottom of the TV. Secure them firmly with the provided screws. Refer to the diagram below for proper attachment.

3. Connecting Power

Connect the power cable to the TV's power input and then plug it into a wall outlet (220 VAC 50 Hz). Ensure the connection is secure.

4. Initial Power On and Basic Settings

Press the power button on the remote control or the TV. Follow the on-screen instructions to select your preferred language, connect to a Wi-Fi network, and complete the initial setup process for your Tizen operating system.



Image: Diagram showing the dimensions of the Samsung 43-inch 4K UHD Smart LED TV: 96.3 cm width, 62.7 cm height, and 19.2 cm depth with stand.

Operating Instructions

Remote Control Usage

The included remote control allows you to navigate the TV's interface, change channels, adjust volume, and access smart features. Familiarize yourself with the button layout for optimal control.

Smart TV Features (Tizen OS)

Your Samsung TV runs on the Tizen operating system, providing access to a variety of internet applications such as Amazon Instant Video, Netflix, and YouTube. You can also use the built-in browser. Navigate through the Smart Hub to discover and launch applications.

Connectivity

The TV features multiple connectivity options:

- **HDMI Ports:** 3 ports for connecting external devices like set-top boxes, gaming consoles, or Blu-ray players.
- **USB Ports:** 1 port for connecting USB storage devices to play media files.
- **Wi-Fi:** Built-in Wi-Fi for wireless internet connectivity.
- **Mobile to TV:** Supports content sharing from mobile devices to the TV.



Image: Side view of the Samsung 43-inch 4K UHD Smart LED TV, highlighting its slim profile.

Maintenance

Cleaning the TV

To clean the screen, gently wipe it with a soft, dry microfiber cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Avoid using harsh chemicals, abrasive materials, or direct spraying of liquids onto the screen or frame. Always unplug the TV before cleaning.

Software Updates

Periodically check for software updates through the TV's settings menu to ensure optimal performance, security, and access to new features. Updates can typically be found under "Settings > Support > Software Update".

Troubleshooting

If you encounter issues with your TV, refer to the following common troubleshooting steps before contacting support:

- **No Power:** Ensure the power cable is securely connected to both the TV and the wall outlet. Try plugging another device into the same outlet to confirm it's working.
- **No Picture/Sound:** Check all HDMI and audio connections. Ensure the correct input source is selected on the TV. Restart connected devices.

- **Remote Control Not Working:** Replace the batteries in the remote. Ensure there are no obstructions between the remote and the TV's IR receiver.
- **Network Connection Issues:** Verify your Wi-Fi router is on and functioning. Try restarting the router and the TV. Check network settings on the TV.
- **Picture Quality Issues:** Adjust picture settings (brightness, contrast, color). Ensure the input source is providing a high-quality signal.

For more detailed troubleshooting or persistent issues, please refer to the Samsung support website or contact customer service.

Specifications

Screen Size	43 Inches (108 cm)
Display Technology	LED
Resolution	4K Ultra HD
Refresh Rate	60 Hz
HDR Format Supported	Dolby Vision
Operating System	Tizen
Connectivity Technology	HDMI, USB, Wi-Fi
Total HDMI Ports	3
Total USB Ports	1
Audio Output Mode	Surround (Dolby Surround Sound)
Wattage	20 Watts
Power Consumption	0.5 Watts (Standby)
Product Dimensions (D x W x H)	19.2D x 96.3W x 62.7H Centimeters
Item Weight	8.3 Kilograms
VESA Mount Standard	200 x 200 mm
Model Number	LH43BEAHLGKLXL
Model Year	2022

Warranty and Support

Warranty Information

Your Samsung 43-inch 4K UHD Smart LED TV comes with a**3 Years Comprehensive Warranty** provided by Samsung from the date of purchase. To avail warranty services, please contact the brand's toll-free number and provide the product's model name (LH43BEAHLGKLXL) and seller's details as mentioned on your invoice. The service center will then assist you in scheduling a service appointment.

Customer Support

For technical assistance, service requests, or any inquiries regarding your product, please contact Samsung Customer Service:

- **Toll-Free Number:** 1800-40726-7864 (1800-40-SAMSUNG)
- **Online Support:** Visit the official Samsung support website for FAQs, downloads, and further assistance.

Please have your product model number (LH43BEAHLGKLXL) and purchase invoice ready when contacting support.

© 2022 Samsung. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BMPQBTZ4

More documents and user manuals: **https://manuals.plus/**