realme RMP2107

realme Pad X WiFi+5G Tablet User Manual

Visit the realme Store

1. Product Overview

The realme Pad X is a versatile tablet designed for various tasks, from entertainment to productivity. It features a large WUXGA+ display, a powerful Snapdragon 695 processor, and a long-lasting battery. This manual provides instructions for setting up, operating, and maintaining your device.



Image: realme Pad X tablet highlighting its slim profile, large display, and compatibility with the realme Pencil.

2. Setup Guide

2.1 Unboxing and Initial Inspection

Carefully remove all items from the packaging. Ensure the following components are present:

- realme Pad X Tablet
- Charger
- Charging Cable
- User Manual

2.2 Charging the Device

Before first use, fully charge your realme Pad X. Connect the charging cable to the tablet's USB-C port and the charger. Plug the charger into a power outlet. The tablet supports 33W Dart Charge for faster charging.

2.3 Powering On/Off

- **To Power On:** Press and hold the Power button until the realme logo appears.
- **To Power Off:** Press and hold the Power button, then select 'Power Off' from the options on the screen.
- **To Restart:** Press and hold the Power button, then select 'Restart' from the options.

2.4 Initial Setup Wizard

Upon first power-on, follow the on-screen instructions to complete the initial setup. This includes selecting your language, connecting to a Wi-Fi network, and setting up your Google account.

2.5 5G Connectivity Setup

For models with 5G capability, insert a nano-SIM card into the designated SIM tray. Use the provided SIM ejector tool to open the tray. Ensure the SIM card is correctly oriented. After insertion, the tablet will automatically detect the network. You may need to configure APN settings if prompted by your service provider.




Image: realme Pad X screen showing 5G network connectivity, indicating high-speed internet access.

3. Operating Instructions

3.1 Touchscreen Gestures

The realme Pad X features a responsive touchscreen. Common gestures include:

- **Tap:** Select an item or open an app.
- **Long Press:** Access contextual menus or move icons.
- **Swipe:** Navigate through screens or scroll content.
- **Pinch-to-Zoom:** Enlarge or reduce content size.

3.2 Display Features

The tablet is equipped with a 27.81 cm (10.95 inch) WUXGA+ Full View Display with a resolution of 2000 x 1200 pixels. It offers 450 nits peak brightness and 16.7 million screen colors. The display also features DC Dimming for comfortable viewing and is TÜV Rheinland Certified for low blue light emission.



Image: realme Pad X display showcasing its WUXGA+ Full View capabilities with rich colors.

3.3 Performance

The realme Pad X is powered by a Qualcomm Snapdragon 695 6nm 5G Processor, featuring Flagship A78 cores and speeds up to 2.2GHz, ensuring smooth operation for applications and multitasking.



Image: Internal diagram of the realme Pad X highlighting the Snapdragon 6nm 5G Processor.

3.4 Audio System

Experience immersive sound with the tablet's Quad Speakers featuring Dolby Atmos. This setup provides a cinematic audio experience for media consumption.



Image: Diagram illustrating the quad speaker placement and Dolby Atmos audio technology on the realme Pad X.

3.5 Camera Functions

The realme Pad X includes a 13 MP primary rear camera and an 8 MP front camera. The front camera features a 105° wide-angle lens and Limelight functionality, which keeps you centered during video calls, compatible with apps like Google Duo, Google Meet, and Zoom.



Image: realme Pad X screen during a video call, demonstrating the Limelight feature that keeps the user in frame.

3.6 Multi-screen Collaboration

Enhance your productivity with Multi-screen Collaboration, allowing seamless interaction between your realme Pad X and other compatible devices. Features include auto-discovery, screen mirroring, reverse control, casting sleeping screen, text cut, and drag & drop transfer.



Image: realme Pad X and a smartphone connected via multi-screen collaboration, showing shared content and control options.

3.7 realme Pencil Compatibility

The realme Pad X is compatible with the realme Pencil (sold separately). The pencil offers 4096 levels of pressure sensitivity, 60° sideways writing, and a 240Hz touch sampling rate. It supports wireless magnetic charging and provides approximately 10.6 hours of battery life.



Image: A hand using the realme Pencil on the realme Pad X, illustrating its creative capabilities.

3.8 realme Smart Keyboard Compatibility

For enhanced productivity, the realme Pad X is compatible with the realme Smart Keyboard (sold separately). This keyboard features 1.3mm deep key travel, multi-functional shortcut keys, and a skin-friendly material for comfortable typing.



Image: realme Pad X connected to the realme Smart Keyboard, showcasing its use as a productivity tool.

4. Maintenance

4.1 Battery Management

The realme Pad X is equipped with an 8340 mAh Lithium Ion battery. To maximize battery life:

- Avoid extreme temperatures.
- Use the original charger and cable for optimal charging.
- Close unused applications running in the background.
- Adjust screen brightness to a comfortable level.



Image: Diagram showing the 8340mAh battery of the realme Pad X and estimated usage times for various activities.

4.2 Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using harsh chemicals or abrasive materials, which can damage the display or finish.

4.3 Software Updates

Regularly check for and install software updates to ensure optimal performance, security, and access to new features. You can usually find update options in the tablet's settings menu.

5. Troubleshooting

This section addresses common issues you might encounter with your realme Pad X.

- **Device Not Powering On:** Ensure the battery is charged. Connect the tablet to its charger for at least 30 minutes, then attempt to power it on. If the issue persists, perform a forced restart by holding the Power button for an extended period (e.g., 10-15 seconds).
- **Charging Issues:** Verify that the charger and cable are securely connected and undamaged. Try using a different compatible charger and cable if available. Ensure the charging port is free of debris.
- **Wi-Fi/5G Connectivity Problems:** Check if Wi-Fi or mobile data is enabled in settings. Restart your router or modem for Wi-Fi issues. For 5G, ensure your SIM card is properly inserted and your plan supports 5G. Try toggling airplane mode on and off.
- **Slow Performance or Lag:** Close unnecessary background applications. Clear cached data from apps. Ensure you have sufficient storage space. Restarting the tablet can often resolve temporary performance issues. Consider performing a factory reset as a last resort (back up your data first).
- **Touchscreen Unresponsive:** Restart the tablet. If only a specific area is unresponsive, ensure the screen is clean and free of moisture. If the entire screen is unresponsive, a hardware issue may be present.

6. Specifications

Feature	Detail
Brand	realme
Model Name	realme Pad X

Model Number	RMP2107
Memory Storage Capacity	128 GB
RAM Memory Installed	6 GB
Screen Size	10.95 Inches (27.81 cm)
Display Resolution Maximum	2000 x 1200 Pixels (WUXGA+)
Display Type	LCD
Processor Brand	Qualcomm
Processor Description	Snapdragon 600 Series (Snapdragon 695)
Operating System	Android
Battery Capacity	8340 mAh
Battery Cell Type	Lithium Ion
Rear Facing Camera Photo Sensor Resolution	13 MP
Front Photo Sensor Resolution	8 MP
Cellular Technology	5G
Network Connectivity Technology	Cellular, Wi-Fi
Other Special Features	Fast Charging, Stereo Speakers
Item Weight	506 Grams
Item Dimensions (L x W x Thickness)	25.7L x 16.1W x 0.7Th Centimeters
Compatible Devices	Stylus Pen, Keyboard

7. Warranty Information

The realme Pad X comes with a**1 Year Manufacturer Warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects but does not cover damage caused by misuse, accidents, or unauthorized modifications.

8. Support Information

For technical assistance, service, or further inquiries, please contact:

- **Manufacturer:** LONGCHEER ELECTRONICS (HUIZHOU) CO.LIMITED
  BUILDING 1, NO. 28 (WEST) HECHANG SIX ROAD, ZHONGKAI HIGH-TECH ZONE, HUIZHOU, GUANGDONG, CHINA
- **Importer:** OPPO MOBILES INDIA PRIVATE LIMITED
  ADDRESS: 5TH FLOOR, TOWER B, BUILDING NUMBER 8, DLF CYBER CITY, GURUGRAM, HARYANA-122002, INDIA

You may also visit the official realme support website for FAQs and additional resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question