Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tolxh #90558556

Tolxh #90558556 Sander Pad Tip Instruction Manual

Compatible Replacement Part for Black & Decker MS1000, MS500K, MS700BA, MS700GB, MS700K, RO600 Series Sanders

1. Product Overview

This document provides instructions for the Tolxh #90558556 Sander Pad Tip, a compatible replacement part designed for specific Black & Decker sander models. This pad tip is engineered to meet manufacturing requirements for functionality and durability, serving as a direct replacement for the original part.



Figure 1: The Tolxh #90558556 Sander Pad Tip. This image displays the black, square-shaped pad tip with a central mounting hole, indicating its design for attachment to a sander.

2. Compatibility

The Tolxh #90558556 Sander Pad Tip is compatible with the following Black & Decker sander models:

- MS1000 Type 1
- MS500K Type 4
- MS700BA Type 1

- MS700GB Type 1
- MS700K Type 1
- RO600 Type 1
- RO600 Type 2
- RO600K Type 2

Please verify your sander's model number to ensure proper fit and function before installation.

3. Installation Instructions

Follow these general steps for replacing the sander pad tip. Always refer to your specific Black & Decker sander's original manual for detailed safety precautions and model-specific instructions.

1. **Safety First:** Before beginning any maintenance or replacement, ensure the sander is unplugged from its power source to prevent accidental startup.
2. **Remove Old Pad:** Locate the existing sander pad tip. Depending on your model, it may be held in place by screws, clips, or a hook-and-loop system. Carefully remove any fasteners and detach the old pad.
3. **Clean Mounting Surface:** Inspect the sander's mounting surface for any debris, dust, or residue. Clean it thoroughly to ensure a secure and flat attachment for the new pad.
4. **Position New Pad:** Align the new Tolxh #90558556 Sander Pad Tip with the mounting holes or attachment points on your sander. Ensure it is oriented correctly.
5. **Secure New Pad:** Attach the new pad using the appropriate fasteners (screws, clips, etc.) that were used for the old pad. Tighten screws securely but do not overtighten, as this can damage the pad or the sander.
6. **Test Functionality:** Once the new pad is securely installed, plug in the sander and briefly test its operation to ensure the pad is stable and functions as expected.

Note: If you encounter any difficulties or are unsure about the installation process, consult a qualified technician or your sander's original instruction manual.

4. Maintenance

Proper maintenance of your sander pad tip can extend its lifespan and ensure optimal sanding performance.

- **Regular Cleaning:** After each use, remove any accumulated dust or sanding debris from the pad surface. A brush or compressed air can be used for this purpose.
- **Inspect for Wear:** Periodically inspect the pad tip for signs of wear, such as thinning, tearing, or loss of adhesion (if applicable). Replace the pad if significant wear is observed to maintain sanding effectiveness and prevent damage to the workpiece.
- **Storage:** Store the sander in a clean, dry environment to protect the pad from moisture and extreme temperatures.

5. Specifications

Part Number	#90558556
Brand	Tolxh
Compatibility	Black & Decker MS1000, MS500K, MS700BA, MS700GB, MS700K, RO600, RO600K Series Sanders
Material	Durable materials (as per manufacturer)

Included Components	(1) Pad Tip

6. Troubleshooting

If you encounter issues after installing the new sander pad tip, consider the following:

- **Pad Not Attaching Securely:**
  - Ensure the pad is correctly aligned with the mounting holes.
  - Check that all fasteners are properly tightened.
  - Verify that the sander model is listed in the compatibility section.
- **Excessive Vibration or Noise:**
  - Confirm the pad is evenly seated and securely fastened.
  - Inspect the sander's internal components for any other issues.
- **Poor Sanding Performance:**
  - Ensure the correct grit sandpaper is being used and is properly attached to the pad.
  - Check the pad for any damage or uneven wear.

If problems persist, contact customer support for further assistance.

7. Warranty and Support

Tolxh is committed to customer satisfaction. This product comes with a one-month refund policy if errors during installation or replacement lead to damage or inability to use the product.
For any questions, concerns, or support needs regarding your Tolxh #90558556 Sander Pad Tip, please contact our customer service. We aim to provide a satisfactory solution to any issues you may encounter.
Note: This is a non-original compatible spare part. Manufacturer's name and part numbers are for reference only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BMVJ4K99

More documents and user manuals: **https://manuals.plus/**