

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [GE APPLIANCES](#) /

› [GE 24-inch Built-In Dishwasher User Manual](#)

GE APPLIANCES GDF535PGRBB

GE 24-inch Built-In Tall Tub Front Control Black Dishwasher User Manual

Model: GDF535PGRBB

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your new GE 24-inch Built-In Tall Tub Front Control Black Dishwasher. Designed for efficiency and convenience, this appliance features a 14 place setting capacity, a Piranha Hard Food Disposer, and versatile installation options including top or side mount brackets, and is built-up floor capable. Please read this manual thoroughly before using your dishwasher to ensure safe and optimal performance.



Front view of the GE 24-inch Built-In Tall Tub Front Control Black Dishwasher. This image shows the sleek black exterior with the front control panel visible at the top.

SETUP AND INSTALLATION

Proper installation is crucial for the performance and longevity of your dishwasher. This model supports both top or side mount installation brackets, offering flexibility for various kitchen cabinet configurations. It is also designed to be built-up floor capable, accommodating different floor heights.

Pre-Installation Checklist:

- Ensure adequate space for the dishwasher (standard 24-inch opening).
- Verify electrical and water supply connections are readily accessible.
- Confirm drain hose routing options.
- Prepare the floor area if a built-up floor installation is required.



The GE dishwasher seamlessly installed within a modern kitchen setting, demonstrating its built-in appearance under a countertop.

OPERATING INSTRUCTIONS

Your GE dishwasher offers multiple cycle options and features to ensure your dishes are thoroughly cleaned and sanitized.

Control Panel Overview:



A detailed view of the dishwasher's front control panel, showing buttons for various cycles and options like Dry Boost, Wash Temp, and Start.

The front control panel allows you to select from various wash cycles and options. Common cycle options include Sanitize, Dry Boost, and Steam + Sani. Refer to the control panel image for button layout.

Loading the Dishwasher:

Proper loading ensures optimal cleaning performance. Arrange dishes to allow water and detergent to reach all surfaces.



The interior of the GE dishwasher with empty upper and lower racks, showcasing the spacious design and rack configuration.



The interior of the GE dishwasher with dishes loaded, demonstrating effective use of space for various dish sizes and types.



A person placing a blue bottle and plates into the top rack of the dishwasher, illustrating the ease of loading.



A person pulling out the bottom rack to load dirty dishes, including plates and cutlery, into the dishwasher.

Starting a Cycle:

1. Load dishes according to guidelines.
2. Add appropriate detergent to the dispenser.
3. Select your desired wash cycle and options.
4. Press the **Start** button to begin the cycle.

MAINTENANCE

Regular maintenance ensures your dishwasher operates efficiently and extends its lifespan.

Cleaning the Interior:

- Periodically clean the interior with a dishwasher cleaner or a mixture of vinegar and baking soda.

- Wipe down the door gasket to remove food particles and residue.

Piranha Hard Food Disposer:

Your dishwasher is equipped with a Piranha Hard Food Disposer, which pulverizes food particles to prevent clogs. While this system is highly effective, it is still recommended to scrape large food scraps from dishes before loading.

TROUBLESHOOTING

This section addresses common issues you might encounter with your dishwasher. For more complex problems, please contact customer support.

Problem	Possible Cause	Solution
Dishwasher not starting	Door not latched, power issue, cycle not selected	Ensure door is fully closed and latched. Check power supply. Select a cycle and press Start.
Dishes not clean	Improper loading, insufficient detergent, clogged spray arms	Review loading guidelines. Use correct amount of detergent. Clean spray arm nozzles.
Excessive noise	Foreign object in disposer, loose items in racks	Inspect Piranha Hard Food Disposer. Secure all items in racks.
Water not draining	Clogged drain hose, air gap issue	Check drain hose for kinks or blockages. Clean air gap if installed.

PRODUCT SPECIFICATIONS

Below are the key specifications for the GE 24-inch Built-In Tall Tub Front Control Black Dishwasher (Model GDF535PGRBB).

Feature	Detail
Model Name	GDF535PGRBB
Brand	GE APPLIANCES
Capacity	14 Place Settings
Noise Level	55 dB
Installation Type	Under Counter
Color	Black
Item Weight	55 Pounds
Voltage	120 Volts
Cycle Options	Sanitize, Dry Boost, Steam + Sani
Inner Material	plastic
UPC	084691856603






Feature	Detail
Included Components	Automatic Temperature Control, Hard Food Disposer, Hard Food Filter, Leak Sensor, Tall Tub

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official GE Appliances website or contact their customer service directly. You can also visit the [GE Store on Amazon](#) for additional resources and product information.

For technical assistance or to schedule service, have your model number (GDF535PGRBB) and serial number ready.

Related Documents - GDF535PGRBB

	GE GDF550PGR/PMR/PSR Plastic Interior Dishwasher with Front Controls - Installation and Features Installation dimensions, electrical ratings, and key features of the GE GDF550PGR/PMR/PSR plastic interior dishwasher with front controls, including Dry Boost, Steam + Sani, and AutoSense Wash Cycle.
	GE GFD35ESPYDS 7.8 cu. ft. Smart Front Load Electric Dryer with Quick Dry - Specifications & Installation Detailed specifications, dimensions, installation requirements, features, and accessories for the GE GFD35ESPYDS 7.8 cu. ft. Smart Front Load Electric Dryer with Quick Dry. Includes venting information and warranty details.
	GE Appliances Standard Tub Dishwashers Owner's Manual This owner's manual provides essential safety information, operating instructions, care and cleaning tips, troubleshooting guidance, warranty details, and consumer support for GE Appliances Standard Tub Dishwashers.
	GE Appliances Built-In & Spacemaker Dishwasher Installation Instructions Comprehensive installation guide for GE Appliances Built-In and Spacemaker dishwashers, covering preparation, electrical, plumbing, and final checks. Ensure proper setup for optimal performance and safety.
	GE Profile PTD60GBSR/BPR 7.4 cu. ft. Gas Dryer Installation Guide Detailed installation, dimensions, and features for the GE Profile PTD60GBSR/BPR 7.4 cu. ft. aluminized alloy drum gas dryer. Covers exhaust options, gas requirements, clearances, ducting, and key benefits like Sanitize Cycle, Sensor Dry, and SmartHQ WiFi.

Comprehensive installation guide for GE Appliances Built-In Dishwashers, covering preparation, electrical, plumbing, and final testing procedures.