



Manuals.plus /

› Lazellz /

› Dryer Lint Filter And Cover - Sits Flush - Compatible with LG Model Numbers DLEX4000W, DLEX4070V, DLEX4070W, DLEX4270V

Lazellz DLEX4000W, DLEX4070V, DLEX4070W, DLEX4270V

Dryer Lint Filter and Cover User Manual

Model Numbers: DLEX4000W, DLEX4070V, DLEX4070W, DLEX4270V

PRODUCT OVERVIEW

This product is a replacement lint filter and housing cover assembly designed for specific LG dryer models. Its primary feature is a design that allows the lint filter to sit flush with the housing cover, addressing issues where some filters may protrude and snag clothing. This assembly includes one lint filter and one housing cover.

COMPATIBILITY

This lint filter and housing cover assembly is compatible with the following LG dryer model numbers:

- DLEX4000W
- DLEX4070V
- DLEX4070W
- DLEX4270V

If your dryer model number is not listed above, please contact the seller for assistance in obtaining the correct part.

PACKAGE CONTENTS

The package includes:

- 1 x Lint Filter
- 1 x Housing Cover

Important Note: New screws are not included with this offering. Please retain the original screws from your old parts for installation.

INSTALLATION

Please be advised that specific installation instructions are not provided with this product. It is recommended to refer to your dryer's original user manual for detailed instructions on how to remove and replace the lint filter and housing cover. If you are unsure about the installation process, consider seeking assistance from a qualified appliance technician.

When replacing the parts, ensure that the new lint filter sits flush within the housing cover as designed. Remember to use the screws from your old parts, as new screws are not supplied.




Figure 1: The image displays the two components of the product: the lint filter and the housing cover, shown separately on the left. On the right, these two components are shown assembled together, illustrating how they fit to form the complete unit. This visual confirms the "sits flush" design.

MAINTENANCE

Regular cleaning of your dryer's lint filter is crucial for optimal dryer performance and safety. After each load, remove the lint filter and clear any accumulated lint. This prevents lint buildup, which can restrict airflow, increase drying time, and pose a fire hazard. Periodically, wash the lint filter with warm, soapy water and a soft brush to remove any residue from fabric softener sheets or detergents that may clog the screen. Rinse thoroughly and allow it to air dry completely before reinserting it into the dryer.

TROUBLESHOOTING

- **Filter Does Not Sit Flush:** Ensure you have the correct model number for your dryer. Verify that the lint filter is correctly seated within the housing cover and that the housing cover is properly installed in the dryer.
- **Difficulty Inserting/Removing:** Check for any obstructions in the dryer's lint filter slot. Ensure the filter and housing cover are clean and free of debris.
- **Dryer Performance Issues (e.g., long drying times):** While this product is a replacement part, ensure the lint filter is clean and not clogged. If issues persist, consult your dryer's main user manual or a qualified technician, as the problem may not be related to the lint filter assembly.

SPECIFICATIONS

Brand	Lazellz
Part Number	780485
Compatible Models	DLEX4000W, DLEX4070V, DLEX4070W, DLEX4270V
Material	Durable Plastic And Screen
Included Components	Lint Filter And Housing Cover
Item Weight	2 ounces
Product Dimensions	16 x 16 x 2 inches
Country of Origin	USA

SUPPORT

For any questions regarding this product, compatibility, or if you require assistance, please contact the seller directly through the platform where you purchased the item. Provide your product details and dryer model number for efficient support.

