Hot Wheels HNG50

Hot Wheels City Ultimate T-Rex Transporter Instruction Manual

Model: HNG50

Introduction

The Hot Wheels City Ultimate T-Rex Transporter is an innovative toy that combines the thrill of a car hauler with the excitement of a transforming dinosaur and a two-lane race track. Designed for endless imaginative play, this set offers multiple modes of interaction for young enthusiasts.

Key features include:

- Transforms from a 20+ toy car transporter to a growling and stomping T-Rex.
- Hauler mode allows it to devour 1:64 scale vehicles and store them.
- T-Rex mode features animated stomping action, lights, and sounds.
- Integrated two-lane race track on the T-Rex's back for competitive play.
- Cars can be launched from the T-Rex's mouth.
- Lights and sounds enhance the fun with glowing red eyes and various dino noises.

Setup

Before beginning play, ensure all components are present and batteries are installed.

What's in the Box:

- 1 Hot Wheels City Ultimate Hauler
- 2 Hot Wheels Cars (1:64 scale)

Battery Installation:

The Ultimate T-Rex Transporter requires 3 AAA batteries (included). Locate the battery compartment, typically on the underside of the main body. Use a small Phillips head screwdriver to open the compartment, insert the batteries according to the polarity indicators (+/-), and securely close the compartment.



Image: The Hot Wheels City Ultimate T-Rex Transporter in its hauler configuration, ready for play.

Operating Instructions

1. Hauler Mode:

In its primary hauler configuration, the T-Rex Transporter functions as a large vehicle carrier. Roll the hauler forward to activate its "eating" mechanism, allowing it to pick up 1:64 scale Hot Wheels cars in its path. The internal compartments can store over 20 vehicles.



Image: The hauler's mouth mechanism, designed to "eat" and store toy cars as it rolls.



Image: A child engaging with the hauler, demonstrating its car-collecting feature.

2. T-Rex Transformation & Race Track Mode:

To transform the hauler into a stomping T-Rex with a race track, simply pull back the tail. The hauler will articulate upwards, revealing the dinosaur's upright stance and activating lights and sounds. The back of the T-Rex forms a two-lane race track.

- **Transformation:** Pull the tail of the hauler upwards and backwards until the T-Rex stands upright.
- **Race Track:** Place two 1:64 scale Hot Wheels cars at the starting gates on the T-Rex's back. Launch them simultaneously to race down the two lanes. The winning car continues, while the second-place car is "pooped" out of the dino's rear.
- **Car Launch:** Press the lever near the T-Rex's mouth to launch cars forward, simulating the dino spitting them out.



Image: The hauler transforming into its upright T-Rex configuration.



Image: The Robo T-Rex in its active state, featuring glowing eyes and sound activation.



Image: The two-lane race track on the T-Rex's back, with cars in motion.

Maintenance

To ensure the longevity and optimal performance of your Hot Wheels City Ultimate T-Rex Transporter, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the toy with a soft, damp cloth. Do not immerse in water or use harsh chemicals, as this may damage electronic components and paint.
- **Storage:** Store the toy in a cool, dry place away from direct sunlight and extreme temperatures. Ensure all cars are properly stored within the hauler to prevent loss.
- **Battery Care:** Remove batteries if the toy will not be used for an extended period to prevent leakage and corrosion.

Troubleshooting

If you encounter any issues with your Hot Wheels City Ultimate T-Rex Transporter, please refer to the following common solutions:

Problem	Possible Cause	Solution
No lights or sounds	Dead or incorrectly installed batteries.	Check battery polarity. Replace with fresh AAA batteries.
Cars not "eating" properly in hauler mode	Obstruction in the mouth mechanism; incorrect car size.	Clear any debris from the mouth. Ensure using 1:64 scale Hot Wheels cars.
Transformation is stiff or incomplete	Mechanism might be jammed or not fully extended/retracted.	Gently manipulate the tail and legs to ensure smooth movement. Do not force.

Problem	Possible Cause	Solution
Cars not racing smoothly on track	Track surface is dirty; cars are damaged.	Clean the track surface. Use undamaged 1:64 scale Hot Wheels cars.

Specifications

Feature	Detail
Product Dimensions	6.65 x 25 x 13.65 inches
Item Weight	7.7 pounds
Item Model Number	HNG50
Manufacturer Recommended Age	4 years and up
Batteries Required	3 AAA batteries (included)
Manufacturer	Mattel
Country of Origin	China

Warranty and Support

For warranty information and customer support, please refer to the official Mattel website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question