Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tiptiper N-W

Tiptiper LED Nightstand with Wireless Charging Station (Model N-W)

Instruction Manual

1. Product Overview

The Tiptiper LED Nightstand (Model N-W) is a versatile furniture piece designed to enhance your bedroom or living space. It features integrated RGB LED lighting, a convenient power strip with wireless charging, USB ports, and AC outlets, along with ample storage including drawers and a pull-out tray. This manual provides essential information for safe assembly, operation, and maintenance.

Video: Quick overview of the Tiptiper LED Nightstand features, including LED lights and charging capabilities.

2. Safety Information

- **Anchoring:** To prevent tipping and ensure stability, it is crucial to anchor the nightstand to the wall using the provided hardware.
- **Indoor Use Only:** This product is designed for indoor use only. Do not expose to moisture or extreme temperatures.
- **Electrical Safety:** Do not overload the power strip. Ensure all connections are secure before use. Avoid spilling liquids near electrical components.
- **Assembly:** Follow all assembly instructions carefully. Do not overtighten screws. Keep small parts away from children.

3. Package Contents

Please verify that all components are present before beginning assembly:

- 1 x Tiptiper Nightstand
- 1 x LED Light Strip
- 1 x Power Strip with Wireless Charger
- 1 x Assembly Kit (hardware and tools)
- 1 x Instruction Manual (this document)

4. Assembly Instructions

Detailed step-by-step assembly instructions are included in your package. Please refer to the printed manual for specific diagrams and hardware identification. All necessary parts and tools are provided in the assembly kit.

General Assembly Tips:

- Lay out all components and hardware before starting.
- Ensure you have a clean, spacious area for assembly.
- Do not fully tighten screws until all parts are correctly aligned.
- Use a screwdriver as recommended for secure fastening.



Image: The fully assembled Tiptiper LED Nightstand, showcasing its design and features.

5. Product Features and Operation

5.1 RGB LED Lights

The nightstand features RGB LED lights with over 60,000 color options and adjustable brightness. Control the lights via a physical button or through a mobile application. The app offers additional modes including style, music, and microphone modes, plus a timer function for scheduled on/off times.



Image: Illustration of the LED light control options, including key control and mobile app control with various modes and colors.

Video: Demonstrates how to use the remote control for the LED lights, including removing the transparent card and aiming at the infrared sensor.

5.2 Power Strip with Wireless Charging

An integrated power strip on the desktop includes a wireless charger, two USB ports, and two AC power sockets. This allows for convenient charging of mobile phones, headphones, tablets, and other electronic devices.



Image: A close-up view of the nightstand's top surface, highlighting the built-in wireless charging pad, USB ports, and AC outlets for device charging.

5.3 Additional Pull-Out Tray

The nightstand features a compact pull-out tray that expands the desktop space. This is ideal for temporary use when additional surface area is needed, such as holding a tablet or a drink.



Image: The pull-out tray extended from the nightstand, providing extra surface area for items like a tablet or small accessories.

5.4 Storage Space

The nightstand offers ample storage with a large open compartment and two smooth-gliding drawers. This provides convenient space for daily essentials, books, and other personal items.



Image: Detailed views of the grey wood grain finish, a metal drawer handle, and the smooth metal drawer slide mechanism.

6. Usage Scenarios

The modern and stylish design of this LED nightstand allows it to seamlessly integrate into various room decors. It can function as a bedside table, an end table, or a simple storage cabinet in different settings.

- **Bedroom:** Perfect as a nightstand next to your bed, providing light, charging, and storage for nighttime essentials.
- **Living Room:** Functions as a stylish end table beside a sofa or armchair.
- **Gaming Room or Study:** Offers convenient storage and charging for electronic devices and accessories.




Image: The Tiptiper LED Nightstand positioned next to a bed in a bedroom, with its blue LED lights illuminated, showcasing its use as a bedside table.



Image: The Tiptiper LED Nightstand used as an end table in a living room, with its pink LED lights illuminated, demonstrating its versatility.

7. Specifications

Feature	Specification
Brand	Tiptiper
Model Name	Nightstand with wireless charging station
Model Number	N-W
Product Dimensions	13.9"D x 15.83"W x 23.62"H
Item Weight	26.5 Pounds
Color	Grey
Frame Material	Engineered Wood

Number of Drawers	2
Included Components	1 x Nightstand, 1 x LED Light Strip, 1 x Power Strip, 1 x Assembly Kit, 1 x Instructions
Tools Recommended For Assembly	Screw Driver

8. Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Dusting:** Regularly dust the nightstand to prevent buildup.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood grain finish.
- **Electrical Components:** Ensure the power strip and LED lights are kept dry. Do not attempt to repair electrical components yourself.

9. Troubleshooting

- **LED Lights Not Working:**
  - Check if the power strip is plugged in and turned on.
  - Ensure the LED light strip is securely connected to the power source.
  - If using the remote, ensure the transparent battery tab is removed and aim it directly at the infrared sensor.
  - Verify the mobile app connection if controlling via smartphone.
- **Wireless Charging Not Functioning:**
  - Confirm the power strip is active.
  - Ensure your device is compatible with wireless charging (Qi-enabled).
  - Remove any thick phone cases that may interfere with charging.
  - Center your device properly on the wireless charging pad.
- **Drawers Sticking:**
  - Check for any obstructions in the drawer slides.
  - Ensure the drawer slides are properly aligned and lubricated if necessary.
  - Verify that the nightstand is on a level surface.

10. Warranty and Support

For warranty information, product support, or to report any issues, please refer to the contact details provided in your purchase documentation or visit the official Tiptiper website. Keep your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BN1RVYHL

More documents and user manuals: **https://manuals.plus/**