

[Manuals.plus](#) /

› [TOMEEM](#) /

› TOMEEM Electric Salt and Pepper Grinder Set User Manual

TOMEEM NDSBYMQ01

TOMEEM Electric Salt and Pepper Grinder Set User Manual

Model: NDSBYMQ01

1. PRODUCT OVERVIEW

This manual provides instructions for the TOMEEM Upgraded Larger Capacity Electric Salt and Pepper Grinder Set. This set features a rechargeable design, adjustable coarseness settings, and integrated LED lights for convenient seasoning.



Image: The TOMEEM Electric Salt and Pepper Grinder Set, including two grinders, a cleaning brush, two Type-C charging cables, and the product packaging box.

2. SETUP AND ASSEMBLY

2.1. Grinder Components and Features



Thicknesses White LED Light:

Visible even in dark environments

Visible Container:

Made of ABS food grade
Adjustable Ceramic Grinder:
5 adjustable

Power Indicator:

Flashes when charging and
remains on when fully charged

Bottom Cover:

Keep your desktop neat
and tidy

ON/OFF Button:

Easy and simple
one-button operation

Image: A detailed view of the electric grinder, highlighting key features such as the white LED light for visibility, the power indicator, the ON/OFF button for one-button operation, the visible container made of ABS food-grade material, the adjustable ceramic grinder, and the bottom cover to keep surfaces clean.

- **Visible Container:** Made of ABS food-grade material, allowing easy monitoring of spice levels.
- **Adjustable Ceramic Grinder:** Features 5 adjustable coarseness levels.
- **Bottom Cover:** Designed to keep your desktop neat and tidy by preventing spice residue.
- **Power Indicator:** Flashes during charging and remains illuminated when fully charged.

- **ON/OFF Button:** Provides easy and simple one-button operation.
- **White LED Light:** Illuminates the grinding area, visible even in dark environments.

2.2. Charging the Grinder

Before initial use, fully charge both grinders. The grinders feature a Type-C charging port for convenience.




Image: An electric grinder connected via a Type-C cable to a power source, illustrating the charging process. The image also indicates a 60-minute charging time and a 500mAh battery capacity.

- Connect the provided Type-C charging cable to the grinder's charging port and a suitable USB power adapter.
- The power indicator light will flash during charging.
- A full charge typically takes approximately 60 minutes. The indicator light will remain solid when fully charged.
- A single charge can provide approximately 3.5 jars of grinding time.

2.3. Filling the Grinder

The grinder is designed for easy refilling with a large diameter opening.



Image: The top section of the grinder is removed, showing the wide opening for easily adding whole peppercorns or salt crystals using a spoon.

1. Gently twist and lift the top stainless steel section of the grinder to separate it from the transparent spice container.
2. Fill the transparent container with your desired whole spices (e.g., peppercorns, salt crystals). Do not overfill; ensure the capacity does not exceed 2.3 ounces (approximately 66g) for pepper.
3. Align the top section with the container and twist it back into place until securely fastened.

3. OPERATING INSTRUCTIONS

3.1. One-Handed Operation

The electric grinder allows for convenient one-handed operation.

One-handed Easy Operating



Considerate
Bright Light



Image: A hand holding the electric grinder over a piece of cooked meat, demonstrating the one-handed operation as spices are dispensed and illuminated by the built-in LED light.

To operate, simply press and hold the ON/OFF button located on the side of the grinder. The grinder will automatically activate, and the LED light will illuminate the area where spices are being dispensed.

3.2. Adjusting Grinding Coarseness

The grinder features 5 adjustable coarseness levels to suit various culinary needs.



5-Level Adjustable Grinder

Meet a variety of cooking needs



Image: A close-up view of the bottom of the grinder, showing the rotary adjustment mechanism for coarseness, with indicators ranging from 'Coarse' to 'Fine'. Below, five distinct piles of ground spices illustrate the different coarseness levels achievable.

To adjust the coarseness, locate the rotary dial at the bottom of the grinder. Turn the dial clockwise for a finer grind and counter-clockwise for a coarser grind. Experiment with the settings to achieve your preferred consistency.

3.3. Step-by-Step Usage Guide



Image: A visual guide depicting four steps for using the electric grinder: 1. Adding seasoning, 2. Tightening the grinder, 3. Adjusting coarseness, and 4. Pressing the button to grind.

1. **Step 1: Add Seasoning.** Fill the transparent container with your desired whole spices.
2. **Step 2: Secure Grinder.** Tighten the grinder's top section and ensure the triangle icon is aligned with the latch position.
3. **Step 3: Adjust Coarseness.** Rotate the bottom adjustment dial to select your desired coarseness level.
4. **Step 4: Begin Grinding.** Press the ON/OFF button to start grinding fresh spices.

4. MAINTENANCE

4.1. Cleaning

- The transparent spice container is dishwasher safe for easy cleaning.
- Wipe the stainless steel exterior with a damp cloth. Do not immerse the main body of the grinder in water.
- Use the provided cleaning brush to remove any spice residue from the grinding mechanism.
- Ensure all parts are completely dry before reassembling.

4.2. Refilling

Refer to section 2.3. **Filling the Grinder** for detailed instructions on refilling your grinder.

5. TROUBLESHOOTING

If you encounter issues with your TOMEEM Electric Salt and Pepper Grinder Set, consider the following:

- **Grinder not operating:** Ensure the grinder is fully charged. Check that the top section is securely fastened and aligned with the transparent container.
- **Inconsistent grind:** Verify that the coarseness adjustment dial is set correctly. Ensure the spice container is not overfilled and that the spices are suitable for grinding (e.g., whole peppercorns, coarse salt).
- **LED light not working:** This may indicate a low battery. Recharge the grinder.
- **Grinding mechanism jammed:** Disassemble the grinder and carefully clean any lodged spice particles from the ceramic grinding mechanism using the provided brush.

6. SPECIFICATIONS

Brand	TOMEEM
Model Number	NDSBYMQ01
Material	Acrylonitrile Butadiene Styrene (ABS), Stainless Steel
Color	Silver
Operation Mode	Automatic
Capacity	2.3 ounces (approx. 66g)
Item Weight	0.83 Kilograms (1.82 pounds)
Package Dimensions	8.74 x 5.51 x 2.44 inches
UPC	768461836735
Dishwasher Safe (Container)	Yes

7. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact the retailer where the product was acquired. You may also visit the official TOMEEM brand store on Amazon for further assistance: [TOMEEM Store](#).

© 2023 TOMEEM. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question