

## V-Moda Crossfade 2 Competition Edition

# V-Moda Crossfade 2 Competition Edition Wireless Gaming Headphone User Manual

Model: Crossfade 2 Competition Edition

[Setup](#) [Operating Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

## 1. SETUP

---

### 1.1. Package Contents

Before beginning, ensure all components are present in the package:

- Crossfade 2 Competition Edition Wireless Headphones
- Exoskeleton Carry Case
- BoomPro Microphone (with 3.5mm jack)
- Audio Cable (3.5mm to 3.5mm)
- USB Charging Cable
- 1/4" Pro Adapter
- Shield Customization Voucher



**Image 1:** All components included with the V-Moda Crossfade 2 Competition Edition headphones, including the headphones, carry case, BoomPro microphone, various cables, and adapters.

## 1.2. Charging the Headphones

For wireless operation, the headphones must be charged. Connect the USB charging cable to the headphone's charging port and the other end to a USB power source (e.g., computer, wall adapter). The LED indicator will show charging status.

## 1.3. Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the power button for approximately 3 seconds until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, computer, etc.), enable Bluetooth and search for "V-Moda Crossfade 2 CE".
4. Select the headphones from the list to connect. The LED will turn solid blue once connected.

## 1.4. Wired Connections

The Crossfade 2 Competition Edition headphones can be used in wired mode, which also enables Hi-Res Audio. This is useful for gaming consoles or when battery power is low.

- **Standard Audio Cable:** Connect the 3.5mm audio cable to the headphone's input jack and to your audio source.
- **BoomPro Microphone:** For voice communication, connect the BoomPro microphone directly into the headphone's 3.5mm input jack. The BoomPro features an in-line mute switch and volume control.




**Image 2:** Close-up view of the BoomPro microphone with its in-line controls and other audio cables included with the headphones.



**Image 3:** The V-Moda Crossfade 2 headphones connected via cable to a gaming console, demonstrating wired usage for gaming.

## 1.5. Shield Customization

The headphones come with a voucher for personalized metal shields. Follow the instructions on the voucher to customize your headphones. This typically involves visiting the V-Moda website and using a unique ID code.



**Image 4:** The shield customization voucher, detailing how to personalize the headphone shields using a unique code and the V-Moda website. More information can be found at <http://bit.ly/3B7bYkb?r=qr>.

## 2. OPERATING INSTRUCTIONS

---

### 2.1. Power On/Off

- **Power On:** Press and hold the power button for 1 second. The LED will flash blue.
- **Power Off:** Press and hold the power button for 3 seconds. The LED will turn off.

### 2.2. Bluetooth Controls

When connected via Bluetooth, use the buttons on the right earcup for control:

- **Volume Up/Down:** Press the '+' or '-' buttons.
- **Play/Pause:** Press the center button once.
- **Next Track:** Press the center button twice.
- **Previous Track:** Press the center button three times.
- **Answer/End Call:** Press the center button once during a call.

- **Reject Call:** Press and hold the center button for 2 seconds during an incoming call.
- **Activate Voice Assistant:** Press and hold the center button for 2 seconds (when not on a call).

### 2.3. BoomPro Microphone Usage

When the BoomPro microphone is connected, it provides clear voice communication for gaming and calls.



**Image 5:** A user wearing the V-Moda Crossfade 2 headphones with the BoomPro microphone attached, illustrating its position for optimal voice capture.

- **Mute Switch:** Use the physical switch on the BoomPro cable to mute or unmute your microphone.
- **Volume Slider:** Adjust the microphone's output volume using the slider on the BoomPro cable.
- **Positioning:** For best voice clarity, position the microphone approximately 2-3 inches from your mouth.



**Image 6:** The V-Moda Crossfade 2 headphones positioned on a gaming laptop, demonstrating a typical gaming setup.

## 3. MAINTENANCE

---

### 3.1. Cleaning

- **Ear Cushions:** Gently wipe the ear cushions with a soft, damp cloth. Avoid harsh chemicals or abrasive materials.
- **Headband and Exterior:** Use a dry or slightly damp cloth to clean the headband and exterior surfaces.
- **Connectors:** Ensure all jacks and plugs are free of dust and debris.

### 3.2. Storage

When not in use, store the headphones in the provided Exoskeleton Carry Case to protect them from dust, scratches, and impacts. Avoid storing in extreme temperatures or high humidity.

### 3.3. Battery Care (for Wireless Use)

- Avoid fully discharging the battery frequently.

- Charge the headphones regularly, even if not used for extended periods, to maintain battery health.
- Do not expose the battery to extreme heat.

## 4. TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound in wireless mode	Headphones not powered on, not paired, or low battery.	Ensure headphones are powered on and charged. Re-pair with your device. Check device volume.
No sound in wired mode	Cable not fully inserted, faulty cable, or incorrect audio source selection.	Ensure cable is securely connected at both ends. Try a different cable. Verify audio output settings on your device.
Microphone not working	BoomPro not fully inserted, mute switch engaged, or incorrect input device selected.	Ensure BoomPro is fully inserted into the headphone jack. Check the mute switch on the BoomPro cable. Verify microphone input settings on your device.
Bluetooth connection drops frequently	Interference, distance from device, or low headphone battery.	Move closer to your device. Avoid obstacles. Charge the headphones. Try re-pairing.

## 5. SPECIFICATIONS

Feature	Detail
Model Name	Competition Edition
Connectivity Technology	Wireless (Bluetooth) / Wired (3.5mm Jack)
Wireless Communication Technology	Bluetooth 4.0
Bluetooth Range	10 Meters
Audio Driver Type	50mm Dual-Diaphragm Dynamic Driver
Frequency Range	20 Hz - 20,000 Hz
Earpiece Shape	Over Ear
Noise Control	Passive Noise Cancellation
Microphone	BoomPro Microphone (Detachable)
Special Features	Microphone Included, Sweatproof
Compatible Devices	Gaming Consoles, Desktops, Laptops, Tablets, Telephones
Item Weight	1.25 pounds (approx. 567 grams)
Product Dimensions	7.2 x 6.1 x 4.4 inches (approx. 18.3 x 15.5 x 11.2 cm)

Feature	Detail
Water Resistance Level	Water Resistant
UPC	761294751718

## 6. WARRANTY & SUPPORT

### 6.1. Warranty Information

V-Moda products typically come with a limited warranty covering defects in materials and workmanship. For specific warranty terms and duration, please refer to the warranty card included with your product or visit the official V-Moda website. Keep your proof of purchase for warranty claims.

### 6.2. Customer Support

For further assistance, technical support, or warranty inquiries, please contact V-Moda customer service. You can usually find contact information, FAQs, and support resources on the official V-Moda website:

[Visit V-Moda Support](#)

© 2024 V-Moda. All rights reserved.

## Related Documents - Crossfade 2 Competition Edition

	<p><a href="#">V-MODA Crossfade Series: Troubleshooting and Sound Differences</a></p> <p>Find answers to common questions about V-MODA Crossfade headphones, including sound differences between models, headband adjustments, audio issues, and cable functionality. Learn about replaceable cushions.</p>
	<p><a href="#">V-MODA S-80 On-Ear Bluetooth Headphones User Manual</a></p> <p>Comprehensive user manual for the V-MODA S-80 on-ear Bluetooth headphones, covering setup, features, troubleshooting, and support. Learn about pairing, sound customization, and more.</p>
	<p><a href="#">V-MODA M-200 ANC User Manual: Active Noise Cancelling Headphones</a></p> <p>Comprehensive user manual for the V-MODA M-200 ANC Active Noise Cancelling Headphones, covering features, package contents, setup, operation, and troubleshooting. Learn how to use your V-MODA M-200 ANC headphones for an optimal audio experience.</p>
	<p><a href="#">V-MODA M-200 ANC Headphones User Manual: Setup, Features, and Troubleshooting</a></p> <p>The official user manual for V-MODA M-200 ANC Active Noise Cancelling Headphones. Learn how to set up, use, and troubleshoot your headphones, including pairing, ANC controls, and battery charging.</p>



[V-MODA HEXM-PR True Wireless Earbuds Quick Start Guide](#)

Quick start guide for V-MODA HEXM-PR True Wireless Earbuds, covering setup, pairing, and essential information. Learn how to get started with your new earbuds.



[V-MODA Product Safety and Important Notes](#)

Comprehensive safety guidelines, warnings, and important usage notes for V-MODA audio products, covering safe listening practices, maintenance, and environmental considerations.