

[Manuals.plus](#) /

> [Hoover](#) /

> Hoover ONEPWR WindTunnel Emerge Pet+ Cordless Stick Vacuum Cleaner User Manual

Hoover BH53603VE

Hoover ONEPWR WindTunnel Emerge Pet+ Cordless Stick Vacuum Cleaner User Manual

Model: BH53603VE

INTRODUCTION

This manual provides instructions for the safe and efficient operation, maintenance, and care of your Hoover ONEPWR WindTunnel Emerge Pet+ Cordless Stick Vacuum Cleaner. Please read all instructions carefully before use and retain this manual for future reference.





Image: The Hoover ONEPWR WindTunnel Emerge Pet+ Cordless Stick Vacuum Cleaner in its upright position, showcasing its sleek design and integrated battery.

PACKAGE CONTENTS

Verify that all components are present in your package:

- Hoover ONEPWR WindTunnel Emerge Pet+ Cordless Stick Vacuum Cleaner (Main Unit)
- All-Terrain Dual Brush Roll Nozzle
- Extension Wand
- Motorized Pet Tool
- Extension Hose

- 2-in-1 Crevice Tool/Dusting Brush
- ONEPWR Batteries (2 included)
- ONEPWR Charger
- Wall Mount (optional installation)



Image: The Hoover ONEPWR Emerge Pet+ vacuum shown with its various attachments, including the motorized pet tool, extension hose, 2-in-1 tool, and charging station.

SETUP AND ASSEMBLY

1. Battery Charging

Before first use, fully charge both ONEPWR batteries. Insert a battery into the charger. The indicator light on the charger will show charging status. A full charge takes approximately 2.5 hours per battery.



Image: A Hoover ONEPWR battery being inserted into its charging station, indicating the charging process.

2. Vacuum Assembly

- Insert the extension wand into the main vacuum body until it clicks securely.
- Attach the All-Terrain Dual Brush Roll Nozzle to the bottom of the extension wand until it clicks.
- Insert a fully charged ONEPWR battery into the battery slot on the main vacuum body until it locks into place.



Image: A hand inserting a Hoover ONEPWR battery into the designated slot on the vacuum's main body.

OPERATING INSTRUCTIONS

Powering On/Off

Press the power button located on the handle to turn the vacuum on or off. The vacuum features two power levels, adjustable via the control method on the handle.

Cleaning Different Surfaces

The All-Terrain Dual Brush Roll is designed to effectively clean various floor types, from hard floors to carpets, without needing to switch nozzles.

TWO BRUSH ROLLS TO CLEAN ALL FLOOR TYPES



Image: The vacuum head transitioning from a carpeted surface to a hard floor, demonstrating its versatility in picking up debris on both.



Image: The vacuum cleaning a mix of carpet and hardwood floor, with a dog resting nearby, highlighting its quiet operation and effectiveness on different surfaces.

Low Profile Cleaning

The vacuum's design allows it to lay nearly flat, enabling easy cleaning under furniture and other low-clearance areas.




Image: The Hoover ONEPWR Emerge Pet+ vacuum head extended flat to clean underneath a piece of furniture, demonstrating its low-profile cleaning capability.

Above-Floor Cleaning and Handheld Mode

To clean above floors or in tight spaces, detach the main vacuum body from the extension wand and nozzle. Attach the desired accessory directly to the main unit or use the extension hose for increased reach.

- **Motorized Pet Tool:** Ideal for upholstery, pet beds, and stairs.
- **2-in-1 Crevice Tool/Dusting Brush:** Use the crevice tool for narrow gaps and edges, or slide the brush down for dusting surfaces.
- **Extension Hose:** Provides flexibility for cleaning car interiors, high shelves, or other hard-to-reach areas.

THE POWER OF TWO

DUAL BRUSH ROLLS SEAMLESSLY WORK TOGETHER TO PICK UP LARGE DEBRIS AND FINE PARTICLES ACROSS EVERY FLOOR TYPE.



Image: A person using the Hoover ONEPWR Emerge Pet+ in handheld mode with an attachment to clean the interior of a car, demonstrating its portability and versatility.



Image: The Hoover ONEPWR Emerge Pet+ in handheld configuration, connected to an extension hose and crevice tool, used for cleaning hard-to-reach areas.

Self-Standing Feature

The vacuum is designed to stand upright on its own, allowing you to pause cleaning without needing to lean it against a wall or lay it down.



Image: The Hoover ONEPWR Emerge Pet+ vacuum standing upright independently in a living room setting, demonstrating its self-standing capability.

MAINTENANCE

Emptying the Dirt Cup

Empty the dirt cup after each use or when debris reaches the MAX fill line. To empty, detach the dirt cup from the main unit, open the bottom flap, and dispose of contents into a waste bin.



Image: A hand holding the detached dirt cup of the Hoover ONEPWR Emerge Pet+ vacuum over a trash can, showing debris being emptied.

Cleaning the Filter

The vacuum uses dual cyclonic filtration. Regularly check and clean the foam filter to maintain optimal suction performance. Rinse the foam filter with water and allow it to air dry completely before reinserting.



Image: An internal view of the Hoover ONEPWR Emerge Pet+ dirt cup, highlighting the dual cyclonic filtration system in action, separating dirt and dust particles.

Cleaning Brush Rolls

Periodically inspect the brush rolls for tangled hair or debris. To clean, remove the brush roll cover (refer to the diagram in the full manual for specific steps) and carefully cut away any wrapped hair or fibers. Ensure brush rolls spin freely before reassembly.



Image: A close-up view of the Hoover ONEPWR Emerge Pet+ vacuum head, showing the two brush rolls working in tandem to pick up debris from a hard floor.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery not charged or not inserted correctly.	Ensure battery is fully charged and securely inserted.
Loss of suction.	Dirt cup full, filter clogged, or brush roll obstructed.	Empty dirt cup, clean filter, remove obstructions from brush roll.
Brush rolls not spinning.	Obstruction in brush roll area.	Turn off vacuum, remove nozzle, and clear any debris from brush rolls.

Problem	Possible Cause	Solution
Vacuum falls over when self-standing.	Uneven surface or improper placement.	Ensure vacuum is placed on a flat, stable surface.

SPECIFICATIONS

Feature	Detail
Brand	Hoover
Model Name	Hoover ONEPWR WindTunnel Emerge Pet+ Cordless Lightweight Stick Vacuum with All-Terrain Dual Brush Roll
Model Number	BH53603VE
Special Feature	Portable, Self-Standing
Filter Type	Foam, Dual Cyclonic Filtration
Included Components	Brush, Motorized Pet Tool, Extension Hose, 2-in-1 Tool, 2 Batteries, Charger, Wall Mount
Cordless	Yes
Capacity	0.4 Liters
Wattage	265 watts
Charging Time	2.5 Hours
Recommended Uses	Carpet, Desk, Furniture, Hard Floor, Tile Floor, Hardwood, Rug, Bare Floor, Sofa
Form Factor	Handheld, Stick
Color	Silver and Red
Battery Type	Hoover ONEPWR
Noise Level	80 Decibels
Battery Life	Up to 45 minutes (per battery, actual runtime varies with power level and attachments)
Product Dimensions	9.5"L x 10.8"W x 44.25"H
Item Weight	7.92 pounds
Number of Power Levels	2

WARRANTY AND SUPPORT

This Hoover ONEPWR WindTunnel Emerge Pet+ Cordless Stick Vacuum Cleaner comes with a **3-year manufacturer's warranty**.

For warranty claims, technical support, or to purchase replacement parts, please visit the official Hoover website or contact Hoover customer service. Retain your proof of purchase for warranty validation.

Official Hoover Website: www.hoover.com

© 2024 Hoover. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.