

[Manuals.plus](#) /

› [Loosafe](#) /

› Loosafe Cellular Security Camera LS-T402-4G User Manual

Loosafe LS-T402-4G

Loosafe Cellular Security Camera LS-T402-4G User Manual

Model: LS-T402-4G | Brand: Loosafe

INTRODUCTION

This manual provides instructions for the installation, operation, and maintenance of your Loosafe Cellular Security Camera, model LS-T402-4G. This outdoor camera features 4G LTE connectivity, solar power, 1080P resolution, PTZ functionality, color night vision, and motion detection for comprehensive surveillance in areas without Wi-Fi or consistent power access.

Built for No WiFi, No Power Access Areas



Image: The Loosafe Cellular Security Camera shown in diverse outdoor environments, highlighting its suitability for locations without traditional Wi-Fi or power infrastructure.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 4G Camera with 15000 mAh Battery
- 10W Solar Panel
- 10ft Extension Wire
- 64GB TF Card (Micro-SD Card)
- Mounting Bracket
- User Manual
- SIM Card

- Screw Kit
- Charging Cable



Image: An overview of the Loosafe cellular security camera system, including the main camera unit, two solar panels, a SIM card, and a 64GB Micro-SD card.

PRODUCT OVERVIEW


Familiarize yourself with the components of your security camera.

Storage

Encrypted Cloud Storage & Local Storage
64GB Micro-SD Card Included



64GB
Micro-SDCart
with 60 days Video Storage



**Highest Standard
of Encrypted Cloud Storage**

Image: This diagram labels key parts of the 4G camera, including the PIR sensor, lens, built-in microphone, light sensor, status LEDs, IR/spotlight LEDs, SIM card slot, and Micro-SD card slot. It also displays all included accessories: 4G Camera, Solar Panel, Extension Wire, Bracket, Charging Cable, Screw Kit, SIM Card, and 64GB Micro-SD Card.

SETUP GUIDE

1. SIM Card and Micro-SD Card Installation

Before mounting, install the SIM card and Micro-SD card into the camera.

1. Locate the SIM card slot and Micro-SD card slot on the camera. These are typically protected by a rubber cover to ensure waterproofing.
2. Carefully open the cover.
3. Insert the provided 4G SIM card into the SIM card slot with the gold contacts facing down and the notched corner

oriented correctly.

4. Insert the 64GB Micro-SD card into its designated slot until it clicks into place.
5. Ensure the rubber cover is securely closed to maintain the IP65 waterproof rating.

Cellular

4G LTE Outdoor Camera



SIM Card



10W Solar Panel



15000 mAh Battery



Image: A visual representation of the Loosafe cellular camera system, highlighting the SIM card, 10W solar panel, and 15000 mAh battery, indicating their roles in the camera's operation.

2. App Installation and Account Creation

Download the dedicated mobile application to manage your camera.

1. Scan the QR code provided in the manual or search for the

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question