

[Manuals.plus](#) /

› [Furmax](#) /

› Furmax Electric Standing Desk User Manual

Furmax HAD00604F

Furmax Electric Standing Desk User Manual

Model: HAD00604F

Brand: Furmax

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Furmax Electric Standing Desk. Designed to promote a healthier working style, this desk allows seamless transitions between sitting and standing positions, helping to alleviate discomfort associated with prolonged sitting.



Image: The Furmax Electric Standing Desk in a home office setting, showcasing its spacious desktop and electric height adjustment.

Key Features

- **Healthy Working Style:** Transition between sitting and standing to reduce fatigue and improve concentration.
- **Durable Quiet Motor:** Adjust height smoothly and quietly at 1 inch per second, with a height range of 27.95" to 46.85".
- **Memory Electric Lift:** Easily control height with buttons and save up to four preferred height settings for quick adjustments.
- **Sturdy Desk Legs:** Box frame structured steel legs with a wide T-shaped foot design ensure stability at all heights.
- **Removable Casters:** Equipped with detachable and lockable casters for easy mobility.
- **Integrated Cable Management:** Features cable grommets and an under-desk cable storage tray to keep your workspace tidy.
- **Convenient Accessories:** Includes a headphone hook and cup holder for enhanced usability.

STANDING DESK WITH CASTERS

Convenient and easy to move to wherever



Image: Detailed view of the desk's features, including removable casters for mobility, cable grommets for organization, and a convenient desk hook.

SETUP INSTRUCTIONS

For detailed assembly instructions, please refer to the official Installation Manual (PDF) provided with your product. It is recommended to follow the steps carefully to ensure proper and safe setup.

Key Assembly Points:

- Ensure all components are present before beginning assembly.
- The tabletop consists of two pieces; align them correctly during assembly.
- Attach the motor and control panel securely.
- Install the casters if desired for mobility, ensuring they are locked when the desk is stationary.
- Utilize the cable management tray and grommets to organize wires.

Product Dimension



Image: Product dimensions, illustrating the desk's size and minimum height for setup planning.

OPERATING INSTRUCTIONS

Height Adjustment

The Furmax Electric Standing Desk features an intuitive control panel for easy height adjustments.

1. **To Raise:** Press and hold the **Up Arrow (^)** button until the desk reaches your desired height.
2. **To Lower:** Press and hold the **Down Arrow (v)** button until the desk reaches your desired height.

The motor operates quietly and smoothly, allowing for seamless transitions.

Memory Settings

The desk allows you to save up to four preferred height settings for quick recall.

1. Adjust the desk to your desired height using the Up/Down arrows.

2. Press and hold one of the numbered memory buttons (1, 2, 3, or 4) until the display flashes or beeps, indicating the height has been saved.
3. To recall a saved height, simply press the corresponding numbered button. The desk will automatically move to the preset height.

NEARLY SILENT LIFTING

Up to 220 LBS & < 55 DB 



LED Display



Up/Down



4 Height Memory Settings

Image: The desk's control panel, featuring an LED display for current height, up/down adjustment buttons, and four programmable memory settings.

ENJOY ANY HEIGHT **YOU WANT**



Image: Visual representation of the desk's adjustable height range, from its lowest (27.95") to highest (46.85") positions.

MAINTENANCE

To ensure the longevity and optimal performance of your Furmax Electric Standing Desk, follow these maintenance guidelines:

- **Cleaning:** Wipe the desktop and frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Motor Care:** The motor is designed for durability. Avoid overloading the desk beyond its maximum weight capacity (100 pounds).
- **Cable Management:** Periodically check the cable management system to ensure wires are neatly tucked away and not interfering with the desk's movement.
- **Caster Maintenance:** If using casters, ensure they are clean and free of debris to maintain smooth movement. Lock them when the desk is stationary.
- **Regular Checks:** Periodically inspect all screws and connections to ensure they are tight and secure.

TROUBLESHOOTING

If you encounter any issues with your Furmax Electric Standing Desk, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Desk not moving or unresponsive.	Power cable disconnected; motor overload; control panel error.	Check power connections. Reduce weight on the desk. Unplug the control panel for 30 seconds and replug.
Desk moves unevenly or makes unusual noises.	Loose connections; obstruction; uneven weight distribution.	Ensure all screws are tightened. Check for any obstructions under the desk. Distribute weight evenly on the desktop.
Buttons not responding as expected (e.g., Up button lowers desk).	Control panel calibration issue.	Unplug the control panel for 30 seconds and replug. If the issue persists, contact customer support.

If the problem persists after attempting these solutions, please contact Furmax customer support for further assistance.

SPECIFICATIONS

Attribute	Detail
Brand	Furmax
Model Number	HAD00604F
Product Dimensions	24"D x 59"W x 45"H
Color	Brown
Style	Modern
Base Material	Metal
Finish Type	Wood
Special Feature	Adjustable Height, Electric
Room Type	Office
Mounting Type	Tabletop
Included Components	Cup Holder, Headphone Hook
Maximum Weight Recommendation	100 Pounds
Minimum Height	28.7 Inches
Maximum Height	46.85 Inches
Item Weight	50 Pounds

SAFETY INFORMATION

Please read and understand all safety warnings before operating your desk.

- This desk has a maximum weight recommendation of **100 pounds**. Do not exceed this limit.
- Properly anchor the desk for stability, especially when used at the highest height.
- Keep hands and objects clear of moving parts during height adjustment.
- Ensure power cables are not pinched or damaged.
- This product is intended for indoor use only.

WARRANTY AND SUPPORT

Warranty Information

Your Furmax Electric Standing Desk comes with a **Limited Warranty**. For specific terms and conditions, please refer to the warranty documentation included with your purchase or contact Furmax customer support.

Optional protection plans are available for extended coverage:

- 2-Year Protection Plan
- 3-Year Protection Plan
- Complete Protect (monthly billing)

Return Policy

This product is eligible for **30-day easy returns**. Please refer to the retailer's return policy for full details.

Customer Support

For any questions, technical assistance, or warranty claims, please contact Furmax customer support. You can find contact information on the official Furmax website or through your purchase platform.

An Installation Manual (PDF) is available for download [here](#).

© 2024 Furmax. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BN3XBQLY>

More documents and user manuals: <https://manuals.plus/>