

[manuals.plus](#) /

› [Jectse](#) /

› [Jectse BH M97 Single Ear Headset User Manual](#)

Jectse BH M97

Jectse BH M97 Single Ear Headset User Manual

Model: BH M97

1. INTRODUCTION

This manual provides detailed instructions for the proper use, setup, and maintenance of your Jectse BH M97 Single Ear Headset. Please read this manual thoroughly before using the product to ensure optimal performance and longevity. Keep this manual for future reference.

2. PACKAGE CONTENTS

Verify that all items listed below are present in your product package:

- Jectse BH M97 Single Ear Headset
- Charging Base
- Charging Cable
- Instruction Manual (this document)



Image: The Jectse BH M97 headset, its dedicated charging base, and the USB charging cable.

3. PRODUCT OVERVIEW

The Jectse BH M97 is a single-ear Bluetooth headset designed for clear communication in various environments. It features a rotatable microphone and a comfortable on-ear design.

3.1 Headset Components

- **Ear Cushion:** Padded for comfort during extended use.
- **Flexible Headband:** Adjustable for a secure fit.
- **Rotatable Microphone:** Can be adjusted to accurately capture your voice and positioned on either side.
- **Control Buttons:** (Specific button functions are typically detailed in the 'Operating Instructions' section.)
- **Charging Contacts:** Located on the earcup for use with the charging base.



Image: The Jectse BH M97 headset securely placed on its charging base.



Image: A detailed view of the headset's padded ear cushion and the charging contacts.

4. SETUP

4.1 Charging the Headset

1. Connect the charging cable to the charging base and a USB power source (e.g., computer USB port, wall adapter).
2. Place the headset onto the charging base, ensuring the charging contacts align.
3. The headset's indicator light will typically show charging status (e.g., red for charging, blue/off for fully charged).
4. A full charge takes approximately 2 hours. The headset provides up to 17 hours of talk time and 200 hours of standby time on a full charge.

4.2 Powering On/Off

- **To Power On:** Press and hold the Multi-function Button (MFB) for approximately 3-5 seconds until the indicator light flashes blue.
- **To Power Off:** Press and hold the MFB for approximately 3-5 seconds until the indicator light flashes red and then turns off.

4.3 Bluetooth Pairing

The headset uses Bluetooth 5.0 for stable and efficient connection.

1. Ensure the headset is powered off.
2. Press and hold the MFB for approximately 5-7 seconds until the indicator light flashes red and blue alternately. This indicates pairing mode.
3. On your device (smartphone, PC, tablet), enable Bluetooth and search for available devices.
4. Select "BH M97" from the list of found devices.
5. Once paired, the headset's indicator light will typically flash blue slowly or turn off.
6. If prompted for a password, enter "0000".



Bluetooth Telephone Headset

Rotatable microphone

Designed to accurately capture your voice

You can easily adjust the microphone to the perfect angle

All day comfort

With padded ear cushions and flexible headband

Ultra lightweight, almost weightless for long hours

Fitted earphones can be worn on the right or left ear depending on your preference

Faster, more efficient and more stable transmission



Image: The headset illustrating its rotatable microphone, comfortable design, and Bluetooth 5.0 capabilities for stable transmission.

5. OPERATING INSTRUCTIONS

5.1 Wearing the Headset

- Adjust the flexible headband to fit comfortably over your head.
- Position the ear cushion over one ear.
- Rotate the microphone boom to bring the microphone close to your mouth for optimal voice capture. The microphone can be worn on either the left or right side.



Image: A user wearing the Jectse BH M97 headset, demonstrating its practical application in a professional environment.

5.2 Call Management

- **Answer Call:** Short press the MFB when a call comes in.
- **End Call:** Short press the MFB during a call.
- **Reject Call:** Press and hold the MFB for approximately 2 seconds when a call comes in.
- **Redial Last Number:** Double-press the MFB when not on a call.

5.3 Volume Control

Use the volume buttons (typically '+' and '-') on the headset to adjust the listening volume. Alternatively, adjust the volume directly on your connected device.

6. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your headset.

- **Cleaning:** Use a soft, dry cloth to wipe the headset and charging base. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headset in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Battery Care:** Avoid fully discharging the battery frequently. Charge the headset regularly, even if not

in constant use, to maintain battery health.

- **Avoid Moisture:** Do not expose the headset to water or excessive moisture.

7. TROUBLESHOOTING

If you encounter issues with your Jectse BH M97 headset, refer to the following common solutions:

- **Headset will not power on:** Ensure the headset is fully charged. Connect it to the charging base and allow it to charge for at least 30 minutes before attempting to power on again.
- **Cannot pair with device:**
 - Ensure the headset is in pairing mode (flashing red and blue alternately).
 - Make sure Bluetooth is enabled on your device.
 - Move the headset closer to your device (within 10 meters).
 - Turn off and on your device's Bluetooth, then try pairing again.
 - If previously paired, try deleting the headset from your device's Bluetooth list and re-pairing.
- **No sound or low volume:**
 - Check the volume levels on both the headset and your connected device.
 - Ensure the headset is properly connected to your device.
 - Verify that the correct audio output device is selected on your computer or phone.
- **Microphone not working:**
 - Ensure the microphone boom is positioned correctly near your mouth.
 - Check microphone settings on your connected device to ensure the headset is selected as the input device.
 - Ensure the microphone is not muted (if a mute function is available on the headset or device).

If the issue persists after trying these steps, please refer to the warranty and support information.

8. SPECIFICATIONS

Feature	Specification
Model	BH M97
Connectivity	Bluetooth 5.0 (Wireless)
Wireless Range	Up to 10 meters (32.8 feet)
Battery Capacity	Built-in 180mAh Lithium Battery
Talk Time	Up to 17 hours
Standby Time	Up to 200 hours
Charging Time	Approximately 2 hours
Material	ABS, Plastic
Ear Placement	On Ear (Single Ear)

Feature	Specification
Microphone	Rotatable, Noise Canceling
Compatible Devices	Cellphones, Tablets, Laptops, PCs
Dimensions (Parcel)	18 x 17 x 6 cm
Weight (Parcel)	329 g

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Jectse website. Keep your proof of purchase for warranty claims.