## Manuals+

Q & A | Deep Search | Upload

## manuals.plus /

- Kappesberg /
- Kappesberg S824 Chest of Drawers User Manual

## Kappesberg S824

# Kappesberg S824 Chest of Drawers User Manual

Model: S824 | Brand: Kappesberg

# 1. PRODUCT OVERVIEW

The Kappesberg S824 is a versatile chest of drawers designed to provide ample storage space for your home. It features three standard drawers and one larger bottom drawer, all equipped with metallic slides for smooth operation. Constructed from MDP (Medium Density Particle board), this furniture piece offers durability and a glossy Nogueira (Walnut) finish, making it a functional and aesthetic addition to any room.



Figure 1: Front view of the Kappesberg S824 Chest of Drawers in Nogueira finish.



Figure 2: Kappesberg S824 Chest of Drawers with key dimensions: 94cm Height, 91cm Width, 47cm Depth.

# 2. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Adult Assembly Required: This product requires adult assembly. Keep small parts and packaging
  materials away from children during assembly.
- Secure to Wall: To prevent tipping, it is highly recommended to secure the chest of drawers to a wall using appropriate anti-tip hardware (not included, or use provided if applicable).
- Weight Limits: Do not exceed the maximum weight capacity for each drawer (6 kg). Distribute weight evenly.
- Stable Surface: Place the furniture on a flat, level, and stable surface.
- Avoid Climbing: Do not allow children to climb on or play with the drawers.
- Proper Use: Use the product only for its intended purpose as a storage unit.

# 3. SETUP AND ASSEMBLY

Assembly is required for this product. Please ensure you have all parts and tools before beginning. It is recommended to assemble the unit in the room where it will be used.

# 3.1. Unpacking and Inspection

- 1. Carefully unpack all components from the packaging.
- 2. Check the parts list against the contents to ensure all pieces are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.
- 3. Keep all hardware (screws, dowels, etc.) organized and within reach.

## 3.2. Required Tools (Not Included)

- · Phillips head screwdriver
- Hammer (for dowels)
- Measuring tape (optional, for placement)

## 3.3. Assembly Steps

Follow the detailed assembly instructions provided in the separate assembly manual that came with your product. General steps typically include:

- 1. Assemble the main frame of the chest of drawers.
- 2. Install the drawer slides onto the main frame.
- 3. Assemble each drawer, ensuring the bottom panel is securely in place and the internal handles are correctly attached.
- 4. Insert the assembled drawers into the frame.
- 5. Secure the unit to the wall using appropriate anti-tip hardware to prevent accidental tipping.

# 4. OPERATING INSTRUCTIONS

The Kappesberg S824 Chest of Drawers is designed for straightforward use.

- Opening Drawers: Gently pull the drawer from its internal handle to open. The metallic slides ensure smooth movement.
- Closing Drawers: Push the drawer firmly until it is fully closed and flush with the chest frame.
- Loading Drawers: Distribute items evenly within each drawer. Avoid overloading to prevent damage to the drawer bottom or slides. The maximum weight capacity per drawer is 6 kg.
- Large Drawer: The bottom drawer is larger, suitable for bulkier items.

# 5. MAINTENANCE AND CARE

Proper care will extend the life and maintain the appearance of your Kappesberg S824 Chest of Drawers.

- Cleaning: Wipe surfaces with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or solvents, as these can damage the glossy finish.
- Spills: Immediately wipe up any spills to prevent moisture damage to the MDP.
- Sunlight: Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- Heat and Moisture: Keep the furniture away from direct heat sources and areas of high humidity.
- **Drawer Slides:** Periodically check the metallic slides for smooth operation. If they become stiff, a small amount of silicone spray can be applied (avoiding contact with wood surfaces).
- Hardware: Periodically check and tighten all screws and fasteners to ensure stability. Do not overtighten.

# 6. TROUBLESHOOTING

Here are some common issues and their solutions:

## · Drawers are stiff or not sliding smoothly:

Solution: Check if the drawer slides are properly aligned and free of obstructions. Ensure all screws on the slides are tightened. A small amount of silicone lubricant can be applied to the slides.

#### · Chest of drawers wobbles:

Solution: Ensure the unit is on a level surface. Check and tighten all assembly screws. If necessary, use shims under the feet to stabilize the unit. Ensure it is properly secured to the wall.

## · Drawer does not close completely:

*Solution:* Check for any items obstructing the drawer's path. Verify that the drawer slides are correctly installed and not bent. Ensure the drawer is not overloaded.

## · Missing parts during assembly:

*Solution:* Double-check all packaging materials. If parts are genuinely missing, contact Kappesberg customer support with your product model and a list of missing components.

# 7. Specifications

Feature	Detail	
Model Number	S824-FR	
Dimensions (H x W x D)	94 cm x 91 cm x 47 cm	
Weight	45.19 kg	
Material (Body)	MDP (Medium Density Particle board)	
Material (Fronts)	MDF	

Feature	Detail
Finish Type	Brilhante (Glossy)
Color	Nogueira (Walnut)
Number of Drawers	4 (3 standard, 1 large)
Drawer Slides	Metallic
Weight Capacity per Drawer	6 kg
Handles	Internal
Assembly Required	Yes

# 8. WARRANTY AND SUPPORT

## 8.1. Manufacturer's Warranty

This Kappesberg S824 Chest of Drawers comes with a**3-month manufacturer's warranty** against manufacturing defects. This warranty covers defects in materials and workmanship under normal use and service.

The warranty does not cover:

- Damage caused by improper assembly or installation.
- Damage resulting from misuse, abuse, neglect, or accident.
- · Normal wear and tear.
- Damage from unauthorized repairs or modifications.

# 8.2. Customer Support


For warranty claims, missing parts, or technical assistance, please contact Kappesberg customer support. Have your product model number (S824) and proof of purchase ready when contacting support. For the most up-to-date contact information, please refer to the Kappesberg official website or the documentation included with your purchase.

© 2024 Kappesberg. All rights reserved.



### Kappesberg BCI013 Assembly Instructions and Parts Guide

Comprehensive assembly instructions, parts list, and accessory guide for the Kappesberg BCI013 furniture model. Includes step-by-step diagrams, maintenance tips, and warranty information.



## Kappesberg M626 Assembly Instructions

Comprehensive assembly guide for the Kappesberg M626 furniture unit, detailing parts, hardware, and step-by-step instructions for assembly and wall mounting.



## Manual de Montagem Kappesberg ARM012

Guia completo de montagem e instruções para o móvel ARM012 da marca Kappesberg, incluindo lista de peças e acessórios.



## Kappesberg BCI010 & PB042 Furniture Assembly Instructions

Comprehensive assembly guide for Kappesberg BCI010 and PB042 furniture items. Includes detailed parts lists, hardware specifications, step-by-step visual instructions translated to English, and care instructions.



### Kappesberg BCI015 Cabinet Assembly Instructions

Comprehensive assembly guide for the Kappesberg BCI015 cabinet, including parts lists, accessory details, safety information, and step-by-step instructions for furniture assembly.



## Kappesberg BA54 Table and 2CAD160 Chairs Assembly Instructions

Comprehensive assembly instructions and user manual for Kappesberg BA54 table/stand and 2CAD160 chairs. Features detailed parts identification, step-by-step visual guides, and essential care and warranty information.