

[Manuals.plus](#) /

› [Sharper Image](#) /

› Sharper Image Infrared Heating Pad User Manual

Sharper Image Infrared Heating Pad

Sharper Image Infrared Heating Pad User Manual

Model: Infrared Heating Pad (B0BN4PMTGD)

PRODUCT OVERVIEW

The Sharper Image Infrared Heating Pad is designed to provide temporary pain relief by utilizing Far Infrared Ray (FIR) heat. This technology allows heat to penetrate deep into muscles and bones without the pad becoming hot to the touch, offering a relaxing experience. It is ideal for addressing arthritis, joint pain, and sports injuries.



Image: The Sharper Image Infrared Heating Pad in use, covering a person's back.

SETUP INSTRUCTIONS

Follow these steps to set up your Infrared Heating Pad:

1. Unpack the heating pad and ensure all components are present.

2. Locate the power port on the heating pad. The power cord is detachable for convenience.



Image: Close-up view of the power cord connection point on the heating pad.

3. Connect the power cord to the heating pad's port.
4. Plug the power adapter into a standard AC electrical outlet.

OPERATING INSTRUCTIONS

To operate your Sharper Image Infrared Heating Pad:

1. Once plugged in, locate the power button on the pad.



Image: Close-up of the power button with Sharper Image branding.

2. Press and hold the power button until it illuminates red to turn the unit on.
3. Cycle through the three available heat levels by pressing the power button:
 - **Low:** Indicated by a Blue light.
 - **Medium:** Indicated by a White light.
 - **High:** Indicated by a Red light.
4. Position the heating pad on the desired area of your body for pain relief. The FIR heat will penetrate deeply without making the pad feel excessively hot to the touch.





Images: Examples of the heating pad being used on the back and stomach for targeted relief.

5. The heating pad features an automatic shut-off function and will turn off after 60 minutes of continuous use for safety.
6. To turn off the pad manually, press and hold the power button until the light extinguishes.

MAINTENANCE

Proper care ensures the longevity of your heating pad:

- Keep the heating pad away from water.
- Spot clean only. Do not immerse in water or machine wash.



Image: The heating pad neatly folded for storage.

TROUBLESHOOTING

If you experience issues with your Sharper Image Infrared Heating Pad, consider the following general advice:

- **No Power:** Ensure the power cord is securely connected to both the heating pad and a functioning electrical outlet. Try a different outlet to rule out power supply issues.
- **No Heat:** Verify that the power button is pressed and held until the indicator light illuminates (Red, White, or Blue). If the light is on but no heat is felt, ensure the pad has been on for a few minutes as FIR heat may not feel hot to the touch but penetrates deeply.
- **Automatic Shut-off:** The pad is designed to automatically shut off after 60 minutes. This is a safety feature, not a malfunction. Simply restart the pad if you wish to continue use.
- For persistent issues not covered here, please refer to the Warranty & Support section for contact information.

SPECIFICATIONS

Feature	Detail
Model Name	Infrared Heating Pad
Color	Black

Brand	Sharper Image
Material	Fabric
Special Feature	Timer
ASIN	B0BN4PMTGD
Manufacturer	Sharper Image
Date First Available	May 24, 2021
Wattage	36 watts
Bulb Voltage	12 volts

WARRANTY & SUPPORT

For specific warranty information and customer support, please contact Sharper Image directly. Details regarding product warranty are typically provided with your purchase documentation or can be found on the official Sharper Image website.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

© 2024 Sharper Image. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question