

FLEXISPOT FLEXISPOT Comhar Pro Desk Q8

FLEXISPOT Q8 55" Bamboo Standing Desk Instruction Manual

Model: FLEXISPOT Comhar Pro Desk Q8

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your FLEXISPOT Q8 55" Bamboo Standing Desk. Please read this manual thoroughly before installation and use to ensure proper function and safety. Retain this manual for future reference.



Figure 1.1: FLEXISPOT Q8 55" Bamboo Standing Desk in an office setting.

2. SAFETY INFORMATION

Observe the following safety guidelines to prevent injury or damage to the desk:

- The desk has a maximum load capacity of 220 lbs (100 kg). Do not exceed this weight limit.
- The height adjustment range is 24.0 inches to 49.2 inches (with tabletop). Ensure no obstructions are present during height adjustments.
- The desktop is made of bamboo and includes a wireless charger. Avoid exposing the desk to excessive heat or direct sunlight.
- Ensure all components are properly assembled and tightened before use.
- Keep children and pets away from the desk during operation.
- Do not sit or stand on the desk.
- Disconnect power before cleaning or performing maintenance.

3. PACKAGE CONTENTS

Your FLEXISPOT Q8 desk is shipped in two separate packages. Verify all components are present before beginning assembly.

- Pre-assembled Bamboo Tabletop with integrated drawer and control panel
- Desk Legs (2)
- Desk Feet (2)
- Cable Management Tray
- Power Adapter and Cable
- Assembly Hardware (screws, tools)
- Instruction Manual



Figure 3.1: Desk dimensions and shipping information.

4. SETUP AND ASSEMBLY

The FLEXISPOT Q8 desk features a quick-install design, allowing for assembly in approximately 15 minutes. The tabletop and drawer come pre-assembled.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place the pre-assembled tabletop upside down on a soft, clean surface to prevent scratches.
2. **Attach Legs:** Securely attach the desk legs to the designated mounting points on the underside of the tabletop using the provided hardware.
3. **Attach Feet:** Fasten the desk feet to the bottom of each leg.
4. **Install Cable Management:** Attach the cable management tray to the underside of the desk as instructed.
5. **Connect Power:** Connect the power adapter to the desk and plug it into a power outlet.
6. **Flip Desk:** With assistance, carefully flip the desk upright.



Figure 4.1: Components for quick installation, including the pre-assembled tabletop, legs, feet, and cable management.

5. OPERATING INSTRUCTIONS

5.1 Height Adjustment

The desk features a dual-motor system for smooth and quiet height adjustments.

- **Up/Down Movement:** Use the up and down arrow buttons on the control panel to adjust the desk height.
- **Memory Presets:** The control panel allows you to save up to four preferred height settings. To set a memory position: adjust the desk to the desired height, then press the 'M' button followed by a number button (1, 2, 3, or 4). The desk will beep to confirm the setting. To recall a saved height, simply press the corresponding number button.

5.2 Integrated Charging Features

The desk includes multiple charging options for your devices.

- **Wired Charging:** The control panel features a Type-A (18W) port and a Type-C (45W) port for charging smartphones, tablets, and laptops.
- **Wireless Charging:** A 10W wireless charging pad is integrated into the tabletop. Place your compatible device directly on the designated wireless charging area on the desk surface.



Figure 5.1: Smart Control Panel with height adjustment and charging ports.




Figure 5.2: Built-in wireless charging area on the desk surface.

5.3 Integrated Drawer

The desk includes a spacious embedded drawer for storing desktop essentials.



Figure 5.3: Spacious desk drawer for storage.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your desk.

- **Cleaning:** Wipe the bamboo surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners. For the metal frame, use a mild detergent solution.
- **Cable Management:** Periodically check and organize cables within the management tray to prevent tangles and damage.
- **Fastener Check:** Every few months, inspect all screws and fasteners to ensure they are tight. Re-tighten if necessary.
- **Motor Care:** The dual motors are designed for durability. Avoid overloading the desk or forcing movement if an obstruction is present.



Figure 6.1: The bamboo desktop is durable and resistant to wear.

7. TROUBLESHOOTING

If you encounter issues with your FLEXISPOT Q8 desk, refer to the following common solutions:

Problem	Possible Cause	Solution
Desk does not move	Power cable disconnected; Overload; Motor error	Check power connections; Reduce weight on desk; Unplug and replug power after 30 seconds.
Uneven height adjustment	Obstruction; Unbalanced load	Remove obstructions; Distribute weight evenly.
Wireless charging not working	Device not compatible; Misalignment; Thick phone case	Ensure device supports Qi wireless charging; Realign device on charging pad; Remove phone case if too thick.

Problem	Possible Cause	Solution
Wired USB charging not working	Cable issue; Device not compatible	Try a different USB cable; Ensure device is compatible with USB charging standards.

If problems persist after attempting these solutions, please contact FLEXISPOT customer support.

8. SPECIFICATIONS

Feature	Specification
Model Number	FLEXISPOT Comhar Pro Desk Q8
Desktop Material	Bamboo
Frame Material	Metal
Product Dimensions (D x W x H)	12.8"D x 28.3"W x 24"H (Base)
Tabletop Size	55 inches (Working Surface Diagonal Length)
Height Range	24.0 inches - 49.2 inches
Motor Type	Dual Motor, 3 Stages
Lift Speed	1.5 inches/second
Weight Capacity	220 lbs (100 kg)
Control Panel	Digital display, Up/Down buttons, 4 Memory Presets
Wired Charging Ports	1x Type-A (18W), 1x Type-C (45W)
Wireless Charging	10W Integrated
Drawer	Integrated Single Drawer
Assembly Required	Yes (Quick Install)

9. WARRANTY AND SUPPORT

The FLEXISPOT Q8 55" Bamboo Standing Desk comes with a Limited Warranty. Please refer to the warranty documentation included with your product for specific terms and conditions.

9.1 Optional Protection Plans

Additional protection plans may be available for purchase to extend coverage beyond the standard warranty period. These plans typically offer:







- 2-Year Protection Plan
- 3-Year Protection Plan

For detailed information on protection plans or to purchase one, please consult your retailer or the FLEXISPOT official website.

9.2 Customer Support

For technical assistance, troubleshooting, or warranty claims, please contact FLEXISPOT customer support through their official website or the contact information provided in your product packaging.

Related Documents - FLEXISPOT Comhar Pro Desk Q8

	<p>FlexiSpot EC4B EC4S EC4W Electric Height-Adjustable Desk Installation Guide</p> <p>This guide provides detailed instructions for installing FlexiSpot EC4B, EC4S, and EC4W electric height-adjustable desk frames. It covers specifications, parts, assembly steps, handset operation, troubleshooting, and warranty information.</p>
	<p>FlexiSpot E7CB/E7CW/E7CS Height Adjustable Standing Desk Installation Guide</p> <p>Comprehensive installation guide for FlexiSpot E7CB, E7CW, and E7CS electric height adjustable standing desks. Includes specifications, parts list, step-by-step assembly instructions, operating instructions, troubleshooting, and limited warranty information.</p>
	<p>FlexiSpot EW8B/EW8W/EW8M Installation Guide and Limited Warranty</p> <p>This document provides installation instructions and warranty information for the FlexiSpot EW8B, EW8W, and EW8M height-adjustable desks. It includes specifications, assembly steps, keypad usage, troubleshooting tips, and details on the limited warranty coverage.</p>
	<p>FlexiSpot EC4B EC4S EC4W Installation Guide</p> <p>This document provides a comprehensive installation guide for the FlexiSpot EC4B, EC4S, and EC4W electric height-adjustable standing desks. It includes specifications, accessory packages, parts included, step-by-step assembly instructions, handset operation, troubleshooting tips, attention notes, and warranty information.</p>
	<p>FlexiSpot EC1B/EC1S/EC1W Installation Guide and Limited Warranty</p> <p>Comprehensive installation guide and limited warranty details for FlexiSpot EC1B/EC1S/EC1W electric height-adjustable desks. Includes specifications, troubleshooting, and product care information.</p>
	<p>FlexiSpot M7L-US Computer Riser Installation Guide and Warranty</p> <p>Official installation guide and limited warranty information for the FlexiSpot M7L-US Sit-Stand Desktop Workstation. Learn how to assemble, use, and understand the warranty terms for your FlexiSpot computer riser.</p>