

## Hiplok V150SB

# Hiplok Original Wearable Chain Bicycle Lock Superbright User Manual

## INTRODUCTION

The Hiplok Original is a multi-award-winning wearable chain lock designed for secure bicycle locking. It features a patented belt fastening system, allowing it to be worn comfortably around the waist while remaining easily removable. This manual provides instructions for its proper use and maintenance.

The Hiplok Original combines a tough hardened steel chain with a secure locking mechanism, offering both security and practicality.


### Key Features:

- Wearable chain lock with adjustable belt fastening.
- Designed to be worn without being locked to the rider.
- Removable and washable outer sleeve.
- Reflective detailing for enhanced visibility (Superbright model).
- Weight: 1950 grams (approximately 4.18 lbs).
- Security Level: High Risk, Silver Sold Secure Rating.
- Specifications: 10mm hardened steel shackle, 8mm hardened steel chain, 3 keys included, 85cm locking diameter.

## SETUP AND WEARING INSTRUCTIONS


The Hiplok Original is designed to be worn around your waist for convenient transport. It is adjustable to fit various waist sizes.

1. **Adjusting the Fit:** Wrap the Hiplok Original around your waist. Use the patented belt fastening system to adjust the length until it fits comfortably and securely. Ensure it is snug but not restrictive.



Adjusting the Hiplok Original to fit comfortably around the waist. The patented belt fastening allows for a secure yet easily removable fit.

2. **Wearing While Riding:** Once adjusted, the lock can be worn while cycling. The design ensures that the lock is not physically locked to your body, allowing for quick removal if needed.



The Hiplok Original worn securely around the waist during cycling. The design ensures it is not locked to the rider.

3. **Visibility:** The Superbright model features reflective elements to enhance your visibility during low-light conditions.



The Superbright model incorporates reflective elements for increased visibility during night rides.

## OPERATING INSTRUCTIONS (LOCKING YOUR BICYCLE)

To secure your bicycle, remove the Hiplok Original from your waist and wrap the chain around your bicycle frame and a fixed object.

1. **Positioning the Lock:** Choose a sturdy, fixed object such as a bike rack, lamppost, or railing. Position your bicycle close to the object.
2. **Wrapping the Chain:** Unfasten the Hiplok Original and wrap the hardened steel chain around a part of your bicycle frame (e.g., the top tube or seat tube) and the fixed object. Ensure the chain passes through both the frame and the fixed object to prevent theft.



Securing a bicycle with the Hiplok Original. The chain is passed through the bicycle frame and around a fixed object, then locked.

3. **Engaging the Lock:** Insert one of the provided keys into the lock cylinder and turn it to secure the chain. Ensure the lock mechanism is fully engaged and the chain cannot be pulled apart.



The Hiplok Original comes with three keys for convenience. Keep spare keys in a safe place.

4. **Removing the Lock:** To unlock, insert the key and turn it to disengage the mechanism. Remove the chain from your bicycle and the fixed object.

## MAINTENANCE

- **Sleeve Cleaning:** The outer sleeve of the Hiplok Original is removable and washable. To clean, slide the sleeve off the chain. Wash it according to standard fabric care instructions (typically hand wash or gentle machine wash with mild detergent). Ensure the sleeve is completely dry before reattaching it to the chain.
- **Lock Mechanism Lubrication:** Periodically apply a small amount of suitable lubricant (e.g., graphite-based or silicone-based lubricant) to the lock cylinder and shackle mechanism. This helps ensure smooth operation and prevents corrosion. Avoid using oil-based lubricants that can attract dirt.
- **Storage:** When not in use, store the Hiplok Original in a dry place to prevent rust and prolong its lifespan.

## SPECIFICATIONS

- **Model:** V150SB
- **Material Composition:** Steel (70%), Brass (5%), Polyester (10%), Nylon (15%)
- **Weight:** 1950 grams (4.18 lbs)
- **Chain Thickness:** 8mm hardened steel
- **Shackle Thickness:** 10mm hardened steel
- **Locking Length:** 85cm (locking diameter)
- **Lock Type:** Key Lock
- **Included Components:** 1 x Chain lock, 3 x keys
- **Security Rating:** Silver Sold Secure
- **Item Dimensions (L x W x H):** 18.75 x 4.25 x 4 inches

- **Special Feature:** Key Unlock

## WARRANTY AND SUPPORT

---

This Hiplok Original Wearable Chain Bicycle Lock is covered by a **Limited Lifetime Warranty**. For complete details regarding warranty coverage, terms, and conditions, please visit the official Hiplok website: [www.hiplok.com](http://www.hiplok.com).

For additional product support, technical assistance, or general inquiries, you may also visit the Hiplok Store on Amazon:

[Hiplok Amazon Store](#)