

[Manuals.plus](#) /

› [Ride](#) /

› Ride Pick-Up Truck Speaker User Manual

Ride WS - 538BT

User Manual

Ride Pick-Up Truck Bluetooth Portable Speaker

Model: WS - 538BT

1. INTRODUCTION

Thank you for purchasing the Ride Pick-Up Truck Bluetooth Portable Speaker. This speaker combines vintage design with modern audio technology, offering versatile listening options and a unique aesthetic. Please read this manual carefully before using the product to ensure proper operation and to maximize its lifespan.

2. SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures, humidity, or direct sunlight.
- Keep the speaker away from water or other liquids. This product is not waterproof.
- Do not disassemble or attempt to repair the speaker yourself. This will void the warranty.
- Use only the provided charger to charge the device.
- Keep out of reach of small children to prevent accidental ingestion of small parts.
- Avoid prolonged listening at high volumes to prevent hearing damage.

3. PACKAGE CONTENTS

Please check the package contents upon opening:

- 1 x Ride Pick-Up Truck Bluetooth Portable Speaker
- 1 x Charging Cable



Image: The Ride Pick-Up Truck Bluetooth Portable Speaker in black, showcasing its design.

4. PRODUCT OVERVIEW

Familiarize yourself with the various parts and controls of your speaker.



Image: Rear view of the speaker, highlighting the input ports and controls.

1. **Power Button:** Press and hold to turn on/off.
2. **Mode Button:** Short press to switch between Bluetooth, FM, USB, TF (SD Card), and AUX modes.
3. **Play/Pause Button:** Press to play or pause audio. In FM mode, long press to auto-scan stations.
4. **Previous Track/Volume Down:** Short press for previous track. Long press to decrease volume.
5. **Next Track/Volume Up:** Short press for next track. Long press to increase volume.

6. **USB Port:** For USB flash drive playback.
7. **TF Card Slot:** For TF (Micro SD) card playback.
8. **AUX Input:** For connecting external audio devices via 3.5mm audio cable.
9. **Charging Port:** For connecting the charging cable.
10. **LED Lights:** Integrated lights for visual effects.
11. **Microphone:** Built-in for hands-free calling.

5. SETUP

5.1 Charging the Speaker

1. Connect the charging cable to the speaker's charging port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate during charging and turn off when fully charged.
4. A full charge takes approximately 2-3 hours. The speaker provides up to 4 hours of playback on a full charge.



Image: Visual indicating the speaker's 1800mAh battery capacity for smart Bluetooth connection.

5.2 Powering On/Off

- To power on, press and hold the Power Button until you hear an audible prompt.
- To power off, press and hold the Power Button again until the speaker shuts down.

6. OPERATING INSTRUCTIONS

6.1 Bluetooth Pairing

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light and an audible prompt.
2. Enable Bluetooth on your mobile device (smartphone, tablet, computer).
3. Search for "WS - 538BT" or "Ride Speaker" in the list of available Bluetooth devices.
4. Select the speaker to connect. Once paired, you will hear a confirmation sound.
5. The speaker will automatically reconnect to the last paired device when powered on, if the device is within range (up to 10 meters) and Bluetooth is enabled.



Image: Visual representation of the five playback modes available on the speaker: Bluetooth, TF card, USB, AUX, and FM radio.

6.2 Auxiliary (AUX) Input

- Connect one end of a 3.5mm audio cable (not included) to the AUX input port on the speaker.
- Connect the other end to the headphone jack of your audio device.
- The speaker will automatically switch to AUX mode, or you can press the Mode Button to select AUX.
- Control playback and volume from your connected device.

6.3 USB/TF Card Playback

- Insert a USB flash drive or TF (Micro SD) card into the respective port on the speaker.

- The speaker will automatically detect the storage device and begin playing supported audio files (MP3).
- Use the Previous/Next Track buttons to navigate songs.

6.4 FM Radio

- Press the Mode Button to switch to FM Radio mode.
- Long press the Play/Pause button to automatically scan and save available FM stations.
- Short press the Previous/Next Track buttons to switch between saved stations.

6.5 Hands-Free Calling

- When connected via Bluetooth, incoming calls will be routed through the speaker.
- Press the Play/Pause button to answer an incoming call.
- Press the Play/Pause button again to end a call.
- Press and hold the Play/Pause button to reject an incoming call.

6.6 LED Lights

- The speaker features integrated LED lights that activate automatically when the speaker is powered on.
- These lights provide visual effects during audio playback.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe the speaker's surface. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Battery Care:** To prolong battery life, charge the speaker fully before first use and at least once every three months if not used regularly.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is low or depleted.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Bluetooth is not enabled on device; speaker is too far; speaker is already paired.	Ensure Bluetooth is on. Move device closer. Disconnect from other devices. Restart speaker and device.
No sound.	Volume is too low; incorrect mode selected; audio cable not fully inserted.	Increase volume on speaker and device. Press Mode button to select correct input. Ensure cables are fully inserted.
Poor FM radio reception.	Weak signal in current location.	Move the speaker to a location with better signal.

9. SPECIFICATIONS

- **Model Name:** Pick-Up Truck

- **Model Number:** WS - 538BT
- **Speaker Type:** Surround Sound
- **Connectivity Technology:** Bluetooth, Auxiliary, USB
- **Wireless Communication Technology:** Bluetooth
- **Bluetooth Range:** Up to 10 meters (33 feet)
- **Power Source:** Battery Powered
- **Battery Life:** Up to 4 Hours
- **Speaker Maximum Output Power:** 5 Watts
- **Material:** Plastic
- **Product Dimensions:** 25"D x 11"W x 3"H
- **Item Weight:** 1.5 pounds
- **Compatible Devices:** iPhone, Laptop, Tablet, Android
- **Control Method:** Voice, Button
- **Supported Modes:** TWS, REC, MP3, USB, TF, FM

10. WARRANTY AND SUPPORT

This product comes with a standard limited warranty. For detailed warranty information or technical support, please refer to the product packaging or contact the retailer where you purchased the item. Please retain your proof of purchase for warranty claims.

