Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tefal FV8066

Tefal Puregliss Steam Iron FV8066 User Manual

Model: FV8066 Puregliss
Brand: Tefal

1. Introduction

Thank you for choosing the Tefal Puregliss Steam Iron FV8066. This manual provides essential information for the safe and efficient use, maintenance, and troubleshooting of your new steam iron. Please read these instructions carefully before first use and keep them for future reference.
The Tefal Puregliss steam iron combines powerful steam performance with enhanced features for exceptional garment care. It offers 3000W for rapid heating, a continuous steam output of 50 g/min, and a powerful 280 g/min steam boost to tackle even the most stubborn creases. Its patented Micro-Calc Filter system protects your clothes from stains, and the Durilium AirGlide Autoclean soleplate ensures excellent glide and scratch resistance.

2. Important Safety Instructions

When using your iron, basic safety precautions should always be followed, including the following:

- Read all instructions before using the iron.
- Use the iron only for its intended use.
- To protect against a risk of electric shock, do not immerse the iron in water or other liquids.
- The iron must always be turned to "Off" before plugging or unplugging from the outlet. Never yank cord to disconnect from outlet; instead, grasp plug and pull to disconnect.
- Do not allow cord to touch hot surfaces. Let iron cool completely before putting away. Loop cord loosely around iron when storing.
- Always disconnect iron from electrical outlet when filling with water or emptying and when not in use.
- Do not operate iron with a damaged cord or if the iron has been dropped or damaged. To avoid the risk of electric shock, do not disassemble the iron; take it to a qualified serviceman for examination and repair. Incorrect reassembly can cause a risk of electric shock when the iron is used.
- Close supervision is necessary for any appliance being used by or near children. Do not leave iron unattended while connected or on an ironing board.
- Burns can occur from touching hot metal parts, hot water, or steam. Use caution when you turn a steam iron upside

down – there may be hot water in the reservoir.

- The iron must be used and rested on a stable surface.
- When placing the iron on its stand, ensure that the surface on which the stand is placed is stable.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

3. Product Components

Familiarize yourself with the different parts of your Tefal Puregliss steam iron.

1. Water filling inlet
2. Spray button
3. Steam boost trigger
4. Temperature control dial
5. Steam control lever (Dry/Steam)
6. Self-clean button
7. Micro-Calc Filter
8. Durilium AirGlide Autoclean Soleplate
9. Water tank
10. Power cord



Figure 3.1: Overview of the Tefal Puregliss Steam Iron FV8066, showing its sleek black and turquoise design.



Figure 3.2: Close-up view of the Durilium AirGlide Autoclean soleplate, highlighting its unique design for optimal glide and steam distribution.

4. Setup

4.1 Before First Use

Before using your iron for the first time, remove any stickers or protective film from the soleplate. It is normal for a small amount of smoke or odor to be produced during the first few minutes of use. This will quickly disappear.

4.2 Filling the Water Tank

1. Ensure the iron is unplugged from the electrical outlet.
2. Set the steam control lever to the "Dry" position.
3. Open the water filling inlet.
4. Fill the water tank with tap water up to the "MAX" level indicated on the tank (270 ml capacity). Do not overfill.
5. Close the water filling inlet securely.



Figure 4.1: The Tefal Puregliss iron resting securely on an ironing board, ready for use.

5. Operating Instructions

5.1 Ironing Temperature Settings

1. Plug the iron into a suitable electrical outlet (2.3E+2 Volts AC).
2. Turn the temperature control dial to the desired setting according to the fabric type. Refer to the fabric care labels on your garments.
3. The indicator light will illuminate, indicating the iron is heating up. It will turn off when the desired temperature is reached.

5.2 Dry Ironing

For dry ironing, ensure the steam control lever is set to the "Dry" position. You can begin ironing once the indicator light turns off.

5.3 Steam Ironing

Steam ironing is recommended for most fabrics. Ensure the water tank is filled and the temperature control dial is set to a steam-compatible setting (usually indicated by steam symbols on the dial).

1. Once the iron reaches the set temperature, move the steam control lever to the desired steam position. The iron provides a continuous steam output of up to 50 g/min.
2. Begin ironing your garments.



Figure 5.1: The Tefal Puregliss iron powerfully emitting steam, demonstrating its effective crease removal capabilities.

5.4 Steam Boost (Shot of Steam)

For stubborn creases, press the steam boost trigger. This delivers an extra shot of steam up to 280 g/min. Wait a few seconds between each shot to allow the iron to reheat.

5.5 Vertical Steaming

The steam boost function can also be used for vertical steaming of hanging garments, curtains, or drapes.

1. Hang the garment on a hanger.
2. Hold the iron vertically, a few centimeters away from the fabric.
3. Press the steam boost trigger repeatedly while moving the iron up and down the garment.



Figure 5.2: A user demonstrating the vertical steaming capability of the Tefal Puregliss iron on a hanging shirt.

5.6 Spray Function

To moisten stubborn creases, press the spray button. This will release a fine mist of water onto the fabric.

5.7 Automatic Shut-off

For safety and energy saving, your iron is equipped with an automatic shut-off feature. If left unattended in a horizontal position, it will turn off after 30 seconds. If left in a vertical position, it will turn off after 8 minutes. The indicator light will flash when the iron is in auto-off mode. To restart, simply move the iron.

6. Maintenance and Cleaning

6.1 Cleaning the Soleplate

To clean the Durilium AirGlide Autoclean soleplate, use a damp cloth or a non-abrasive sponge. Do not use abrasive cleaners or metallic scouring pads as they can damage the soleplate coating.

6.2 Cleaning the Micro-Calc Filter

The patented Micro-Calc Filter collects limescale particles to prevent them from staining your garments. It should be cleaned regularly, depending on the hardness of your water and frequency of use.

1. Ensure the iron is unplugged and completely cool.
2. Locate the Micro-Calc Filter, usually at the back of the iron near the water tank.
3. Carefully pull out the filter.
4. Rinse the filter under running water to remove any accumulated limescale.
5. Reinsert the clean filter back into the iron until it clicks into place.



Figure 6.1: The Micro-Calc Filter being removed from the iron, showing accumulated limescale ready for cleaning.

6.3 Emptying the Water Tank

After each use, it is recommended to empty any remaining water from the tank to prevent limescale buildup and odors. Unplug the iron, open the water filling inlet, and invert the iron over a sink to drain the water.

7. Troubleshooting

Problem	Possible Cause	Solution
No steam is produced.	Water tank is empty. Temperature setting is too low for steam. Steam control lever is on "Dry".	Fill the water tank. Set the temperature to a steam-compatible setting. Move the steam control lever to a steam position.
Water drips from the soleplate.	Temperature is too low for steam. Steam boost used too frequently. Anti-drip system is active (normal for low temperatures).	Allow the iron to heat up fully before using steam. Wait a few seconds between steam boosts. This is normal. Increase temperature if possible.
Iron does not heat up.	Iron is unplugged. Automatic shut-off activated. Power outlet issue.	Check power connection. Move the iron to reactivate. Test the outlet with another appliance.
White flakes coming from soleplate.	Limescale buildup.	Clean the Micro-Calc Filter as described in Section 6.2.

If the problem persists, please contact Tefal customer support.

8. Specifications

Model: FV8066 Puregliss

Brand: Tefal

Power: 3000 Watts

Continuous Steam Output: Up to 50 g/min

Steam Boost: Up to 280 g/min

Water Tank Capacity: 270 Millilitres

Soleplate Material: Durilium AirGlide Autoclean

Color: Black/Turquoise

Dimensions (L x W x H): 34 x 14 x 18 cm

Item Weight: 280 Grams

Voltage: 2.3E+2 Volts (AC)

Special Features: Automatic Shut-off, Anti-drip system, Micro-Calc Filter

Country of Origin: France

9. Warranty and Support

Tefal products are designed for durability and performance. For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official Tefal website.
For technical assistance, spare parts, or repair services, please contact Tefal customer support in your region. You can usually find contact details on the Tefal website or in the product packaging.
Online Support: www.tefal.com

© 2025 Tefal. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BN8PJHGD

More documents and user manuals: **https://manuals.plus/**