

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Apple](#) /
- › [Apple iPhone 14 Pro Max User Manual](#)

Apple iPhone 14 Pro Max

Apple iPhone 14 Pro Max User Manual

MODEL: IPHONE 14 PRO MAX

Brand: Apple

Introduction

This manual provides essential information for setting up, operating, and maintaining your Apple iPhone 14 Pro Max. Please read thoroughly to ensure optimal performance and longevity of your device. This device is an Unlocked (Renewed) model with 256GB storage in Space Black.

What's in the Box

- Apple iPhone 14 Pro Max (Space Black, 256GB)
- USB Cable

Note: A power adapter (charger) is not included in the box. Please use a compatible USB-C power adapter for charging.

Setup

1. Initial Power On

Press and hold the **Side button** on the right side of the device until the Apple logo appears. Follow the on-screen instructions to complete the initial setup process.

2. eSIM Activation

The iPhone 14 Pro Max utilizes eSIM technology for cellular connectivity. There is no physical SIM card tray. To activate your cellular service, follow the on-screen prompts during setup or navigate to **Settings > Cellular > Add eSIM**. Contact your carrier for assistance with eSIM activation if needed.

3. Basic Configuration

During setup, you will be guided to connect to a Wi-Fi network, sign in with your Apple ID, set up Face ID, and configure other essential settings. Ensure you have your Apple ID credentials ready.

Operating Your Device

Display

The iPhone 14 Pro Max features a 6.7-inch Super Retina XDR display with Always-On and ProMotion technology. The Dynamic Island integrates alerts, notifications, and activities into an interactive area at the top of the display.



Front and back view of the Apple iPhone 14 Pro Max in Space Black.

Cameras

The device is equipped with an advanced camera system:

- **48MP Main Camera:** Offers up to 3x optical zoom.
- **12MP Ultra-Wide Camera:** Provides an expanded field of view.

- **Optical Zoom Range:** Up to 6x optical zoom range for versatile photography.

Video recording supports 4K and 1080p HD at various frame rates (25, 30, 60 fps), including Cinematic mode up to 4K HDR at 30 fps.



Close-up view of the triple camera system on the back of the iPhone 14 Pro Max.

Buttons and Ports

- **Side Button:** Located on the right, used for power, Siri, and Apple Pay.
- **Volume Buttons:** Located on the left, for adjusting audio levels.
- **Lightning Port:** Located at the bottom, used for charging and data transfer via the included USB cable.
- **Speakers & Microphones:** Located at the bottom and top for audio output and input.





Side view of the iPhone 14 Pro Max, highlighting the flat edges and button placement.

Performance and Battery

Powered by the A16 Bionic chip with 8GB RAM, the iPhone 14 Pro Max delivers robust performance. It offers all-day battery life and supports MagSafe wireless charging for convenient power replenishment.

Maintenance

To ensure the longevity and optimal performance of your iPhone 14 Pro Max, consider the following:

- Keep the device clean using a soft, lint-free cloth. Avoid abrasive materials or harsh chemicals.
- Protect the device from extreme temperatures, direct sunlight, and moisture.
- Use a protective case and screen protector to guard against physical damage.

Troubleshooting

If you encounter issues with your device, try the following common solutions:

- **Screen Blackouts:** If the screen randomly blacks out or turns off during calls, try restarting the device. Ensure the proximity sensor area (near the top of the screen) is clean and unobstructed. If the issue persists, it may indicate a hardware concern.
- **Battery Health:** Renewed devices may have varying battery health percentages. While some may be at 100%, others might be lower (e.g., 85%). This is normal for renewed products. Monitor battery performance via **Settings > Battery > Battery Health & Charging**
- **General Performance Issues:** Restarting your iPhone can resolve many minor software glitches. If problems persist, ensure your iOS is updated to the latest version via **Settings > General > Software Update**.

For persistent issues not resolved by these steps, please refer to the Warranty and Support section.

Specifications

Feature	Detail
Model Name	iPhone 14 Pro Max
Operating System	iOS 16
Screen Size	6.7 Inches
Resolution	2796 x 1290
Refresh Rate	120 Hz
CPU Model	Apple A14 Bionic
CPU Speed	2.02 GHz
RAM Memory Installed Size	8 GB
Memory Storage Capacity	256 GB
Color	Space Black

Battery Capacity	4323 Milliamp Hours
Item Weight	8.3 ounces
Product Dimensions	10 x 2 x 2.7 inches

Warranty and Support

Your renewed Apple iPhone 14 Pro Max comes with a 90-day refund/replacement return policy. Optional protection plans are available for extended coverage.

For further assistance or to inquire about warranty claims, please contact the seller, **talkTek**, directly through the Amazon platform.