

[manuals.plus](#) /› [Apple](#) /› [Apple iPhone 14 Pro Max User Manual - 128GB Space Black \(Renewed\)](#)

Apple iPhone 14 Pro Max

Apple iPhone 14 Pro Max User Manual

Model: iPhone 14 Pro Max, 128GB, Space Black - Unlocked (Renewed)

1. INTRODUCTION AND OVERVIEW

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Apple iPhone 14 Pro Max. This device is a renewed model, offering a 6.7-inch Super Retina XDR display featuring Always-On & ProMotion technology. It is powered by the Apple A16 Bionic chip and comes with 128GB of storage.



Image: Front and back view of the Apple iPhone 14 Pro Max in Space Black.

2. WHAT'S IN THE Box

Your Apple iPhone 14 Pro Max (Renewed) package includes the following items:

- Apple iPhone 14 Pro Max (128GB, Space Black)
- USB Cable

3. SETUP

1. **Power On:** Press and hold the Side button on the right side of the device until the Apple logo appears.
2. **Initial Configuration:** Follow the on-screen instructions to select your language, region, and connect to a Wi-Fi network.
3. **Data Transfer:** If you have an existing iPhone, you can transfer your data using Quick Start or restore from an iCloud or computer backup.
4. **Face ID Setup:** Set up Face ID for secure unlocking and purchases.
5. **Apple ID:** Sign in with your Apple ID or create a new one. This is essential for accessing the App Store, iCloud, and other Apple services.
6. **eSIM Activation:** The iPhone 14 Pro Max uses eSIM technology. Contact your carrier to activate your cellular plan.

4. OPERATING

4.1 General Operation

- **Gestures:** Navigate your iPhone using intuitive gestures like swiping up to go home, swiping down from the top-right for Control Center, and swiping down from the top-center for notifications.
- **Face ID:** Unlock your device and authenticate purchases securely using facial recognition.

4.2 Display

The iPhone 14 Pro Max features a 6.7-inch Super Retina XDR display with Always-On and ProMotion technology. The display offers vibrant colors, deep blacks, and a smooth scrolling experience with a 120 Hz refresh rate.

Dynamic Island: This interactive area at the top of the display adapts to show alerts, notifications, and ongoing activities like timers, music playback, and incoming calls, providing quick access to relevant information.

4.3 Camera

The device is equipped with an advanced camera system:

- **Main Camera:** A 48MP main sensor captures highly detailed photos.
- **Telephoto:** Utilize the 2x telephoto crop for optical-quality zoomed shots.
- **Advanced Features:** Benefit from improved Smart HDR and Night mode algorithms for better skin tones and reduced noise in low-light conditions.



Image: Detailed view of the triple-lens camera system on the iPhone 14 Pro Max.

4.4 Performance

Powered by the Apple A16 Bionic chip with a CPU speed of 3.46 GHz and 6GB of RAM, the iPhone 14 Pro Max delivers robust performance for demanding applications, intensive gaming, and video editing with efficient thermal management.

4.5 Connectivity

- **USB-C:** The device features a USB-C port for charging and data transfer, offering universal compatibility with modern devices.
- **Wireless Charging:** Supports wireless charging for convenient power replenishment.
- **Dual SIM:** Offers Dual SIM capabilities for managing two cellular plans.

5. MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean your iPhone. Avoid abrasive materials or harsh chemicals.

- **Software Updates:** Regularly update your iOS to the latest version to ensure optimal performance, security, and access to new features.
- **Battery Care:** To prolong battery lifespan, avoid extreme temperatures and optimize battery settings in iOS.

6. TROUBLESHOOTING

If you encounter issues with your iPhone 14 Pro Max, try the following steps:

- **Restart:** Perform a force restart by quickly pressing and releasing the Volume Up button, then the Volume Down button, then press and hold the Side button until the Apple logo appears.
- **Charging Issues:** Ensure your USB-C cable and power adapter are functioning correctly. Try a different cable or adapter.
- **Software Glitches:** If an app is unresponsive, force close it. If the issue persists, consider updating iOS or resetting settings.
- **Screen Issues:** For minor screen issues, a restart may resolve it. For persistent problems, contact support.

7. SPECIFICATIONS

Feature	Detail
Model Name	iPhone 14 Pro Max
Brand	Apple
Storage Capacity	128 GB
Color	Space Black
Operating System	iOS 16
CPU Model	Apple A16 Bionic
CPU Speed	3.46 GHz
RAM Memory	8 GB
Screen Size	6.7 Inches
Resolution	2796 x 1290
Refresh Rate	120 Hz
Battery Capacity	4323 Milliamp Hours
Charging Time	24 Hours (full charge cycle, not 0-100%)

Product Dimensions	0.31 x 2.81 x 5.81 inches
Item Weight	4.6 ounces
Special Features	Dual SIM, Always-On Display, ProMotion

8. WARRANTY AND SUPPORT

As a renewed product, your Apple iPhone 14 Pro Max is backed by the Amazon Renewed Guarantee, which provides a replacement or refund within 90 days of receipt if the product does not work as expected. For technical support or further assistance, please refer to Apple's official support resources or contact Amazon Renewed customer service.

- **Amazon Renewed Guarantee:** [Learn more](#)
- **Apple Support:** [Visit Apple's official iPhone support page](#)