

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [GUESS](#) /

> [GUESS Men's Trend Tonneau 43mm Watch \(Model GW0499G3\) Instruction Manual](#)

GUESS GW0499G3

GUESS Men's Trend Tonneau 43mm Watch (Model GW0499G3) Instruction Manual

Model: GW0499G3

1. INTRODUCTION

This instruction manual provides essential information for the proper use, care, and maintenance of your GUESS Men's Trend Tonneau 43mm Watch, Model GW0499G3. Please read this manual thoroughly before using your watch to ensure optimal performance and longevity.

2. PRODUCT OVERVIEW

The GUESS Men's Trend Tonneau 43mm Watch (Model GW0499G3) features a clear 44mm metal case and a vibrant multicolor dial. It is equipped with a comfortable clear silicone strap and an analog display. This timepiece is water resistant to 50 meters and includes multifunction sub-dials for enhanced utility.



Figure 2.1: Front view of the GUESS Men's Trend Tonneau 43mm Watch, Model GW0499G3.

3. SETUP

3.1. Time Setting

1. Pull the crown (located on the right side of the watch case) out to the second click position.
2. Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the desired time.
3. Once the time is set, push the crown back into its normal position to start the watch.



Figure 3.1: Close-up of the watch dial and crown.

3.2. Strap Adjustment

The watch features a clear silicone strap with a buckle clasp. To adjust the strap, simply insert the pin of the buckle into one of the holes on the strap that provides a comfortable and secure fit on your wrist.



Figure 3.2: Watch buckle clasp detail.

4. OPERATING INSTRUCTIONS

4.1. Reading the Time

Your watch uses an analog display with hour, minute, and second hands. The hour markers are clearly visible on the multicolor dial.

4.2. Multifunction Dials

The watch features three sub-dials that provide additional information. These typically display the day of the week, date, and 24-hour time. Refer to the specific markings on your watch's sub-dials for their exact functions.





Figure 4.1: Watch on wrist, displaying the time and multifunction dials.

4.3. Water Resistance

This watch is water resistant to 50 meters (5 ATM). This means it is suitable for short periods of recreational

swimming, but not for diving or snorkeling. Avoid operating the crown or pushers while the watch is wet or submerged.

5. MAINTENANCE

5.1. Cleaning Your Watch

- Wipe the watch case and strap with a soft, dry cloth regularly to remove dust and dirt.
- For silicone straps, a mild soap and water solution can be used, then rinse thoroughly and dry completely.
- Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish.

5.2. Battery Replacement

The watch is powered by one AA battery. When the watch stops or the second hand begins to jump erratically, it indicates that the battery needs to be replaced. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance seal is maintained.

5.3. Water Resistance Care

- Ensure the crown is fully pushed in before any contact with water.
- Avoid exposing the watch to extreme temperature changes (e.g., hot showers, saunas), as this can compromise the water resistance seals.
- Have the water resistance seals checked periodically by a professional, especially after battery replacement.

6. TROUBLESHOOTING

6.1. Watch Not Running

- **Check the Crown:** Ensure the crown is fully pushed into its normal operating position.
- **Battery:** The battery may be depleted. Refer to Section 5.2 for battery replacement.

6.2. Incorrect Time

- **Reset Time:** Follow the steps in Section 3.1 to reset the time.
- **Impact:** A strong impact may have affected the movement. If the issue persists, consult a qualified watch technician.

7. SPECIFICATIONS

Feature	Specification
Model Number	GW0499G3
Case Diameter	44 millimeters
Case Material	Metal
Case Thickness	10 millimeters
Band Material	Silicone
Band Width	10 millimeters

Band Color	Clear
Dial Color	Multicolor
Movement	Quartz
Display Type	Analog
Water Resistance Depth	50 Meters
Dial Window Material	Mineral Glass
Clasp Type	Buckle
Item Weight	1.87 ounces
Battery	1 AA (included)

8. WARRANTY AND SUPPORT

8.1. Warranty Information

Manufacturer's warranty information can be requested directly from GUESS customer service. Please retain your proof of purchase for warranty claims.

8.2. Customer Support

For further assistance, technical support, or service inquiries, please visit the official GUESS website or contact their customer service department. Contact details can typically be found on the GUESS official website or on the product packaging.

9. WATCH SIZE CHART VIDEO

This video provides a general guide to watch case sizes on different wrist sizes, which may be helpful for understanding how various watch sizes appear.

Your browser does not support the video tag.

Video 9.1: Guess Watch Size Chart. This video illustrates different watch case sizes on 6-inch and 7-inch wrists.