

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Joyside](#) /

› [Joyside 11'x11' Pop Up Canopy Tent Instruction Manual](#)

## Joyside 11'x11' Pop Up Canopy Tent

# Joyside 11'x11' Pop Up Canopy Tent Instruction Manual

Model: 11'x11' Pop Up Canopy Tent

## INTRODUCTION

Thank you for choosing the Joyside 11'x11' Pop Up Canopy Tent. This manual provides essential information for the safe and efficient setup, operation, and maintenance of your canopy. Please read all instructions carefully before assembly and use.

## Safety Warnings

- **Two-Person Assembly:** At least two persons are required for safe and proper assembly of this canopy.
- **Secure Anchoring:** Always use the provided stakes and ropes to securely anchor the gazebo. Failure to do so may result in instability and potential damage or injury, especially in windy conditions.
- **Weather Conditions:** This canopy is designed for sun protection and light weather conditions. Do not use in heavy rain, strong winds, or other severe weather. Disassemble and store the canopy during adverse weather.
- **Fire Safety:** The canopy fabric is CPAI-84 certified and flame resistant, but it is not fireproof. Keep all flame and heat sources away from the canopy fabric.

## PACKAGE CONTENTS

Please ensure all components are present before beginning assembly:

- Pop-Up Frame (Pre-assembled)
- Canopy Top (150D Oxford fabric)
- Mosquito Netting Sidewalls (with zippers)
- Stakes
- Ropes
- Carrying Bag

## SETUP INSTRUCTIONS

Follow these steps for a fast and hassle-free setup. Two people are recommended for assembly.



*Figure 1: Easy Setup Steps Overview*

**1. Step 1: Open the Gazebo Frame.**

With a partner, gently pull the pop-up frame open from opposite sides until it is partially extended. Ensure all legs are on the ground.


**2. Step 2: Attach the Canopy Top.**

Drape the canopy top over the partially opened frame. Align the corners and secure the canopy to the frame using any integrated fasteners (e.g., Velcro straps, corner pockets).

**3. Step 3: Extend and Lock the Frame.**

From underneath the canopy, push up on the central push-button control system until the frame fully extends and locks into place. You should hear a "click" sound. Adjust the height of the legs by pressing the release buttons and extending the lower leg sections to your desired height.

## EASY SETUP



01  
STEP

Open the gazebo frame

Cover the gazebo and push up on the Push-Button control system to raise



02  
STEP



03  
STEP

Adjust to fit for preferred shade coverage

Put the mosquito netting on the gazebo

04  
STEP



Figure 2: Push-Button Control System

#### 4. Step 4: Attach Mosquito Netting Sidewalls.

Hang the zippered mesh sidewalls from the frame using the provided rings or hooks. Ensure the zippers are aligned for easy closure. The sidewalls can be tied back to the legs when not in use.



*Figure 3: Canopy Tent with Sidewalls*

**5. Step 5: Secure the Canopy.**

Use the provided stakes to anchor each leg of the canopy firmly to the ground. Attach ropes to the canopy corners and stake them into the ground at an angle for additional stability.

## **OPERATING INSTRUCTIONS**

### **Using the Mosquito Netting Sidewalls**

The canopy includes zippered mesh sidewalls to provide privacy and protection from insects. To close the sidewalls, simply zip them together. To open them, unzip and tie them back to the canopy legs using the integrated ties.

# SIZE 11FT x 11FT



Figure 4: Securing Sidewall Ties

## Vented Double-Tier Top

The double-tier top design promotes airflow, reducing heat buildup and enhancing comfort underneath the canopy. The extended eave design helps prevent rain accumulation.

## UV Protection

The 150D Oxford fabric canopy top offers UPF 50+ UV sun protection, blocking up to 99% of harmful UV rays.

## MAINTENANCE

- **Cleaning:** Clean the canopy fabric and mesh sidewalls with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Rinse thoroughly and allow to air dry completely before storage.
- **Frame Care:** The powder-coated steel frame is rust-resistant. Wipe down the frame with a damp cloth as needed. Inspect the frame for any damage or loose connections periodically.
- **Storage:** When not in use or during severe weather, disassemble the canopy and store it in the complimentary carrying bag in a dry, cool place. Ensure all components are clean and dry before storage to prevent mold or mildew.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Canopy is unstable or sways in light wind.	Insufficient anchoring.	Ensure all legs are properly staked to the ground and ropes are securely attached and staked. Do not use in strong winds.
Water accumulates on the canopy top.	Improper setup or heavy rainfall.	Ensure the frame is fully extended and locked, and the canopy top is taut. While water-repellent, the canopy is not designed for heavy rain; disassemble during such conditions.
Mosquito netting does not fully close or has gaps.	Improper attachment or alignment.	Verify that the netting is correctly hung from the frame and zippers are properly aligned and fully closed.
Frame difficult to extend or retract.	Mechanism not properly engaged or debris.	Ensure the push-button control system is fully engaged or disengaged. Check for any obstructions or debris in the moving parts. Apply a silicone-based lubricant if necessary.

## SPECIFICATIONS

**Brand:** Joyside

**Model:** 11'x11' Pop Up Canopy Tent

**Dimensions:** 11 ft x 11 ft (Top), 10 ft x 10 ft (Base)

**Occupancy:** Up to 6 People

**Frame Material:** Powder-Coated Alloy Steel

**Canopy Fabric:** 150D Oxford Fabric

**UV Protection:** UPF 50+ (Blocks up to 99% of UV rays)

**Water Resistance:** Water Repellent

**Fire Resistance:** CPAI-84 Certified

**Assembly Required:** Yes (2 persons suggested)

**Shape:** Square



*Figure 5: Product Dimensions and Features*

## **WARRANTY AND SUPPORT**

---

For any questions, concerns, or issues related to your Joyside Pop Up Canopy Tent, please contact our customer service team. We are committed to ensuring your satisfaction.

Please refer to your purchase documentation or the retailer's website for specific warranty details and contact information.