

- [Manuals.plus](#) /
- › [VINGLI](#) /
 - › VINGLI 70-inch Fireplace TV Stand User Manual

VINGLI 70-inch Fireplace TV Stand

VINGLI 70-inch Fireplace TV Stand User Manual

MODEL: 70-INCH FIREPLACE TV STAND

1. Introduction

Thank you for purchasing the VINGLI 70-inch Fireplace TV Stand. This product combines a spacious entertainment center with an integrated electric fireplace and customizable LED lighting, designed to enhance your living space. This manual provides essential information for safe assembly, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your product.



Image 1.1: The VINGLI 70-inch Fireplace TV Stand, showcasing its design and functionality in a typical home environment.

2. Safety Information

Please read all safety warnings and instructions carefully before assembly and operation. Failure to follow these instructions may result in electric shock, fire, property damage, or personal injury.

- **Electrical Safety:** Ensure the power outlet meets the product's electrical requirements. Do not overload circuits. Keep power cords away from heated surfaces and foot traffic. Never operate the fireplace with a damaged cord or plug.
- **Fireplace Safety:** Maintain a minimum clearance of 3 feet (0.9 meters) from the front of the fireplace to any combustible materials (e.g., furniture, curtains). Do not block air vents. The electric fireplace is equipped with overheating protection; if it overheats, it will automatically shut off.
- **Assembly Safety:** Assembly should be performed by two adults. Use appropriate tools and ensure all fasteners are securely tightened. Do not stand on the unit.
- **Placement:** Place the TV stand on a flat, level, and stable surface. Avoid placing it near water sources or in

excessively humid environments.

- **Children and Pets:** Keep children and pets away from the fireplace and moving parts. Do not allow them to play with the remote control.

3. Package Contents

The VINGLI 70-inch Fireplace TV Stand is delivered in two separate packages, which may arrive at different times. Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

23 INCH Fireplace With Remote Control



(burn with or without heater)





The item will be delivered in **2** packages, and each may arrive at a different time.



Authentic flame effect



0.5-6 Hours Timer



62°F-82°F



Six Mesmerizing Flame Colors



Overheating protection



CSA Listed

Image 3.1: The 23-inch electric fireplace insert, indicating that the product ships in two packages.

Expected Components:

- TV Stand Panels and Shelves (various sizes)
- Electric Fireplace Insert (23-inch)
- Remote Control for Fireplace

- LED Light Strip with APP/Remote Control
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Instruction Manual

4. Setup and Assembly

Before assembly, clear a spacious area and lay out all components on a soft, clean surface to prevent scratches. Refer to the included detailed assembly instructions for step-by-step guidance. Two people are recommended for assembly.

Key Assembly Steps:

1. **Unpack and Identify Parts:** Carefully remove all items from the packaging and identify each component using the parts list in the separate assembly guide.
2. **Assemble TV Stand Frame:** Follow the diagrams to connect the base, side panels, and top board using the provided hardware. Ensure all connections are secure.
3. **Install Adjustable Shelves:** Insert shelf pins into desired height positions within the open cubbies and place the shelves.
4. **Integrate Electric Fireplace:** Carefully slide the 23-inch electric fireplace insert into the designated central opening. Ensure it is flush and secured according to the fireplace's specific instructions.
5. **Attach LED Lighting:** Adhere the LED light strips to the interior of the open shelves as desired. Connect the LED controller and power supply.
6. **Cable Management:** Utilize the integrated cable management holes to route and organize power cords and media device cables.




Meticulously Crafted Details



Elegant Carved Decorations



Spacious Storage Shelves



Sturdy Base Foundation



Exquisitely Crafted Top Board

Image 4.1: Detailed views of the TV stand's construction, highlighting features relevant to assembly and structural integrity.

5. Operating Instructions

5.1. Electric Fireplace Operation

The electric fireplace can be operated via the control panel on the unit or the included remote control.

- **Power On/Off:** Press the power button to turn the fireplace on or off.
- **Heat Settings:** Adjust the temperature between 65°F and 95°F (18°C-35°C). The heater has a maximum output of 1400 Watts.
- **Flame Brightness:** Cycle through 3 levels of flame brightness to suit your preference.
- **Backlight Colors:** Select from 6 different backlight colors to customize the ambiance.
- **Timer Function:** Set an automatic shut-off timer from 0 to 6 hours.
- **Flame Effect Only:** The flame effect can be operated independently of the heater.

5.2. LED Lighting Operation

The integrated LED lighting can be controlled using the provided remote control or a compatible smartphone application.



Image 5.1: The LED lighting features, demonstrating color options and control methods.

- **Color Selection:** Choose from a full spectrum of colors to match your mood or decor.
- **Dynamic Modes:** Activate music rhythm sync or mic-sync dynamic modes for interactive lighting effects.
- **Auto-Off Timer:** Set a timer for the LED lights to automatically turn off.
- **Brightness Adjustment:** Adjust the intensity of the LED illumination.

6. Maintenance

Regular maintenance ensures the longevity and appearance of your VINGLI Fireplace TV Stand.

- **Cleaning:** Dust the surfaces with a soft, dry cloth. For stubborn marks, use a slightly damp cloth and mild soap, then wipe dry immediately. Avoid abrasive cleaners or harsh chemicals.

- **Fireplace Insert:** Ensure the fireplace is unplugged and cool before cleaning. Gently wipe the glass and exterior surfaces with a soft, damp cloth. Do not spray liquids directly into the unit.
- **Electrical Components:** Periodically check the power cord for any signs of damage.

7. Troubleshooting

If you encounter issues with your VINGLI Fireplace TV Stand, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, power switch off, remote battery low.	Check power connection, ensure main power switch is on, replace remote batteries.
No heat output.	Heater function off, overheating protection activated.	Ensure heater is enabled. Unplug unit, wait 15 minutes for reset, then plug back in. Clear any obstructions from vents.
LED lights not working.	Loose connection, remote battery low, controller issue.	Check all LED strip connections. Replace remote batteries. Try controlling with the app if applicable.
Remote control unresponsive.	Low battery, obstruction, out of range.	Replace batteries. Ensure clear line of sight to the receiver. Move closer to the unit.

If the problem persists after attempting these solutions, please contact VINGLI customer support.

8. Specifications

Feature	Detail
Product Dimensions	70"W x 15.75"D x 35.83"H
Material	Engineered Wood
Power Source	Corded Electric
Heat Output	1400 Watts
Fireplace Size	23 inches
Temperature Range	65°F - 95°F
Flame Brightness Levels	3
Fireplace Backlight Colors	6
Fireplace Timer	0-6 hours
Installation Type	Freestanding
Certifications	CSA certified (Fireplace)




Image 8.1: Dimensional drawing of the TV stand, illustrating its overall size and internal shelf measurements.

9. Warranty and Support

VINGLI stands behind the quality of its products. Your VINGLI Fireplace TV Stand comes with a **1-year Quality Service** warranty.

- **Warranty Coverage:** This warranty covers manufacturing defects and material flaws under normal use for one year from the date of purchase.
- **Customer Support:** For any questions, concerns, or assistance with assembly, operation, or warranty claims, please contact VINGLI's **24/7 Professional Quality Service**. Refer to your purchase documentation or the VINGLI official website for specific contact details.



Image 9.1: VINGLI's commitment to product quality and customer support.

© 2023 VINGLI. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BNB84JG3>

More documents and user manuals: <https://manuals.plus/>