

[manuals.plus](#) /

› [Luoran](#) /

› [Luoran M4B MP3 Player Instruction Manual](#)

Luoran M4B

Luoran M4B MP3 Player Instruction Manual

Model: M4B

Brand: Luoran

1. INTRODUCTION

The Luoran M4B MP3 Player is a versatile and user-friendly device designed for kids and teenagers, offering a comprehensive multimedia experience. It comes pre-installed with popular applications like Spotify Kids, Spotify, Amazon Music, and Audible, and supports a wide range of audio and video formats. Featuring a 4.0-inch IPS touchscreen, Bluetooth, Wi-Fi connectivity, and expandable storage up to 256GB, the M4B is perfect for music, videos, audiobooks, and more. Its robust parental control system ensures a safe and controlled environment for young users.

2. WHAT'S IN THE Box

Your Luoran M4B MP3 Player package includes the following items:

- Luoran M4B MP3 Player
- OTG Adapter
- Wired Earphones
- Instruction Manual
- USB-C Cable
- Silicon Case



Image: Luoran M4B MP3 Player with included accessories.

3. PRODUCT OVERVIEW & PHYSICAL FEATURES

Familiarize yourself with the physical components and controls of your M4B MP3 Player.

3.1. Device Layout

Parental Controls

Block & unblock apps, installation control, set auto ON/OFF timer



Image: Side view of the MP3 player, highlighting the power and volume buttons.

- **Power Button:** Located on the side, press and hold to power on/off or restart.
- **Volume Buttons:** Located on the side, press to adjust volume up or down.
- **USB-C Port:** Located at the bottom for charging and data transfer.
- **3.5mm Headphone Jack:** Located at the bottom for wired earphones.
- **Micro SD Card Slot:** Located on the side, allows for expandable storage up to 256GB.

Supports music formats including

MP3, WAV, FLAC, APE, OGG, M4A, AAC, WMA, MP2, ETC.



Image: Bottom view of the MP3 player, showing the USB-C port and headphone jack.

Expandable Memory

Supports maximum 256GB micro SD card



Image: The MP3 player with a Micro SD card inserted into its expandable memory slot.

4. INITIAL SETUP

4.1. Powering On/Off

To power on the device, press and hold the Power button on the side until the screen lights up. To power off, press and hold the Power button again until a menu appears, then select 'Power off'.

4.2. Connecting to Wi-Fi

Navigate to 'Settings' from the home screen. Select 'Network & Internet' or 'Wi-Fi'. Turn on Wi-Fi and select your desired network from the list. Enter the password if prompted and tap 'Connect'.

4.3. Setting Date and Time

In 'Settings', go to 'System' or 'Date & Time'. You can enable 'Automatic date & time' for network-provided time or set it manually.

5. OPERATING INSTRUCTIONS

5.1. Navigation

The M4B features a 4.0-inch IPS full touchscreen for intuitive navigation. Swipe left or right to browse through app pages. Tap on app icons to open them. Use the on-screen navigation buttons (Back, Home, Recent Apps) at the bottom of the screen.

5.2. Music Playback

The device supports various music formats including MP3, WAV, FLAC, APE, OGG, M4A, AAC, WMA, MP2. You can organize and play music by Title, Folder, Artist, Album, etc. Use the pre-installed music apps like Spotify, Amazon Music, or HiBy Music.



Image: The MP3 player displaying various music playback options and supported formats.

5.3. Video Playback & E-book Reading

The 4.0-inch IPS display is suitable for watching videos and reading e-books. Use the dedicated Video and E-book applications to access your media files.

5.4. Other Applications

The device includes other useful applications such as FM Radio, a Clock, a Calculator for school or daily use, and a File Manager to browse and organize your stored content.

6. PARENTAL CONTROLS

The M4B features a robust parental control system to manage your child's usage and access to applications.

- **Application Blocking:** All applications can be blocked or unblocked as needed.
- **New Application Installation Approval:** New app installations require parental approval.
- **Auto ON/OFF Time:** Set specific times for the device to automatically turn on or off, controlling screen time.

Your browser does not support the video tag. This video demonstrates the parental management system of the Luoran M4B MP3 player, showing how to enable or disable applications and control installation settings.

Video: Kids MP3 player with parental management system.

Important: Please be sure to write down and remember any password or PIN codes you set for parental controls, as you will not be able to access the device without them.

7. CONNECTIVITY

7.1. Bluetooth

The player comes with Bluetooth, compatible with a wide variety of Bluetooth devices such as earphones, headphones, speakers, and car stereos. It provides fast pairing and stable connections.

Metal Frame & Tempered Glass Back

**4.0
inch**

IPS display with full touchscreen




Image: The MP3 player demonstrating its Bluetooth connectivity with wireless headphones.

7.2. Wi-Fi

Built-in Wi-Fi allows for internet access, enabling streaming from pre-installed apps and downloading content.

8. STORAGE

8.1. Expandable Memory

This digital audio player provides a Micro SD card slot, allowing you to expand external storage up to 256GB. It is compatible with SDXC and SDHC cards, greatly satisfying your need to store more songs, videos, and audiobooks.

Expandable Memory

Supports maximum 256GB micro SD card



Image: The MP3 player with a Micro SD card being inserted into its dedicated slot.

9. BATTERY LIFE & CHARGING

The M4B MP3 Player is equipped with a built-in 1500mAh capacity battery and a USB-C charging port. A full charge takes approximately 2 hours and provides up to 50 hours of music playing time. The device also features a standby power-saving feature to extend battery life.

10. TROUBLESHOOTING

10.1. Missing or Upgrading Apps

If you encounter issues with missing applications or need to upgrade existing ones, please contact the Luoran Team. They will provide you with the necessary APK files and easy-to-follow installation steps. Expect a reply within 12 hours.

10.2. Forgotten Password/PIN

It is crucial to write down and remember any password or PIN codes you set for the device, especially for parental controls. If forgotten, you may not be able to access certain features or the device itself.

10.3. Device Not Responding/Freezing

If the device becomes unresponsive, press and hold the Power button for approximately 10-15 seconds to force a restart. If the issue persists, ensure the battery is charged.

10.4. Connectivity Issues

If experiencing issues with Bluetooth or Wi-Fi, try toggling the respective settings off and on. Ensure the device is within range of the network or Bluetooth accessory. For persistent Wi-Fi issues, try restarting your router.

11. SPECIFICATIONS

Feature	Detail
Product Dimensions	4.06 x 2.4 x 0.39 inches
Item Weight	5.3 ounces
Manufacturer	Luoran
ASIN	B0BNB85SJV
Item Model Number	M4B
Batteries	1 Lithium Metal batteries required (included)
Date First Available	August 17, 2021
Model Name	M4B
Special Feature	Parental Control System (Control New Installation, Set Auto ON/OFF Time, Block and Unblock Applications)
Connectivity Technology	Bluetooth, Wi-Fi, Aux
Memory Storage Capacity	8 GB (Expandable up to 256GB)
Color	Black
Screen Size	4 Inches
Compatible Devices	Earphone, Speaker
Media Type	Micro SDHC, Micro SDXC, Micro SD

12. SUPPORT

For any questions, technical support, or assistance with your Luoran M4B MP3 Player, please contact the Luoran Team directly. They are available to help with app installations, troubleshooting, and general inquiries. Visit the official Luoran Store for more information and products:[Luoran Store on Amazon](#)

