Rattaner B0BNBCYSMB

Rattaner 45-Inch 60000 BTU Steel Gas Fire Table User Manual

Model: B0BNBCYSMB

Important Safety Information

WARNING: Failure to follow these instructions could result in fire, explosion, or carbon monoxide poisoning, which could cause property damage, personal injury, or death.

- Always follow the safety instructions provided with the product.
- Allow the fire pit to cool down before covering it.
- Keep a safe distance from the fire pit while in use.
- Do not use flammable liquids to start or accelerate the fire.
- Never leave the fire pit unattended.
- Store the fire pit in a cool, dry place when not in use.
- For outdoor use only. Do not use indoors or in an enclosed area.
- Ensure proper ventilation.
- Keep children and pets away from the fire table.
- Do not store propane tanks indoors.

Product Overview

The Rattaner 45-Inch Steel Gas Fire Table (Model B0BNBCYSMB) is designed for outdoor use, providing 60000 BTU of heat. It features a durable steel construction with a woodgrain marble tabletop, a glass wind guard, and blue crystal beads for aesthetic appeal. This versatile unit can function as both a fire pit and a coffee table when the fire lid is in place.



Figure 1: Rattaner 45-Inch Fire Table in operation, showcasing the flames, glass wind guard, and blue crystal beads.

Key Features:

- **Heat Output:** 60000 BTU, suitable for outdoor gatherings.
- **Durable Construction:** Steel frame with woodgrain marble tabletop and embossed rattan-look panels.
- **Safety Features:** Includes a glass wind guard and a protective cover.
- **Multi-purpose Design:** Functions as a fire table or a coffee table with the lid on.
- **Easy Assembly:** Designed for straightforward assembly with included hardware.



Figure 2: Detailed view of the fire table's components, including the glass wind guard, woodgrain marble tiles, blue crystal glass beads, and stainless steel burner.

Setup and Assembly

The Rattaner Fire Table is packaged in one box and includes all necessary hardware for assembly. Follow the detailed instructions provided in the packaging for a smooth setup. It is recommended to assemble the unit on a soft, non-abrasive surface to prevent scratches.

1. Unpack all components and verify against the parts list in your manual.
2. Assemble the main frame of the fire table according to the diagrams.
3. Install the burner assembly into the tabletop.
4. Place the blue crystal glass beads around the burner.
5. Connect the LP gas regulator hose to a standard 20lb propane tank (not included). Ensure all connections are tight.
6. Carefully place the propane tank inside the designated compartment and secure it.

7. Install the glass wind guard around the burner area.



Figure 3: Components of the fire table, illustrating the assembly process.



Figure 4: Proper connection of the propane tank to the fire table, showing the LP Gas Regulator and Pulse Ignition Device.

Operating Instructions

Lighting the Fire Table:

1. Ensure the propane tank valve is open.
2. Push and turn the control knob to the "HIGH" position.
3. Hold the electronic ignitor button for 45 seconds to light the burner.
4. If the burner does not light, release the control knob, wait 5 minutes, and repeat the lighting procedure.
5. Once lit, adjust the flame to your desired height using the control knob (LOW to HIGH).

Turning Off the Fire Table:

1. Turn the control knob to the "OFF" position.
2. Close the valve on the propane tank.

3. Allow the unit to cool completely before covering or storing.

Your browser does not support the video tag.

Video 1: Demonstration of the Rattaner fire table ignition and flame adjustment. This video shows the ease of use for lighting and controlling the fire.

Maintenance

- **Cleaning:** Regularly clean the exterior surfaces with a soft cloth and mild soap. Avoid abrasive cleaners.
- **Burner Maintenance:** Ensure the burner ports are clear of debris. Use a soft brush to clean if necessary.
- **Storage:** When not in use, especially during off-seasons or inclement weather, cover the fire table with the included protective cover. Store the fire table in a cool, dry place.
- **Inspection:** Periodically check all gas connections and hoses for leaks or damage.



Figure 5: The fire table with its protective cover, demonstrating proper storage to extend product life.

Troubleshooting

Problem	Possible Cause	Solution
Burner does not light.	Propane tank valve closed, low propane, ignitor issue, clogged burner ports.	Open tank valve, check propane level, replace ignitor battery (AAA), clean burner ports.
Low flame or inconsistent flame.	Low propane, regulator issue, clogged burner ports.	Check propane level, ensure regulator is fully open, clean burner ports.
Gas smell.	Gas leak.	Immediately turn off gas supply. Check all connections for leaks using soapy water. Do not operate if leak persists. Contact qualified service personnel.

Specifications

Model: B0BNBCYSMB

Brand: Rattaner

Material: Metal

Product Dimensions: 24"D x 45"W x 25"H

Item Weight: 95 Pounds

Fuel Type: Liquefied Petroleum Gas (Propane)

Heat Output: 60000 BTU

Color: Black, Blue (for beads)

Style: Modern

Tabletop: Woodgrain Marble Tile

Warranty and Support

For warranty information, please refer to the documentation included with your product or contact Rattaner customer support. If you encounter any issues or require assistance, please reach out to the seller for prompt and effective solutions, including replacement or return & refund options as per their policy.
Seller: Rattan artisan

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question