

[Manuals.plus](#) /

> [JISULIFE](#) /

> JISULIFE Handheld Mini Lash Fan FA49 User Manual

JISULIFE FA49

JISULIFE Handheld Mini Lash Fan User Manual

Model: FA49

1. INTRODUCTION

Thank you for choosing the JISULIFE Handheld Mini Lash Fan. This compact and portable fan is designed to provide personal cooling with its ultra-slim design, three-speed settings, and rechargeable battery. Please read this manual carefully before use to ensure proper operation and maintenance.



Image 1.1: The JISULIFE Handheld Mini Lash Fan (Model FA49) in beige, demonstrating its compact form factor

and directed airflow.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- JISULIFE Handheld Mini Lash Fan (FA49)
- Long Lanyard
- USB Type-C Charging Cable
- User Manual




Image 2.1: Illustration of the items included in the product package.

3. PRODUCT FEATURES

- **Ultra-Slim Design:** Simple and stylish, easy to carry.
- **Innovative Five-Blade Fan:** Provides strong airflow with improved efficiency.
- **Three Wind Speeds:** Adjustable settings for various cooling needs.
- **Low Noise Operation:** Designed for quiet use.
- **Small and Portable:** Weighs only 104g, includes a lanyard for hands-free use.
- **Integrated Bracket:** Converts into a desktop fan.
- **Rechargeable Battery:** Built-in 2000mAh battery with Type-C charging.
- **Security Lock:** Prevents accidental activation.

Innovative Five-Blade Fan Powerful Airflow

FA49 30% Airflow Improvement, 50% Wind Power Increase



Max.Speed
6000 r/min

Max.Wind Speed
3.7 m/s

Max.Airflow
92 m³/h

Image 3.1: Illustration of the innovative five-blade fan design and its performance metrics.

Ultra Slim And Light Design High Quality PC Material

The body is made of PC, wear-resistant
and durable without odor



Image 3.2: The fan's ultra-slim and lightweight construction, weighing approximately 104 grams.

Low Noise Operation More Comfortable with Each Blowing



Image 3.3: The fan operates with low noise, comparable to whispering at its lowest setting.



Image 3.4: The lanyard design allows for hands-free use, making it convenient for various activities.

4. SETUP

4.1 Initial Charge

Before first use, fully charge the fan. Refer to the 'Charging Instructions' section for details.

4.2 Security Lock

The fan features a security lock to prevent accidental activation. Locate the small switch on the side of the fan. To enable operation, slide the switch to the "ON" position. To disable, slide it to the "OFF" position.




Image 4.1: Location of the security lock switch and power button on the fan.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off and Speed Adjustment

1. Ensure the security lock is in the "ON" position.
2. Press the power button once to turn on the fan at Speed 1 (Gentle Breeze).
3. Press the power button a second time for Speed 2 (Cool Breeze).
4. Press the power button a third time for Speed 3 (Powerful Wind).
5. Press the power button a fourth time to turn off the fan.

3 Wind Speeds

Adjust as you like



Image 5.1: The fan offers three adjustable wind speeds with varying battery life.

5.2 Using the Integrated Bracket

The fan features a rear bracket that allows it to be used as a desktop fan. Simply extend the bracket from the back of the fan to prop it up on a flat surface.



Image 5.2: The fan's convenience bracket allows for instant conversion to a desktop fan.

5.3 Usage Scenarios

The fan is versatile and can be used in various ways:

- **Handheld:** For direct personal cooling.
- **Desktop:** Use the integrated bracket to place it on a table or desk.
- **Wearable:** Attach the long lanyard to wear it around your neck.

Handheld / Desktop / Takeaway

Easy to achieve multiple needs



Image 5.3: The fan can be used handheld, on a desktop, or worn around the neck for convenience.

6. CHARGING INSTRUCTIONS

The JISULIFE Handheld Mini Lash Fan is equipped with a built-in 2000mAh rechargeable battery and a Type-C charging port.

1. Connect the provided USB Type-C charging cable to the fan's charging port.
2. Connect the other end of the cable to a compatible USB power source (e.g., wall charger, power bank, laptop, car charger).
3. The charging indicator light will illuminate during charging.
4. A full charge typically takes approximately 3-4 hours.

Built-in 2000mAh Rechargeable Battery

Small in size, big in power



Image 6.1: The fan features a built-in 2000mAh rechargeable battery, charged via Type-C port.



Image 6.2: The Type-C charge port is located on the side of the fan for convenient charging.

7. MAINTENANCE

7.1 Cleaning

- Ensure the fan is turned off and disconnected from any power source before cleaning.
- Wipe the exterior of the fan with a soft, dry cloth.

- Do not use abrasive cleaners, solvents, or immerse the fan in water.

7.2 Storage

- Store the fan in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery periodically to maintain its health.

8. TROUBLESHOOTING

8.1 Fan Does Not Turn On

- **Check Security Lock:** Ensure the security lock switch is in the "ON" position.
- **Battery Level:** The battery may be depleted. Connect the fan to a power source and charge it.
- **Power Button:** Ensure the power button is pressed firmly.

8.2 Weak Airflow

- **Speed Setting:** Increase the fan speed by pressing the power button.
- **Obstructions:** Check if anything is blocking the fan blades or air intake/outlet.
- **Battery Level:** A low battery can result in reduced performance. Charge the fan.

8.3 Fan Not Charging

- **Cable Connection:** Ensure the USB Type-C cable is securely connected to both the fan and the power source.
- **Power Source:** Verify that the USB power source is functional. Try a different port or adapter.
- **Cable Damage:** Inspect the charging cable for any signs of damage. Try a different Type-C cable if available.

9. SPECIFICATIONS

| Feature | Specification |
|---------------------|--|
| Brand | JISULIFE |
| Model Name | FA49 |
| Color | Beige |
| Electric Fan Design | Wearable Fan |
| Power Source | Battery Powered |
| Product Dimensions | 3.07"D x 0.8"W x 5.2"H (7.8 x 2.1 x 13.2 cm) |
| Item Weight | 3.46 ounces (98 Grams) |

| | |
|---------------------------|---|
| Special Feature | Portable, Lash Fan |
| Wattage | 2000 milliamp_hours (Battery Capacity) |
| Voltage | 5 Volts |
| Switch Type | Push Button |
| Included Components | Long lanyard, rear bracket, ultra-slim design, five-blade fan |
| Indoor/Outdoor Usage | Outdoor |
| Control Method | Touch (referring to button press) |
| Is Cordless? | Yes |
| Number of Power Levels | 3 |
| Main Power Connector Type | USB Type C |
| Batteries Required | 1 Lithium Ion battery (included) |

10. WARRANTY AND SUPPORT

For warranty information or technical support, please contact JISULIFE customer service through their official website or the retailer where the product was purchased. Please retain your proof of purchase for warranty claims.