Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HNARL 52631GT

Z-45 Decal Platform Control Panel Instruction Manual

Model: 52631GT | Brand: HNARL

Product Overview

This document provides essential information for the installation, use, and maintenance of the HNARL 52631GT Z-45 Decal Platform Control Panel. This decal is designed as a replacement part for Genie Boom Lift models Z-45-25, Z-45-25J, Z-45/25, and Z-45/25J (DC and Bi-Energy versions).

The decal serves to clearly label the functions of the control panel, ensuring proper operation and safety. It is a durable, waterproof decal designed for outdoor usage.



Image Description: A rectangular black decal with various white and yellow symbols and text, representing the layout of a boom lift control panel. Key labels visible include "AUXILIARY POWER", "DRIVE ENABLE OPERATION", and various boom function indicators. This image shows the primary side of the decal that faces the user.

Setup and Installation

Proper installation of the decal ensures its longevity and adherence. Follow these steps carefully:

1. **Prepare the Surface:** Ensure the control panel surface where the decal will be applied is clean, dry, and free of any grease, dust, or old adhesive residue. Use a suitable cleaner and allow the surface to dry completely.
2. **Align the Decal:** Carefully position the decal over the control panel to ensure correct alignment with buttons, switches,

and indicators. Do not remove the backing yet.

3. **Apply the Decal:** Slowly peel off the 3M adhesive backing from one end of the decal. As you peel, firmly press the decal onto the control panel surface, working from one end to the other to avoid air bubbles. Use a squeegee or a soft cloth to smooth out any bubbles.
4. **Secure Adhesion:** Once applied, press firmly over the entire surface of the decal to ensure maximum adhesion. Allow sufficient time for the adhesive to bond before exposing the panel to harsh conditions.



Image Description: The reverse side of the black decal, clearly showing the white 3M adhesive backing with repeated "3M" logos. This view highlights the adhesive layer that needs to be removed during installation.

Operating Instructions (Decal Function)

While the decal itself does not operate, it is an integral part of the boom lift's control system, providing clear visual cues for operators. The decal labels correspond to specific functions of the Genie Boom Lift Z-45 series.

- **Function Identification:** Each symbol and text label on the decal indicates a specific control or function, such as "AUXILIARY POWER", "HORN", "ENGINE START", "GLOW PLUG", and various boom movement controls (e.g., "JIB BOOM UP/DOWN", "PLATFORM ROTATE", "PRIMARY BOOM EXTEND/RETRACT").
- **Drive Enable Operation:** A prominent yellow section on the decal highlights the "DRIVE ENABLE OPERATION" instructions, which are crucial for safe movement of the boom lift. This section typically requires the operator to hold down a specific button while operating drive functions.
- **Directional Indicators:** Arrows and symbols clearly indicate the direction of movement for various boom and platform functions, as well as steering.
- **Emergency Stop:** The decal includes a designated area for the "EMERGENCY STOP" button, emphasizing its critical safety role.



Image Description: An angled perspective of the black control panel decal, providing a clearer view of the individual function labels and symbols. This includes details for boom functions, engine controls, and the "DRIVE ENABLE OPERATION" warning.

Maintenance

To ensure the decal remains legible and adheres properly over time, follow these maintenance guidelines:

- **Cleaning:** Clean the decal regularly with a soft cloth and mild soap and water. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the decal's surface or fade the printing.
- **Inspection:** Periodically inspect the decal for any signs of peeling, bubbling, or damage. Address any issues promptly to prevent further deterioration.
- **Protection:** While the decal is waterproof and designed for outdoor use, prolonged exposure to extreme weather conditions (e.g., intense UV radiation, freezing temperatures) can eventually affect its lifespan.

Troubleshooting

If you encounter issues with your decal, consider the following:

- **Decal Not Sticking Properly:**

- Ensure the surface was thoroughly cleaned and dry before application.
- Verify that the adhesive backing was fully removed.
- Apply firm, even pressure across the entire decal during installation.
- Temperature during application might be too low; apply in moderate temperatures if possible.

- **Bubbles Under the Decal:**
  - Small bubbles can often be smoothed out by gently pressing them towards the edge with a soft cloth or squeegee.
  - For stubborn bubbles, a very fine needle can be used to prick a tiny hole at the edge of the bubble to release air, then press down.
- **Fading or Damage:**
  - This typically indicates wear and tear over time due to environmental exposure. Replacement may be necessary.

Specifications

Attribute	Detail
Part Name	Z-45 DECAL
Part Number	52631GT
Application	Genie Boom Lift Z-45-25, Z-45-25J, Z-45/25, Z-45/25J (DC and Bi-Energy)
Description	DECAL, PLATFORM CTRL PANL, BI/DC
Brand	HNARL
Color	Black
Special Feature	Waterproof
Reusability	Single Use
Item Form	Rectangular
Indoor/Outdoor Usage	Outdoor
Package Dimensions	26.77 x 9 x 0.04 inches
Item Weight	1.76 ounces
Country of Origin	China

Warranty and Support

HNARL is committed to providing 100% satisfaction with your purchase. If you encounter any problems or have questions regarding the Z-45 Decal Platform Control Panel 52631GT, please do not hesitate to contact us.
We aim to resolve any issues within 24 hours of your inquiry. For support, please refer to the contact information provided at the point of purchase or on the official HNARL store page.
This product is intended as a replacement part and should be installed by qualified personnel if you are unsure about the process.

© 2024 HNARL. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BNG1H1PF

More documents and user manuals: **https://manuals.plus/**