

[Manuals.plus](#) /

› [QUECHUA](#) /

› Quechua MH100 Ultra Fresh 3-Person Camping Tent Instruction Manual

QUECHUA MH100

Quechua MH100 Ultra Fresh 3-Person Camping Tent Instruction Manual

Brand: QUECHUA | Model: MH100

INTRODUCTION

This manual provides essential information for the proper setup, use, maintenance, and care of your Quechua MH100 Ultra Fresh 3-person camping tent. Designed for warm summer conditions, this tent offers easy installation, excellent ventilation, and two access doors. Please read these instructions carefully before using your tent to ensure a safe and enjoyable camping experience.



Image: The Quechua MH100 Ultra Fresh 3-person camping tent, showing its overall structure and design.

SAFETY INFORMATION

- **Fire Safety:** Keep all flame and heat sources away from the tent fabric. The tent is made of flammable material and will burn if exposed to an open flame.
- **Ventilation:** Ensure adequate ventilation, especially when using cooking equipment or heaters inside the tent. Never use fuel-burning appliances inside the tent without proper ventilation.
- **Site Selection:** Choose a flat, clear area for pitching your tent, away from potential hazards like falling rocks, dead trees, or flood-prone areas.
- **Weather Conditions:** While the tent is waterproof, extreme weather conditions (heavy storms, strong winds) may require additional precautions or seeking alternative shelter.
- **Children:** Supervise children around the tent to prevent accidents.

PACKAGE CONTENTS

Before setup, verify that all components are present:

- Tent body (inner tent and flysheet)
- Tent poles (fiberglass)
- Tent stakes/pegs
- Guylines
- Carry bag



Image: The Quechua MH100 tent packed in its carry bag, showing its compact dimensions (57 cm length, 15 cm width).

SETUP INSTRUCTIONS

The Quechua MH100 tent is designed for quick and easy pitching, typically taking around 10 minutes.

1. **Unpack:** Remove the tent and all components from the carry bag. Lay the inner tent flat on your chosen campsite.

2. **Assemble Poles:** Connect the fiberglass pole sections. The tent uses a simple dome structure with two main poles.
3. **Insert Poles:** Slide the assembled poles through the sleeves on the inner tent. Ensure they cross at the top.
4. **Secure Poles:** Insert the ends of the poles into the grommets or pins located at the corners of the inner tent. This will raise the tent structure.
5. **Attach Flysheet:** Drape the flysheet over the inner tent, aligning the doors and vents. Secure the flysheet to the inner tent structure using the clips or buckles provided at the corners.
6. **Stake Down:** Use the tent stakes to secure the corners of the tent body and the flysheet to the ground. Ensure the tent is taut to prevent flapping in the wind and to allow proper water runoff.
7. **Attach Guylines:** Extend and stake out the guylines for added stability, especially in windy conditions. Adjust tension as needed.



Image: The Quechua MH100 tent fully pitched with its flysheet, ready for use.

OPERATING (USAGE)

- **Ventilation:** The MH100 features an "Ultra Fresh" design for optimal airflow. Utilize the two doors and any integrated vents to maximize air circulation and minimize condensation, especially during warm weather.
- **Doors:** The tent has two doors for convenient entry and exit. Use the zippers carefully to avoid snagging the fabric. Roll up and secure the door flaps when open to prevent them from obstructing the entrance.
- **Storage Pockets:** Use any internal pockets for organizing small items.
- **Weather Protection:** Ensure the flysheet is properly tensioned and all zippers are closed during rain to maintain waterproof integrity.

MAINTENANCE

- **Cleaning:** Clean the tent with a sponge and soapy water. Do not use harsh detergents or a washing machine, as this can damage the waterproof coating. Rinse thoroughly.
- **Drying:** Always ensure the tent is completely dry before packing it away. Packing a damp tent can lead to mildew, odors, and damage to the fabric and coatings. Air dry in a shaded, well-ventilated area.


- **Storage:** Store the clean, dry tent in its carry bag in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Pole Care:** Inspect poles for damage before and after each use. If a pole breaks, repair kits are often available.
- **Stakes/Guylines:** Clean stakes and guylines. Replace any bent stakes or frayed guylines.

TROUBLESHOOTING

- **Condensation:** Condensation is natural. Maximize ventilation by opening vents and doors (when weather permits). Ensure the tent is pitched in a well-ventilated spot.
- **Water Leaks:** Check if the flysheet is properly tensioned and covering the inner tent. Ensure all zippers are fully closed. Small leaks might be repaired with seam sealer.
- **Difficulty Pitching:** Ensure poles are fully assembled and inserted correctly into grommets/sleeves. Check for obstructions on the ground.
- **Tent Not Stable:** Ensure all stakes are firmly in the ground and guylines are properly tensioned and secured. Reposition if necessary.

SPECIFICATIONS

Feature	Detail
Model	MH100 Ultra Fresh
Capacity	3 Persons
Dimensions (L x W x H)	2.1 m x 2.1 m x 1.05 m (Inner tent floor: 210 cm x 210 cm)
Maximum Height	120 cm
Packed Dimensions	57 cm x 15 cm (approx.)
Weight	4.1 kg
Setup Time	10 Minutes
Number of Doors	2
Flysheet Material	100% Polyester with waterproof coating
Inner Tent Material	Polyester
Groundsheet Material	Polyethylene
Pole Material	Glass-reinforced plastic (Fiberglass)
Water Resistance	Waterproof
Special Features	Thermal shield, Easy transport, Blackout features



4,1 kg | 9lb 0,6oz

5 Ans
Years | Garantie
Warranty

Image: Diagram illustrating the internal dimensions (210 cm x 210 cm floor, 120 cm height) and 3-person capacity of the Quechua MH100 tent.

WARRANTY AND SUPPORT

This Quechua MH100 Ultra Fresh tent comes with a **2-year manufacturer's warranty**, covering defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

For product support, spare parts, or warranty inquiries, please contact your retailer or visit the official QUECHUA website. You can find more information and contact details at [Decathlon.fr](https://www.decathlon.fr) (as Quechua is a Decathlon brand).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question