

LUCK4U 10x2.7-6.5 Solid Scooter Tire

LUCK4U 10x2.7-6.5 Solid Scooter Tire Instruction Manual

Model: 10x2.7-6.5 Solid Scooter Tire

1. PRODUCT OVERVIEW

The LUCK4U 10x2.7-6.5 Solid Scooter Tire is a durable, maintenance-free replacement tire designed for various electric scooters. Constructed from high-quality rubber, this solid tire eliminates the need for inflation and provides enhanced resistance against punctures and explosions, ensuring a consistent riding experience.



Image 1.1: Overview of the LUCK4U 10x2.7-6.5 Solid Scooter Tire, highlighting its dimensions and compatibility with various electric scooter models.

2. KEY FEATURES

- **High-Quality Rubber Construction:** Made from premium rubber for improved grip, durability, wear resistance, compression resistance, and explosion-proof performance.
- **Maintenance-Free:** Requires no inflation or ongoing maintenance, offering a hassle-free solution for scooter owners.
- **Puncture and Explosion Proof:** Designed to withstand various road conditions without the risk of flats.
- **Enhanced Stability:** Wider and thicker design compared to ordinary solid tires, contributing to better cushioning and reduced vibration during rides.

Wide range of applicable models

- ✓ Gotrax G4
- ✓ Hiboy max3
- ✓ Other electric scooters with 70/65-6.5 tires
- ✓ Hover-1 Alpha
- ✓ Boyueda 5600 watt
- ✓ Evercross H5
- ✓ Emove Cruiser



Image 2.1: Comparison illustrating the robust construction of the LUCK4U solid tire against other types, emphasizing its high-quality rubber and resistance to damage.

3. COMPATIBILITY

This solid scooter tire is compatible with a range of electric scooter models that use 70/65-6.5 tires. Known compatible models include:

- Hover-1 Alpha
- Evercross H5
- Boyueda 5600 watt
- Emove Cruiser
- Hiboy Max3
- Kugoo M4 Pro
- Zero 10x
- Dualtron
- Gotrax G4

Please verify your scooter's current tire size (10x2.7-6.5 or 70/65-6.5) to ensure proper fitment.

4. WHAT'S IN THE BOX

Your package includes:

- 1 x LUCK4U 10x2.7-6.5 Solid Scooter Tire

5. INSTALLATION INSTRUCTIONS

Installing a solid tire requires specific steps to ensure a secure fit. Please follow these instructions carefully. Two people are recommended for installation.

1. **Step 1: Heat the Tire.** Place the solid tire into boiling water for approximately 20 minutes. This process softens the rubber, making it more pliable for installation.
2. **Step 2: Lubricate the Tire.** After heating, carefully remove the tire from the boiling water. Apply soapy water or Vaseline to the inside of the tire. *Do not use gasoline or lubricating oil, as these can damage the tire material.*
3. **Step 3: Mount the Tire.** Position one side of the tire onto the scooter's wheel hub. With assistance, firmly step on this side to begin seating the tire. Gradually work the rest of the tire onto the rim, using appropriate tools if necessary, ensuring not to damage the tire or rim.
4. **Step 4: Final Adjustments.** Once the tire is mostly on the rim, make minor adjustments to ensure it is fully and evenly seated around the entire hub.

Installation Steps



Step 1: Boil the solid tires in boiling water for 20 minutes.



Step 2: Cover the inside of the tire with soapy water or Vaseline (Please avoid using the gasoline or lubricating oil, otherwise the tire will be damaged).



Step 3: Place either side of the hub on the tire and step on this side (Two people are recommended for installation).



Step 4: After some minor tweaking, the installation is complete.

Image 5.1: Visual guide detailing the four steps for installing the solid scooter tire, including heating, lubrication, mounting, and final adjustments.

Your browser does not support the video tag.

Video 5.1: This video demonstrates the physical characteristics and dimensions of the LUCK4U 10x2.7-6.5 Solid Scooter Tire, providing a visual reference for its size and tread pattern.

6. MAINTENANCE

One of the primary advantages of the LUCK4U Solid Scooter Tire is its minimal maintenance requirement. Unlike pneumatic tires, it does not require inflation, puncture repairs, or regular pressure checks. Simply ensure the tire is free from debris and inspect it periodically for any signs of wear or damage.

Luck4U Off-Road Solid Tire


The Luck4U off-road solid tire has anti-skid pattern design, which is suitable for various road conditions.



Stone Pavement Road



Mud Road



Raining Road



Uneven & Irregular Road

Image 6.1: Illustration highlighting that the solid tire requires no maintenance or inflation, simplifying scooter upkeep.

7. SPECIFICATIONS

Specification	Detail
Brand	LUCK4U
Model Number	US-10*2.7-6.5 Solid Scooter Tire
Tire Size	10x2.7-6.5 inches (70/65-6.5)
Construction Type	Solid Rubber
Tire Diameter	10 inches (236mm)
Rim Width	2.7 inches (75.8mm)
Inner Diameter	151mm
Inner Width	54.3mm
Item Weight	1.5 kg
Tread Type	Directional
Seasons	Year Round

No Maintenance Required

No Need To Inflate

Solid tires can be used directly after installation without inflation, No need to do any maintenance on the tires during the ride. Specially designed for electric scooters, longer life and more durable.



No maintenance
required



No need
to inflate



Stone Pavement
Road



Mud Road



Uneven &
Irregular Road



Raining Road

Image 7.1: Detailed diagram showing the key dimensions of the LUCK4U 10x2.7-6.5 Solid Scooter Tire.

8. TROUBLESHOOTING

- **Difficulty during installation:** Ensure the tire has been heated sufficiently in boiling water (at least 20 minutes) and that ample soapy water or Vaseline has been applied for lubrication. Installation often requires significant force and is easier with two people.
- **Tire does not fit:** Double-check the tire size markings on your scooter's original tire and compare them with the 10x2.7-6.5 (70/65-6.5) specification of this product. Incompatibility can occur if the sizes do not match precisely.
- **Reduced range or acceleration:** Solid tires are generally heavier than pneumatic tires, which can slightly impact the scooter's range and acceleration. This is a characteristic of solid tires and not a defect.

9. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your LUCK4U 10x2.7-6.5 Solid Scooter Tire, please contact LUCK4U customer service through the retailer where the product was purchased. Please retain your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BNHNJV7Z>

More documents and user manuals: <https://manuals.plus/>