

AIPER Seagull Plus

AIPER Seagull Plus Cordless Pool Vacuum

ROBOTIC POOL CLEANER INSTRUCTION MANUAL

1. Product Overview

The AIPER Seagull Plus is a 2023 upgraded cordless robotic pool cleaner designed for efficient and hassle-free maintenance of above-ground and in-ground flat-floored pools up to 60 feet. It features stronger power suction, an extended battery life of 110 minutes, and a convenient LED indicator for operational status.

- **Efficient Cleaning:** Cleans all types of debris from dirt to stones with powerful dual-drive motors.
- **Cordless & Easy to Use:** No extension cables or messy hoses. One-click activation for automatic cleaning.
- **Longer Battery Life:** 2.5 hours to fully charge, providing 110 minutes of cleaning.
- **Quick Water Release:** Sophisticated system drains water in seconds for easy retrieval.
- **LED Indicator:** 4-color LED indicator to monitor device status.

2. What's in the Box

Your AIPER Seagull Plus package includes the following components:

- AIPER Seagull Plus Robotic Pool Cleaner (x1)
- Power Adapter (x1)
- Retrieval Hook (x1)
- User Manual (x1)
- Brush (x1)
- Rotor (x1)



Image: The AIPER Seagull Plus robotic pool cleaner, a sleek gray unit with a handle, shown on a white background.

3. Setup Guide

Follow these steps to set up your AIPER Seagull Plus for first use:

1. **Fully Charge the Device:** Before first use, fully charge the device for 2.5 hours using the provided power adapter. The LED indicator will communicate the charging status.
2. **Prepare for Submersion:** Ensure the charging port is dry and securely plugged with its rubber cover before placing the device in water.
3. **Activate and Submerge:** Press the power button to turn on the device. Gently drop it into the pool, ensuring it is fully submerged. The device will automatically begin cleaning.

Video: A man demonstrates switching on the Seagull Plus and fully submerging it into a pool, showing its initial cleaning action.

Improved Charging Time To minimize your wait



2.5 hours



Charges in $\frac{1}{2}$ the time
*compared to the Seagull 1000

Image: The AIPER Seagull Plus charging on a wooden floor next to a wall outlet, indicating its 2.5-hour charging time.

4. Operating Instructions

The Seagull Plus operates automatically once submerged. It will clean the pool floor and can handle inclines up to 15 degrees. The device will stop cleaning and park itself near the pool wall when the battery is low.

- **LED Indicator Status:**

- Green: >90% battery
- Blue: 50-90% battery
- Yellow: 10-50% battery
- Red: <10% battery (device will stop and light will go off)

- **Retrieval:** To retrieve the device, press the power button to stop cleaning. The rapid water release system will drain water in seconds, making it easy to lift from the pool using the retrieval hook.

Video: Demonstrates how to use the Seagull Plus, including activation, submersion, cleaning, and retrieval from the pool.

Quick Water Release Easy to remove from the pool



Image: A person uses a pole with a hook to retrieve the AIPER Seagull Plus from the pool, showcasing its quick water release feature.

5. Maintenance

Regular maintenance ensures optimal performance and longevity of your pool cleaner:

- **Clean Filter Tray:** After each use, or as needed, remove the top shell and the filter tray. Rinse the filter tray thoroughly with a hose to remove collected debris.
- **Drying Charging Port:** Ensure the charging port is completely dry before charging the device to prevent rust and damage.
- **Saltwater Pool Cleaning:** If used in a saltwater pool, rinse the device with fresh water after each use to prevent corrosion.



Image: A person cleaning the filter tray of the AIPER Seagull Plus with a hose, showing accumulated debris.

6. Troubleshooting

If you encounter issues with your AIPER Seagull Plus, refer to the common problems and solutions below:

- **Device Not Holding Charge / Dies Mid-Cycle:**
 - Ensure the device is fully charged (2.5 hours) before each use.
 - Verify the charging port is dry and free of rust or debris.
 - Confirm the power adapter is functioning correctly.
- **Device Not Moving / Stuck:**
 - Check the filter tray for excessive debris that might be blocking the motor or suction.
 - Ensure the pool floor is flat; the Seagull Plus is designed for flat-bottomed pools and may struggle with steep inclines or large seams.
 - Verify the device is fully submerged and not floating.
- **LED Indicator Not Working:**
 - Ensure the device is properly connected to the charger or fully powered on.
 - If the device fails to charge, the light will be off.

7. Specifications

Feature	Detail
Brand	AIPER
Model Name	Seagull Plus
Product Dimensions	22.2"L x 16.1"W x 10.7"H

Item Weight	17.78 pounds
Power Source	Battery Powered
Battery Type	Lithium-Ion
Charging Time	2.5 Hours
Run Time	110 Minutes
Control Method	Remote
Special Feature	Cordless

8. Warranty and Support

The AIPER Seagull Plus comes with a 1-year warranty. For any product inquiries, troubleshooting assistance, or warranty claims, please contact AIPER customer service. Refer to the user manual for specific contact details or visit the official AIPER website for support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

