

[Manuals.plus](#) /

> [AUNA](#) /

> Auna Mary Ann Bluetooth Turntable System User Manual

## AUNA Mary Ann

# Auna Mary Ann Bluetooth Turntable System User Manual

Model: Mary Ann

## INTRODUCTION

---

Thank you for purchasing the Auna Mary Ann Bluetooth Turntable System. This versatile audio system combines vintage aesthetics with modern functionality, allowing you to enjoy your vinyl records, CDs, DAB+/FM radio, and digital music via USB or Bluetooth. This manual provides essential information for safe operation, setup, and maintenance of your device. Please read it thoroughly before use and keep it for future reference.

## SAFETY INSTRUCTIONS

---

- Read all instructions carefully before operating the device.
- Keep the manual for future reference.
- Do not expose the unit to rain, moisture, or direct sunlight.
- Ensure proper ventilation; do not block any ventilation openings.
- Place the unit on a stable, level surface.
- Use only attachments/accessories specified by the manufacturer.
- Unplug the unit during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.
- Avoid placing objects filled with liquids, such as vases, on the apparatus.
- Do not place naked flame sources, such as lighted candles, on the apparatus.

## PACKAGE CONTENTS

---

Carefully unpack the box and ensure all items are present and in good condition:

- 1 x Auna Mary Ann Turntable System with Integrated Speakers
- 1 x Power Adapter

- 1 x Remote Control
- 1 x 45 RPM Adapter
- 1 x User Manual (this document)

## PRODUCT OVERVIEW

---

The Auna Mary Ann system features a comprehensive set of controls and connections for various audio sources.



Front view of the Auna Mary Ann Turntable System, showing the main unit with integrated speakers, control panel, and LCD display.

### Key Features:

- **3-Speed Turntable:** Supports 33 1/3, 45, and 78 RPM records.
- **Integrated Stereo Speakers:** 24 Watts RMS for clear audio output.
- **Auto-Stop Function:** Automatically stops the platter when a record finishes, protecting your vinyl.
- **Multiple Playback Options:** CD player, DAB+/FM radio, USB input for MP3 playback, AUX-in, and Bluetooth

connectivity.

- **Digital Conversion:** Easily convert vinyl records to MP3 files via USB.
- **User-Friendly Controls:** Intuitive control panel with an LCD display and a multifunctional rotary knob.
- **Vintage Design:** Elegant wooden finish with a straight tonearm and magnetic cartridge.
- **Convertible Design:** Removable feet allow for standalone use or tabletop placement.

## SETUP

1. **Unpacking:** Carefully remove the turntable system from its packaging. Retain the packaging for future transport or storage.
2. **Placement:** Place the unit on a stable, level surface away from direct sunlight, heat sources, and excessive dust or vibrations. Ensure adequate space around the unit for ventilation.
3. **Feet Installation (Optional):** If you wish to use the system as a standalone unit, attach the provided feet to the designated points on the bottom of the main unit. Ensure they are securely fastened.

### LE SOUFFLE D'ANTAN AVEC UN DESIGN RÉTRO ET ÉLÉGANT



#### TÊTE DE LECTURE MAGNÉTIQUE

Pour une sécurité et une  
qualité sonore maximales



#### ÉLÉGANCE ET SOBRIÉTÉ

Bras de lecture au  
design rectiligne

Diagram showing the dimensions of the Auna Mary Ann Turntable System, illustrating its convertible design with and without the removable feet.

4. **Power Connection:** Connect the power adapter to the DC input port on the back of the unit, then plug the adapter into a suitable wall outlet.
5. **Antenna Connection:** For optimal DAB+/FM radio reception, ensure the FM antenna is properly extended.
6. **Dust Cover:** Remove any protective films or ties from the dust cover and ensure it can open and close smoothly.

## OPERATING INSTRUCTIONS

---

### General Operation:

- **Power On/Off:** Press the Power button on the front panel or remote control to turn the unit on or off.
- **Mode Selection:** Use the "Function" button on the unit or remote to switch between Phono (Vinyl), CD, DAB+, FM, USB, AUX, and Bluetooth modes.
- **Volume Control:** Adjust the volume using the rotary knob on the front panel or the Volume +/- buttons on the remote control.

### Playing Vinyl Records:

1. Select "Phono" mode.
2. Place a record on the platter. If playing a 45 RPM single, place the 45 RPM adapter on the spindle first.
3. Select the correct speed (33 1/3, 45, or 78 RPM) using the speed selector switch.
4. Release the tonearm lock.
5. Lift the tonearm using the cueing lever and position it over the desired track on the record.
6. Lower the tonearm gently onto the record using the cueing lever. The record will begin to play.
7. At the end of the record, the auto-stop function will stop the platter. Lift the tonearm, return it to its rest, and engage the lock.



**3 vitesses pour votre collection de disques**



**Connexion optimale : AUX-In**



**Un son puissant : 2 enceintes stéréo de 24 W max.**



**Auto-Stop : La sécurité pour vos disques**



**Joue les disques de format 7", 10" & 12".**



**Meilleur son : Tête de lecture en céramique**

Visual representation of key features including 3-speed playback, powerful stereo speakers, auto-stop function, and support for various record sizes.

## Playing CDs:

1. Select "CD" mode.
2. Press the Eject button to open the CD tray.
3. Place a CD with the label side facing up into the tray.
4. Press the Eject button again to close the tray. The CD will load and begin playing automatically.
5. Use the Play/Pause, Skip Forward/Backward buttons on the unit or remote to control playback.

## DAB+/FM Radio:

1. Select "DAB+" or "FM" mode.
2. For DAB+ radio, the system will automatically scan for available stations upon first use. Use the navigation buttons to browse and select stations.
3. For FM radio, use the tuning buttons to manually or automatically scan for stations.

4. You can save your favorite stations as presets for quick access. Refer to the display for specific instructions on saving presets.

### **Bluetooth Connectivity:**

1. Select "Bluetooth" mode. The display will show "BT" or "Pairing".
2. Enable Bluetooth on your external device (smartphone, tablet, etc.).
3. Search for "Auna Mary Ann" or a similar device name in your device's Bluetooth settings.
4. Select the device to pair. Once connected, you will hear a confirmation sound, and the display will indicate a successful connection.
5. Play music from your external device. Audio will stream through the turntable system's speakers.

### **USB Playback & Recording:**

1. Insert a USB flash drive into the USB port.
2. Select "USB" mode. The system will automatically detect and play compatible MP3 files.
3. **Recording Vinyl to USB:**
  - Ensure a USB drive is inserted.
  - Select "Phono" mode and start playing a vinyl record.
  - Press the "Record" button (usually indicated by a REC icon) on the unit. The display will show recording status.
  - Press the "Record" button again to stop recording. The recorded audio will be saved as an MP3 file on the USB drive.

# LECTURE ET NUMÉRISATION DES DISQUES



Enceintes  
stéréo :  
24 W  
max.



## GO DIGITAL

Conversion facile de  
disques vinyles en  
fichiers MP3



Image illustrating the "Go Digital" feature for converting vinyl to MP3 via USB, and the silent belt-drive mechanism for 33 1/3, 45, or 78 RPM playback.

## AUX-in:

1. Connect an external audio device (e.g., an older MP3 player) to the AUX-in port using a 3.5mm audio cable (not included).
2. Select "AUX" mode.
3. Play audio from your external device.

## MAINTENANCE

- **Cleaning the Unit:** Wipe the exterior of the unit with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents.
- **Cleaning the Stylus:** Gently clean the stylus regularly with a soft brush, brushing from back to front. Avoid touching the stylus with your fingers.
- **Cleaning Records:** Use a dedicated record cleaning brush and solution to keep your vinyl records free of dust and static.

- **Dust Cover:** Keep the dust cover closed when not in use to protect the turntable and stylus from dust.
- **Stylus Replacement:** The stylus has a limited lifespan (typically 300-500 hours of playback). If you notice a decrease in sound quality, replace the stylus. Contact Auna support for compatible replacement styli.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power adapter not connected; power outlet not active.	Ensure the power adapter is securely connected to the unit and a working power outlet.
No sound from speakers	Volume too low; incorrect mode selected; external speakers connected (if applicable).	Increase volume. Select the correct input mode. Disconnect external speakers if you want sound from internal speakers.
Turntable not spinning	Speed selector incorrect; tonearm not lifted; auto-stop engaged.	Check speed setting. Lift tonearm. Ensure auto-stop is not preventing rotation prematurely (though it should only stop at end of record).
Poor sound quality from vinyl	Dirty record; dirty or worn stylus; incorrect speed.	Clean the record. Clean or replace the stylus. Verify the correct speed setting.
Bluetooth not connecting	Device not in pairing mode; external device Bluetooth off; too far from unit.	Ensure the turntable is in Bluetooth pairing mode. Turn on Bluetooth on your external device and search for "Auna Mary Ann". Move closer to the unit.
CD not playing	CD inserted incorrectly; dirty or scratched CD; incorrect mode.	Ensure CD is inserted label-side up. Clean the CD. Select "CD" mode.

## SPECIFICATIONS

<b>Brand</b>	AUNA
<b>Model Name</b>	Mary Ann
<b>Turntable Speeds</b>	33 1/3, 45, 78 RPM
<b>Motor Type</b>	Belt-driven
<b>Connectivity Technology</b>	Bluetooth, USB, RCA (output, implied by HiFi system)
<b>Audio Output Power</b>	24 Watts RMS (integrated speakers)
<b>Power Consumption</b>	24 Watt
<b>Power Source</b>	Electric cable
<b>Compatible Devices</b>	Speaker, MP3 player, Personal computer, Smartphone, Tablet, Amplifier
<b>Material</b>	Wood
<b>Color</b>	Black
<b>Item Weight</b>	8.5 Kilograms
<b>Dimensions (L x W x H) with feet</b>	34 cm x 49 cm x 68.5 cm
<b>Dimensions (L x W x H) without feet</b>	34 cm x 49 cm x 25 cm

## WARRANTY AND SUPPORT

---

Auna products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Auna website.

Should you encounter any issues or require technical assistance, please contact Auna customer support. You can typically find contact information on the official Auna website or through your retailer. Please have your model name ("Mary Ann") and purchase details ready when contacting support.

**Online Support:** Visit the Auna brand store on Amazon or the official Auna website for FAQs and further assistance.

