



Manuals.plus /

› CHIQ /

› CHIQ CSD90D4D Vertical Freezer Instruction Manual

## CHIQ CSD90D4D

# CHIQ CSD90D4D Vertical Freezer Instruction Manual

Model: CSD90D4D | Brand: CHIQ

## INTRODUCTION

---

This manual provides comprehensive instructions for the safe and efficient use of your new CHIQ CSD90D4D Vertical Freezer. Please read all instructions carefully before installation and operation. Keep this manual for future reference.

## SAFETY INFORMATION

---

- Ensure the freezer is placed on a stable, level surface to prevent tipping.
- Do not block ventilation openings in the appliance enclosure or in the built-in structure.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Keep children away from packaging materials to avoid suffocation risk.
- Before cleaning or maintenance, always unplug the appliance from the power outlet.

## SETUP

---

### Unpacking and Placement

Remove all packaging materials. Place the freezer in a well-ventilated area, away from direct sunlight and heat sources. Ensure there is adequate space around the unit for air circulation. The freezer dimensions are approximately 54.9 cm (width) x 55.7 cm (depth) x 84.5 cm (height).

# El congelador ideal bajo la mesa



Image: The CHI Q CSD90D4D vertical freezer shown with its adjustable feet, an ice cube tray, and an ice scraper, highlighting its compact design suitable for under-counter placement.

## Leveling and Door Reversal

Adjust the leveling feet to ensure the freezer is stable and level. This model features a reversible door, allowing you to adjust its opening direction (left/right) to suit your space requirements. Refer to the detailed diagram for external dimensions.

# Bonitas dimensiones exteriores

Cajón corredizo x2 Cajón de solapas x1



Image: A diagram illustrating the exterior dimensions of the CHI Q CSD90D4D vertical freezer, showing its width (549mm), depth (557mm), and height (845mm).

## Initial Power-on

After placement, wait at least 4 hours before plugging in the appliance to allow the refrigerant gas to settle. Clean the interior before first use. Once plugged in, allow the freezer to run for 24 hours before loading food, especially if loading non-frozen items.

## OPERATING INSTRUCTIONS

---

### Temperature Control

The freezer is equipped with an adjustable thermostat, offering 4 settings to control the internal temperature. The recommended temperature range for optimal food preservation is  $-18^{\circ}\text{C}$  to  $-24^{\circ}\text{C}$ . Setting 4 provides the coldest temperature, while Setting 1 is less cold.

# Control de temperatura fácil



Ultracongelación: -24°C

Congelación suave: -18°C



Image: A visual guide to the easy temperature control dial, showing 4 available settings. It also indicates 'Ultracongelación' at -24°C and 'Congelación suave' at -18°C, with images of frozen fish, meat, and ice cream.

## Loading Food

The 85L capacity is efficiently organized with multiple layers and drawers, including two sliding drawers and one flap drawer, for easy storage and access. The 4-star freezing certification ensures rapid freezing to preserve food nutrients. Avoid overloading the freezer to maintain proper air circulation and freezing efficiency.

# Tamaño del producto



\* Las imágenes de los productos se proporcionan únicamente con fines ilustrativos y pueden diferir del producto real.

Image: An open CHI Q CSD90D4D freezer displaying its internal layout with three clear drawers. Dimensions for the drawers are indicated, showing a depth of 40cm, a height of 21cm for the bottom drawer, and a width of 39cm.

## MAINTENANCE

### Cleaning

Regularly clean the interior and exterior of your freezer. Use a soft cloth with a mild detergent and warm water. Do not use abrasive cleaners or sharp objects. Ensure the freezer is unplugged before cleaning.



Image: A detailed view of the CHI Q CSD90D4D freezer's interior, highlighting the transparent drawers and shelves, which can be removed for cleaning.

## Defrosting

This freezer requires manual defrosting. Frost buildup can reduce efficiency. Defrost when the frost layer reaches approximately 5mm. Remove all food, unplug the unit, and allow the frost to melt naturally. Use the provided ice scraper to gently remove ice, avoiding sharp tools.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Freezer not cooling	Power outage; plug not inserted correctly; temperature setting too high.	Check power supply; ensure plug is secure; adjust thermostat to a colder setting.
Excessive noise	Freezer not level; objects touching the back of the unit.	Adjust leveling feet; ensure nothing is touching the freezer.
Excessive frost buildup	Door not closed properly; frequent door opening; high humidity.	Ensure door seal is intact and door is closed tightly; reduce frequency of door opening; defrost the unit.

If problems persist after attempting these solutions, please contact customer support.

## SPECIFICATIONS

---

**Model Name:** CSD90D4D

**Brand:** CHiQ

**Type:** Vertical Freezer

**Capacity:** 85 Liters

**Energy Efficiency Class:** D

**Annual Energy Consumption:** 131 kWh/annum

**Noise Level:** 39 dB

**Dimensions (D x W x H):** 55.7 cm x 54.9 cm x 84.5 cm

**Product Weight:** 28 kg

**Voltage:** 220 Volts

**Door Material:** Stainless Steel

**Door Orientation:** Top (referring to the hinge position for reversal)

**Compliance:** CE certified



CHIQ

CSD90D4D




**131** kWh/annum



**85** L



**0** L



AB**C**D

2019/2016

Image: The official EU Energy Efficiency Label for the CHIQ CSD90D4D freezer, indicating its Class D rating, 85L capacity, and 39dB noise level. For more details, visit [eprel.ec.europa.eu/qr/1333520](http://eprel.ec.europa.eu/qr/1333520).

## WARRANTY AND SUPPORT

Your CHIQ CSD90D4D Vertical Freezer comes with a 3-year manufacturer's warranty. Additionally, the compressor is covered by a 12-year replacement warranty. For any inquiries, technical assistance, or warranty claims, please refer to the contact information provided with your purchase documentation or visit the official CHIQ brand store.

Official CHIQ Brand Store: CHIQ Store on Amazon