

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Kappesberg](#) /

› [Kappesberg Carol L780A Kitchen Cabinet Kit User Manual](#)

### Kappesberg L780A

# Kappesberg Carol L780A Kitchen Cabinet Kit User Manual

Model: L780A

## INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your Kappesberg Carol L780A Kitchen Cabinet Kit. Please read this manual carefully before beginning assembly or use to ensure proper installation and longevity of your product. Keep this manual for future reference.



Figure 1: Front view of the Kappesberg Carol L780A Kitchen Cabinet Kit, showcasing its design with eight doors and one drawer.

## SETUP AND ASSEMBLY

The Kappesberg Carol L780A Kitchen Cabinet Kit requires assembly. It is recommended to have at least two people for assembly. Ensure you have all components and tools listed in the packaging before starting. Follow the step-by-step instructions provided in the separate assembly guide included with your product. This section provides general guidance.

### Preparation:

- Unpack all components and verify against the parts list.
- Clear a spacious, clean, and level area for assembly.
- Gather necessary tools (e.g., screwdriver, hammer, measuring tape).

### Assembly Steps (General):

1. Assemble the base cabinets first, ensuring all connections are secure.
2. Attach the back panels to the assembled frames.
3. Install drawers and doors, adjusting hinges for proper alignment.

4. Mount upper cabinets securely to the wall, following local building codes and using appropriate fasteners for your wall type.
5. Install shelves and any additional accessories.



Figure 2: View of the internal structure and shelving layout, illustrating the components before doors and drawers are fully installed.



Figure 3: Dimensional diagram of the kitchen cabinet kit, showing overall height (210 cm), width (258 cm), and depth (52 cm).

## OPERATING INSTRUCTIONS

The Kappesberg Carol L780A Kitchen Cabinet Kit is designed for practical kitchen storage. Its eight doors and one drawer provide ample space for various kitchen items.

### Using Doors and Drawers:

- **Doors:** Open and close doors gently using the handles. Avoid slamming to prevent damage to hinges and cabinet structure.
- **Drawer:** The single drawer operates on smooth glides. Pull and push the drawer evenly to ensure smooth movement and prevent misalignment.
- **Shelves:** The two internal shelves are adjustable in some sections. Ensure items are distributed evenly to prevent overloading any single shelf.



Figure 4: The Kappesberg Carol L780A Kitchen Cabinet Kit integrated into a modern kitchen environment, demonstrating its functional use.

## MAINTENANCE

Proper maintenance will extend the life and appearance of your Kappesberg Carol L780A Kitchen Cabinet Kit.

### Cleaning:

- Wipe surfaces with a soft, damp cloth.
- For stubborn stains, use a mild, non-abrasive cleaner specifically designed for wood or laminate surfaces.
- Avoid harsh chemicals, abrasive pads, or excessive moisture, as these can damage the MDP (Medium Density Particleboard) and finish.
- Dry surfaces immediately after cleaning to prevent water damage.

### General Care:

- Periodically check all screws and fasteners for tightness and re-tighten if necessary.
- Avoid placing hot items directly on the cabinet surfaces without protection.
- Protect surfaces from sharp objects to prevent scratches.
- Ensure proper ventilation in the kitchen to prevent moisture buildup, which can affect the cabinet material.

## TROUBLESHOOTING

Here are solutions to common issues you might encounter with your kitchen cabinet kit.

| Problem                                 | Possible Cause                                    | Solution  |
|---|---|---|
| Doors or drawers do not close properly. | Misaligned hinges or drawer slides; loose screws. | Adjust hinge screws or drawer slide mechanisms. Tighten all mounting screws.  |
| Cabinet feels wobbly.                   | Uneven floor; loose assembly screws.              | Adjust leveling feet (if present) or place shims under the base. Re-tighten all assembly screws.                              |
| Scratches or minor surface damage.      | Accidental impact or abrasion.                    | For minor scratches, use a furniture repair pen or wax crayon matching the finish. For deeper damage, consult a professional. |

## SPECIFICATIONS

Detailed technical specifications for the Kappesberg Carol L780A Kitchen Cabinet Kit.

| Feature                | Detail   |
|------------------------|--|
| Model Number           | L780A  |
| Brand                  | Kappesberg   |
| Dimensions (H x W x D) | 210 cm x 262 cm x 52 cm (82.7 in x 103.1 in x 20.5 in) |
| Product Weight         | 78.07 kg (172.1 lbs)                                   |
| Material               | MDP (Medium Density Particleboard)                     |
| Finish Type            | PINTURA TOUCH  |
| Color                  | Nogueira/Verde (Walnut/Green)                          |
| Number of Doors        | 8  |
| Number of Drawers      | 1  |
| Number of Shelves      | 2  |
| Glass Components       | No   |
| Assembly Required      | Yes  |
| Components Included    | Shelves  |
| Warranty Period        | 3 months   |
| EAN                    | 7909875060504  |

## WARRANTY AND SUPPORT

### Warranty Information:

This Kappesberg Carol L780A Kitchen Cabinet Kit comes with a manufacturer's warranty of **3 months** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for any warranty claims.

## **Customer Support:**

For assembly assistance, missing parts, or any other inquiries regarding your product, please contact Kappesberg customer support. Refer to the contact information provided on the product packaging or the official Kappesberg website.

You may also visit the official Kappesberg website for additional resources: [www.kappesberg.com.br](http://www.kappesberg.com.br)

© 2023 Kappesberg. All rights reserved. Information in this manual is subject to change without notice.