

## VEVOR Wet&Dry Vacuum 2.6 Gallon

# VEVOR Shop Vac Wet and Dry Vacuum Cleaner

## USER MANUAL

### 1. Important Safety Instructions

When using an electrical appliance, basic precautions should always be followed, including the following:

- Read all instructions before using this appliance.
- Do not leave appliance when plugged in. Unplug from outlet when not in use and before servicing.
- Do not use outdoors or on wet surfaces. This appliance is designed for indoor use.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without filters in place. Ensure the correct filter is installed for wet or dry operation.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Unplug before connecting hose.

### 2. Package Contents

Carefully unpack your VEVOR Wet and Dry Vacuum Cleaner and ensure all components are present and undamaged. Refer to the diagram below for identification.



Figure 2.1: Included Components and Dimensions

1. Main Vacuum Unit (2.6 Gallon Tank, Motor Head)
2. 4 ft x 1-1/4 in Hose
3. Deluxe Car Nozzle
4. 2-in-1 Utility Nozzle
5. 2-in-1 Crevice Nozzle
6. Cloth Filter (for Dry Use)
7. Foam Filter (for Wet Use)
8. 4 Universal Wheels

### 3. Setup and Assembly

Follow these steps to assemble your vacuum cleaner before first use:

1. **Attach the Wheels:** Invert the tank and firmly insert the four universal wheels into the designated slots on the base of the vacuum tank until they click into place. Ensure they rotate freely.
2. **Install the Correct Filter:**
  - **For Dry Vacuuming:** Place the cloth filter over the filter cage inside the tank, ensuring it covers the entire cage.
  - **For Wet Vacuuming:** Remove the cloth filter. Slide the foam filter over the filter cage.

*Note: Always use the appropriate filter for the task. Using the cloth filter for wet pickup can damage the filter and the motor.*



Figure 3.1: Filter Installation for Wet and Dry Cleaning

3. **Secure the Motor Head:** Place the motor head onto the tank, aligning it properly. Secure it by snapping the two side latches into place. Ensure they are firmly locked to prevent accidental opening during operation.
4. **Attach the Hose:** Insert the larger end of the hose into the vacuum inlet port on the front of the tank. Twist to secure it firmly. The hose connection is designed to prevent accidental detachment during use.
5. **Attach Accessories:** Connect the desired cleaning nozzle (Deluxe Car Nozzle, 2-in-1 Utility Nozzle, or 2-in-1 Crevice Nozzle) to the free end of the hose.

## 4. Operating Instructions

Your VEVOR Wet and Dry Vacuum Cleaner offers versatile cleaning modes:

# 3 IN 1 COST-EFFECTIVE

Thoroughly clean up dust, liquid, hair, etc.



Figure 4.1: 3-in-1 Functionality (Dry, Wet, Blow)

### 4.1 Dry Vacuuming

For picking up dry debris, dust, and dirt:

1. Ensure the cloth filter is properly installed.
2. Attach the appropriate nozzle for dry pickup.
3. Plug the power cord into a suitable electrical outlet.
4. Turn the power switch to the 'ON' position.
5. Begin vacuuming the desired area.
6. When finished, turn the power switch to 'OFF' and unplug the unit.

# ALL-POWERFUL SUCTION

Make clean-up jobs a breeze for you



Figure 4.2: Powerful Suction for Dry Debris

## 4.2 Wet Vacuuming

For picking up liquids and wet messes:

1. **Crucially, remove the cloth filter and install the foam filter.**
2. Attach the appropriate nozzle for wet pickup.
3. Plug the power cord into a suitable electrical outlet.
4. Turn the power switch to the 'ON' position.
5. Begin vacuuming the liquid. The vacuum has a float mechanism that will automatically shut off suction when the tank is full to prevent overflow.
6. When the float rises and suction stops, turn the power switch to 'OFF' and unplug the unit. Empty the tank immediately.

## 4.3 Blower Function

To use the vacuum as a blower for clearing debris from surfaces or inflating items:

1. Ensure the tank is empty and clean.
2. Locate the blower port on the motor head (opposite the vacuum inlet).
3. Insert the hose into the blower port, twisting to secure it.

4. Plug the power cord into a suitable electrical outlet.
5. Turn the power switch to the 'ON' position.
6. Direct the hose to blow air as needed.
7. When finished, turn the power switch to 'OFF' and unplug the unit.

## 5. Maintenance

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

### 5.1 Emptying the Tank

Empty the tank after each use, especially after wet vacuuming, to prevent odors and maintain suction.

1. Unplug the vacuum cleaner from the power outlet.
2. Release the side latches and carefully lift the motor head off the tank.
3. Pour out the collected debris or liquid into a suitable disposal area.
4. Rinse the inside of the tank with water if necessary and wipe it dry before reassembling.

### 5.2 Cleaning Filters

Clean filters regularly to maintain suction power and air quality.

- **Cloth Filter (Dry):** Tap off loose dust into a trash can. For deeper cleaning, the cloth filter is washable. Rinse it under running water until clean. Allow it to air dry completely before reinstallation.
- **Foam Filter (Wet):** Rinse the foam filter under running water to remove debris. Squeeze out excess water and allow it to air dry completely before storage or next use.

*Note: Never use a wet filter for dry vacuuming. Always ensure filters are completely dry before dry use.*

### 5.3 Hose and Accessory Cleaning

Inspect the hose and accessories for blockages or debris. Clear any obstructions to ensure proper airflow.

## 6. Troubleshooting

If you encounter issues with your vacuum cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Vacuum does not turn on.	No power to outlet; Power cord not plugged in; Power switch is off.	Check power outlet; Plug in power cord firmly; Turn power switch to 'ON'.
Loss of suction.	Tank is full; Filter is clogged; Hose or nozzle is blocked; Motor head not sealed properly.	Empty tank; Clean or replace filter; Clear blockages from hose/nozzle; Ensure latches are secured.
Water overflow during wet vacuuming.	Float mechanism stuck or damaged; Tank is overfilled.	Check float for free movement; Empty tank when suction stops.

Problem	Possible Cause	Solution
Unusual noise.	Debris in motor; Damaged fan.	Turn off and unplug. Inspect for foreign objects. If noise persists, contact customer support.

If the problem persists after attempting these solutions, please contact VEVOR customer support for assistance.

## 7. Specifications

Detailed technical specifications for your VEVOR Wet and Dry Vacuum Cleaner:

Feature	Specification
Brand	VEVOR
Model Name	Wet&Dry Vacuum 2.6 Gallon
Capacity	2.6 Gallon / 10 Liters
Motor Horsepower	2.5 Peak HP
Wattage	800 watts
Noise Level	77 dB
Hose Length	4 Feet (1.2 meters)
Product Dimensions (L x W x H)	12"L x 11.6"W x 14.4"H (30.5 cm x 29.5 cm x 36.5 cm)
Item Weight	7.1 pounds (3.2 kg)
Filter Type	Cloth (Dry), Foam (Wet)
Power Source	Corded
Number of Wheels	4 (Universal)
Indoor/Outdoor Usage	Indoor

## 8. Warranty and Support

For detailed warranty information, please refer to the official user manual PDF provided by VEVOR. This document contains specific terms and conditions regarding your product's warranty.

If you require further assistance, have questions about your product, or need to claim warranty service, please contact VEVOR customer support through their official website or the contact information provided in the original product packaging.

You can often find the official user manual and support contact details on the VEVOR brand store page or by searching for your specific model on their website.

Official User Manual (PDF): [Download Here](#)

© 2023 VEVOR. All rights reserved.