

[Manuals.plus](#) /

› [ZEALOT](#) /

› ZEALOT S57 Portable Bluetooth Speaker User Manual

ZEALOT S57

ZEALOT S57 Portable Bluetooth Speaker User Manual

Model: S57

1. INTRODUCTION

The ZEALOT S57 is a high-performance portable Bluetooth speaker designed for robust audio output and versatile connectivity. This manual provides detailed instructions for the proper setup, operation, and maintenance of your speaker to ensure optimal performance and longevity.


2. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x ZEALOT S57 Bluetooth Speaker
- 1 x Type-C Charging Cable
- 1 x 3.5mm AUX Cable
- 1 x User Manual




Caja de Embalaje



Guía del Usuario



Altavoz S57



Línea de Carga



Línea de Sonido

Image: ZEALOT S57 Package Contents. Shows the speaker, user manual, Type-C charging cable, and 3.5mm AUX cable.

3. PRODUCT OVERVIEW

The ZEALOT S57 speaker features an 80W audio system with dual woofers and tweeters, providing powerful and clear sound. It includes a control panel for easy operation and various input/output ports for versatile connectivity.

3.1 Control Panel

The control panel is located on the top of the speaker. Familiarize yourself with the buttons:

- **Power Button:** Press and hold to power on/off.
- **Light Button:** Press to cycle through RGB light modes. Double-click to turn lights off.
- **Mode (M) Button:** Press to switch between Bluetooth, TF card, AUX, and USB disk modes.
- **Dual Pairing Button:** Press to initiate TWS (True Wireless Stereo) pairing with another S57 speaker.
- **Play/Pause Button:** Press to play or pause audio.
- **Volume Down (-) / Previous Track:** Press to decrease volume. Press and hold for previous track.
- **Volume Up (+) / Next Track:** Press to increase volume. Press and hold for next track.



Image: Close-up of the ZEALOT S57 speaker's control panel, showing the power, light, mode, dual pairing, play/pause, and volume buttons.

3.2 Input/Output Ports

The ports are located on the side, protected by a rubber cover:

- **USB Port:** For USB disk playback and charging external devices (power bank function).
- **TF Card Slot:** For playing audio from a MicroSD/TF card.
- **Type-C Charging Port:** For charging the speaker.
- **AUX Input:** For wired audio connection via 3.5mm cable.
- **MIC Input:** For connecting an external microphone.

DUAL PAIRING

MORE ENTHUSIASM



Image: Diagram showing the input/output ports of the ZEALOT S57 speaker, including USB, TF card, Type-C, AUX, and MIC ports.

3.3 Speaker Components

The S57 is equipped with two woofers, two full-range drivers, and two tweeters to deliver its 80W sound output.



Image: Diagram illustrating the internal speaker components of the ZEALOT S57, highlighting two subwoofers and two tweeters for 80W sound.

4. SETUP

4.1 Charging the Speaker

1. Connect the provided Type-C charging cable to the speaker's Type-C port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. The speaker is fully charged when the indicator light changes or turns off (refer to specific light behavior in the quick start guide if available).

Note: For optimal battery life, fully charge the speaker before first use.

4.2 Power On/Off

- **To Power On:** Press and hold the Power button (🔌) for approximately 3 seconds until you hear an audible prompt and the indicator lights illuminate.
- **To Power Off:** Press and hold the Power button for approximately 3 seconds until you hear an audible prompt and the indicator lights turn off.

4.3 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth mode. If not, press the Mode (M) button until you hear the Bluetooth pairing prompt. The Bluetooth indicator light will flash.
2. On your mobile device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "ZEALOT S57" from the list of devices.
4. Once paired, you will hear a confirmation sound, and the Bluetooth indicator light will remain solid.

14400MAH BATTERY 40H PLAYTIME

CHARGE FOR THE DEVICE



Image: The ZEALOT S57 speaker connected via Bluetooth to a smartphone, illustrating the wireless connection.

4.4 Dual Pairing (TWS Function)

To achieve True Wireless Stereo (TWS) sound, you can pair two ZEALOT S57 speakers together:

1. Ensure both S57 speakers are powered on and in Bluetooth mode, but not connected to any device.
2. On one speaker (this will be the primary speaker), press the Dual Pairing button (🔗). It will search for the secondary speaker.
3. The speakers will automatically connect to each other. You will hear a confirmation tone once TWS pairing is successful.
4. Now, connect your mobile device to the primary speaker via Bluetooth as described in section 4.3. Audio will play in stereo through both speakers.

MIC PORT AVAILABLE



Image: Two ZEALOT S57 speakers wirelessly connected, demonstrating the dual pairing feature for enhanced stereo sound.

5. OPERATING INSTRUCTIONS

5.1 Basic Playback

- **Play/Pause:** Press the Play/Pause button (⏮) to start or stop audio playback.
- **Volume Adjustment:** Press the Volume Up (+) or Volume Down (-) buttons to adjust the volume level.
- **Track Skip:** Press and hold the Volume Up (+) button for the next track. Press and hold the Volume Down (-) button for the previous track.

5.2 Mode Switching

Press the Mode (M) button to cycle through available input sources:

- **Bluetooth Mode:** For wireless audio streaming from a paired device.
- **TF Card Mode:** Insert a MicroSD/TF card into the TF card slot. The speaker will automatically play audio files.
- **AUX Mode:** Connect an audio device using the 3.5mm AUX cable to the AUX input.

- **USB Disk Mode:** Insert a USB flash drive into the USB port. The speaker will automatically play audio files.

5.3 RGB Lighting Control

The speaker features dynamic RGB lighting around its perimeter:

- Press the Light button (🔦) to cycle through different RGB light effects.
- Double-click the Light button to turn the RGB lights off.



Image: The ZEALOT S57 speaker displaying its colorful RGB lighting effects.

5.4 Using the Microphone Input

Connect a microphone (not included) to the MIC input port for karaoke or public address functions.

- Plug your microphone into the MIC input jack.
- Adjust the microphone volume on the microphone itself or through your connected audio source if applicable.

5.5 Using as a Power Bank

The ZEALOT S57 can charge external devices using its built-in 14,400mAh battery:

- Connect your device's charging cable to the USB output port on the speaker.
- The speaker will begin charging your device.



Image: The ZEALOT S57 speaker charging a smartphone via its USB output port, demonstrating its power bank functionality.

6. MAINTENANCE

6.1 Waterproof Feature (IPX7)

The ZEALOT S57 speaker is IPX7 waterproof, meaning it can be submerged in water up to 1 meter for 30 minutes. This makes it suitable for use near pools, beaches, or in rainy conditions.

- Ensure the rubber cover for the input/output ports is securely closed before exposing the speaker to water.
- Do not expose the speaker to saltwater or chemicals, as this may damage the seals. Rinse with fresh water if exposed to saltwater.
- Do not charge the speaker if it is wet.

IPX7 WATERPROOF



Image: The ZEALOT S57 speaker partially submerged in water, demonstrating its IPX7 waterproof rating.

6.2 General Care

- Clean the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Store the speaker in a cool, dry place when not in use.
- Avoid dropping or subjecting the speaker to strong impacts.

7. TROUBLESHOOTING

If you encounter issues with your ZEALOT S57 speaker, refer to the following common solutions:

7.1 No Power

- Ensure the speaker is fully charged. Connect it to a power source using the Type-C cable.
- Press and hold the Power button for at least 3 seconds.

7.2 No Sound

- Check the volume level on both the speaker and your connected device.

- Ensure the speaker is in the correct mode (Bluetooth, AUX, TF Card, USB Disk) for your audio source.
- If using Bluetooth, ensure the speaker is properly paired and within range.
- If using AUX, ensure the cable is fully inserted into both the speaker and the audio source.

7.3 Bluetooth Pairing Issues

- Ensure the speaker is in Bluetooth pairing mode (indicator light flashing).
- Turn off Bluetooth on your device and then turn it back on.
- Forget or remove "ZEALOT S57" from your device's Bluetooth list and attempt to pair again.
- Move the speaker and your device closer to each other, ensuring no obstructions.
- Restart both the speaker and your device.

7.4 Charging External Devices Issues

- Ensure the speaker has sufficient battery charge to act as a power bank.
- Verify the charging cable for your external device is functional and properly connected to the speaker's USB output port.

8. SPECIFICATIONS

Feature	Detail
Brand	ZEALOT
Model Number	S57
Speaker Maximum Output Power	80 Watts
Battery Capacity	14,400 mAh
Battery Average Life	Up to 40 Hours
Connectivity Technology	Bluetooth 5.2, USB, TF Card, AUX
Wireless Technology	Bluetooth
Bluetooth Range	Up to 100 Feet / 100 Meters
Water Resistance Level	IPX7 Waterproof
Audio Output Mode	Stereo
Item Dimensions (D x W x H)	5.74"D x 8.18"W x 14.4"H
Item Weight	1.91 Kilograms
Additional Features	RGB Lighting, Dual Pairing, Microphone Input, Power Bank Function



Image: Diagram showing the dimensions of the ZEALOT S57 speaker: 8.11" height, 14.27" width, and 5.69" depth.

9. OFFICIAL PRODUCT VIDEOS

Watch these official videos for a visual guide on the ZEALOT S57 speaker's features and operation.

Your browser does not support the video tag.

Video: Comprehensive overview of the ZEALOT S57 Bluetooth Speaker, demonstrating its features and design.

Your browser does not support the video tag.

Video: A detailed look at the 80W Portable Bluetooth Speaker, highlighting its sound capabilities.

10. WARRANTY AND SUPPORT

10.1 Warranty Information

The ZEALOT S57 speaker comes with a **1-year limited warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

10.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact ZEALOT customer support. Refer to the contact information provided on the product packaging or the official ZEALOT website.

The ZEALOT team is committed to providing support and will respond to inquiries within 24 hours.

