

Smoby 810204

Smoby Friends House Evo Children's Garden Shed

MODEL: 810204 - INSTRUCTION MANUAL

Introduction

Welcome to the instruction manual for your new Smoby Friends House Evo Children's Garden Shed. This manual provides important information regarding the assembly, safe operation, and maintenance of your playhouse. Please read it thoroughly before assembly and retain it for future reference. This playhouse is designed to provide a fun and imaginative play environment for children aged 3 years and above.

Important Safety Information

WARNING:

- Intended for indoor or outdoor use.
- For family use only.
- Minimum age: 36 months (3 years).
- Maximum weight: 25 kilograms (approximately 55 lbs).
- Adult supervision is required at all times when children are using the playhouse.
- Ensure the playhouse is assembled on a flat, stable surface to prevent tipping.
- Regularly check all components for wear and tear, and replace damaged parts immediately.
- Keep small parts away from children during assembly to prevent choking hazards.

Included Components

Before beginning assembly, please ensure all parts listed below are present and undamaged. The product

is shipped in 3 boxes for convenience.

- 1 x Playhouse structure (various panels for walls and roof)
- 1 x Large door with lock and peephole
- 1 x Gate (serving as a 'secret passage')
- 6 x Windows
- 2 x Shutters (360° rotatable)
- 1 x Letter box
- All necessary fasteners and connectors for assembly (e.g., screws, clips)



Image: The complete Smoby Friends House Evo Children's Garden Shed, showcasing its modern design with beige, green, and grey elements, a main door, and multiple windows.

Assembly Instructions

The Smoby Friends House Evo is designed for straightforward assembly. Adult assembly is required. Follow these general steps:

1. **Unpack Components:** Carefully unpack all parts from the boxes. Verify that all components listed in the "Included Components" section are present and undamaged.
2. **Prepare the Site:** Choose a flat, level, and stable surface for the playhouse. Ensure there is adequate clear space around the playhouse for safe play.
3. **Assemble Base Structure:** Begin by connecting the base panels according to the manufacturer's

detailed diagrams (refer to the separate assembly guide included in the packaging). Ensure all connections are secure.

4. **Attach Wall Panels:** Connect the wall panels to the base and to each other. Pay attention to the designated slots for windows, doors, and other features.
5. **Install Windows and Shutters:** Insert the 6 windows into their respective openings. Attach the 2 shutters, ensuring they can rotate 360 degrees as intended.
6. **Mount Doors and Gate:** Install the large main door with its lock and peephole. Attach the rear gate, which serves as a "secret passage."
7. **Attach Roof Panels:** Securely attach the roof panels to the top of the wall structure. Ensure they are firmly connected to provide stability and weather protection.
8. **Install Letter Box:** Mount the functional letter box in its designated position.
9. **Final Check:** Once assembled, thoroughly check all connections, screws, and moving parts to ensure they are secure and functioning correctly.



Image: Three children interacting with the Smoby Friends House Evo, highlighting its size and various entry/exit points, including the main door and windows, demonstrating the assembled product in use.

Operating the Playhouse

The Smoby Friends House Evo is designed for imaginative play and offers several interactive features:

- **Main Door:** The large front door features a lock and a peephole, allowing children to simulate entering and securing their play space.
- **Secret Passage Gate:** A gate at the back of the house provides an additional entry/exit point, encouraging creative play scenarios.
- **Windows and Shutters:** The six windows allow light and air into the playhouse. The two 360° rotatable shutters can be opened or closed, adding to the interactive experience.
- **Functional Letter Box:** Children can use the letter box for sending and receiving pretend mail, enhancing role-play.
- **Customization:** The playhouse is designed to be customizable with various Smoby accessories (sold separately), such as a summer kitchen, picnic table, water collector, nomadic lamp, or doorbell. These accessories can be easily integrated to expand play possibilities.



Image: A young child bending down to interact with the green letterbox on the side of the Smoby Friends House Evo, demonstrating a functional feature of the playhouse.

Care and Maintenance

To ensure the longevity and safety of your Smoby Friends House Evo, follow these maintenance guidelines:

- **Cleaning:** Clean the playhouse regularly with a damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals, as these can damage the plastic.
- **UV Protection:** The playhouse features an anti-UV treatment to help maintain color retention over time. However, prolonged exposure to direct sunlight may still cause some fading.
- **Structural Integrity:** Periodically check all connections, screws, and structural components for tightness and signs of wear. Tighten any loose fasteners.
- **Damage Inspection:** Inspect the plastic components for cracks, breaks, or sharp edges. Discontinue

use if any significant damage is found and contact customer support for replacement parts.

- **Winter Storage (Optional):** While designed for outdoor use, storing the playhouse indoors or covering it during harsh winter conditions can further extend its lifespan.

Troubleshooting

If you encounter any issues with your Smoby Friends House Evo, consider the following:

- **Stability Issues:** Ensure the playhouse is assembled on a completely flat and level surface. Recheck all connections to confirm they are securely fastened.
- **Parts Not Fitting:** Double-check the assembly instructions and diagrams provided with the product. Ensure you are using the correct parts for each step. Do not force parts together.
- **Missing Components:** If any components were missing upon unpacking, refer to the "Included Components" list and contact Smoby customer support with your product model number and details of the missing part.
- **Damaged Parts:** If any part is damaged during shipping or assembly, do not attempt to use it. Contact customer support for replacement parts.

Product Specifications

Feature	Detail
Brand	Smoby
Model Number	810204
Material Type	Plastic
Assembly Required	Yes
Minimum Age	36 Months (3 years)
Maximum Age	96 Months (8 years)
Item Dimensions (L x W x H)	45 x 69.06 x 63.78 inches
Item Weight	39200 Grams (approx. 86.4 lbs)
Number of Windows	6
Included Components	1 house, 1 large door with lock and peephole, 1 gate, 6 windows, 2 shutters, 1 letter box

Warranty and Customer Support

For warranty information, replacement parts, or any questions not covered in this manual, please contact Smoby customer support directly. Keep your purchase receipt and product model number (810204) handy when contacting support.

You can typically find contact information on the official Smoby website or on the product packaging.

