

Moimhear WF285491

Moimhear Chalet-Shaped Kids Bed

Model: WF285491

INTRODUCTION

This instruction manual provides detailed guidance for the assembly, operation, maintenance, and troubleshooting of your Moimhear Chalet-Shaped Kids Bed. Please read this manual thoroughly before assembly and use to ensure safe and correct operation.

This bed frame is designed for children and features a versatile structure that can be personalized. It can also serve as a reading nook or play area. The bed is constructed from solid pine wood, ensuring durability and stability. Only the bed frame is included; the mattress is not part of the delivery.

Safety Warnings

- Ensure the product is correctly assembled to guarantee stability.
- Do not exceed the specified maximum load capacity of 150 kg.
- Keep small parts and sharp edges away from children to prevent hazards during assembly and use.
- Regularly check all connections and fasteners to ensure they remain tight and secure.
- This bed is recommended for children aged 5 to 10 years.

SETUP AND ASSEMBLY

Assembly of the Moimhear Chalet-Shaped Kids Bed is designed to be straightforward. Please follow the steps below carefully. It is recommended to have two adults for assembly.

Required Tools (Not Included):

- Screwdriver (Phillips head)
- Hammer (optional, for dowels)

Assembly Steps:

1. **Unpack Components:** Carefully unpack all parts and hardware. Verify that all components listed in the parts list (not provided in this manual, refer to packaging) are present and undamaged.
2. **Assemble Side Rails:** Attach the side rails to the headboard and footboard using the provided screws and dowels. Ensure all connections are secure.
3. **Install Bed Slats:** Place the bed slats onto the designated supports on the side rails. Secure them according to the instructions provided with the hardware.

4. **Construct House Frame:** Assemble the chalet-shaped frame components and attach them to the main bed structure. Ensure all joints are tight.
5. **Assemble Storage Drawers:** Put together the two storage drawers. Install the wheels on the bottom of each drawer.
6. **Integrate Shelves:** The headboard features integrated shelves. Ensure these are securely fastened during the headboard assembly.
7. **Final Check:** Once assembled, gently shake the bed to ensure stability. Retighten any loose screws.



Image: Detailed dimension diagram of the Moimhear Chalet-Shaped Kids Bed, illustrating overall length (204 cm), width (95 cm), height (168.5 cm), and dimensions of the drawers and shelves.



Image: Angled view of the assembled bed, highlighting the chalet-shaped frame and the integrated shelving unit at the headboard.

OPERATING INSTRUCTIONS

The Moimhear Chalet-Shaped Kids Bed is designed for comfortable and functional use.

Mattress Placement:

- Place a standard 90 x 200 cm mattress directly onto the bed slats. Ensure the mattress fits snugly within the frame.

Storage Drawers:

- The bed includes two under-bed storage drawers. These drawers are on wheels for easy access.
- Pull the drawers out gently to access stored items. Push them back in fully when not in use to prevent tripping hazards.
- Do not overload the drawers.



Image: Close-up of an open storage drawer, showing its interior capacity and construction.

Integrated Shelves:

- The headboard features multiple open shelves for storing books, small toys, or decorative items.
- Ensure items placed on shelves are stable and do not pose a falling hazard.



Image: Front view of the bed, clearly showing the headboard with its multiple storage compartments.

MAINTENANCE

Proper maintenance will extend the life and appearance of your Moimhear Kids Bed.

Cleaning:

- Wipe the bed frame with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or polishes, as these can damage the wood finish.
- For spills, clean immediately with a dry cloth to prevent staining.

Inspections:

- Periodically check all screws, bolts, and fasteners to ensure they are tight. Retighten if necessary.
- Inspect the bed slats for any signs of damage or wear. Replace any broken slats immediately.
- Check the stability of the house frame structure regularly.



Image: Close-up of the bed's side rail and the wooden slats that support the mattress, showing the construction details.

TROUBLESHOOTING

If you encounter any issues with your Moimhear Kids Bed, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose fasteners or incorrect assembly.	Check all screws and bolts. Tighten any loose connections. Review assembly instructions to ensure all parts are correctly installed.
Drawers do not slide smoothly.	Obstruction, damaged wheels, or uneven floor.	Check for any objects blocking the drawer path. Inspect drawer wheels for damage. Ensure the bed is on a level surface.

Problem	Possible Cause	Solution
Squeaking noises.	Loose connections or friction between wood parts.	Tighten all fasteners. Apply a small amount of furniture wax or silicone spray to contact points if necessary (avoiding areas where children might touch).

SPECIFICATIONS

Feature	Detail
Brand	Moimhear
Model Number	WF285491
Color	White
Material	Solid Pine Wood
Overall Product Dimensions (L x W x H)	206 x 97 x 150.5 cm
Compatible Mattress Size	90 x 200 cm
Item Weight	30 kg
Maximum Load Capacity	150 kg
Recommended Age	5 to 10 years
Special Features	2 Storage Drawers, Integrated Shelves, Easy Assembly, Water-based Paint

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation provided with your purchase or contact the retailer directly. Information regarding spare parts availability is not provided in this manual.

For further assistance, please contact Moimhear customer service through their official channels.

© 2024 Moimhear. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BNNZMDT4>

More documents and user manuals: <https://manuals.plus/>