

Trueque B0BNPBTJDP

Trueque Wireless Keyboard User Manual

Model: B0BNPBTJDP | Brand: Trueque

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the Trueque Wireless Keyboard. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your new keyboard. Please read this manual thoroughly to ensure optimal performance and longevity of your device.



Image: Trueque Wireless Keyboard with blue backlighting, showing its full size and integrated wrist rest.

2. PRODUCT FEATURES

The Trueque Wireless Keyboard is designed for enhanced productivity and comfort, offering a range of features:

- **7 Switchable Colors Backlight:** Customize your typing experience with 7 distinct backlight colors and 3 brightness levels for optimal visibility in any lighting condition.



7 COLORED BACKLIGHTS



3 Levels Adjustable Brightness

 + 

Turn on/off light

 + 

Switch light color

 + 

Adjust light brightness

Image: Illustration of the keyboard's 7 colored backlights and controls for turning on/off, switching colors, and adjusting brightness.

- **Ergonomic Palm Rest:** Features an integrated wrist rest and foldable stands to improve comfort and reduce wrist strain during extended use.

GENEROUS PALM REST INCREASED COMFORT

Palm Rest for Reducing Wrist Fatigue



Foldable Stand

7°

Palm Rest



Others



Ours

Image: Diagram illustrating the ergonomic palm rest and foldable stand, showing improved wrist posture compared to other keyboards.

- **Rechargeable and Long Lasting:** Equipped with a Type-C charging cable, offering an extra-long standby time of up to 24 months on a single charge. Includes an automatic sleep power-saving mode and a separate ON/OFF switch.

TYPE-C QUICK CHARGE

Built-in Rechargeable Battery

2
Hours

Charging
Time

365
Days

Standby
Time



Smart Sleep
Mode




Image: Visual representation of the keyboard's Type-C quick charge feature, highlighting 2 hours charging time, 365 days standby time, and smart sleep mode.

- **Quiet and Comfortable Typing:** Responsive low-profile keys provide fluid, quiet, laptop-like typing, reducing disruptive sounds by over 95%.

LESS NOISE & SENSITIVE RESPONSE



OUR  Quiet & Fast

OTHER  Noisy & Delayed

0.1in

95% Noise Reduction

Image: Close-up showing the low-profile keys and emphasizing 95% noise reduction for quiet typing.

- **Integrated Phone/Tablet Holder:** Conveniently designed with a tablet/phone holder, allowing you to work or watch videos simultaneously.



COMPATIBILITY WITH 99% OF DEVICES



**TRADITIONAL COMPUTER
- USB PORT**



**MACBOOK
- TYPE C PORT**

Image: Keyboard with a smartphone placed in its integrated holder, illustrating 2.4G stable connection and 33ft wireless range.

- **Wireless Stable Connection:** 2.4 GHz wireless technology ensures a strong and reliable connection up to 33 feet without latency. Plug and play, no drivers required.
- **Wide Compatibility:** Compatible with all USB and Type-C port devices, including iPad, PC, Laptop, Smart TV, MacBook, Tablet, Smartphone, and more. Supports Windows OS, iOS, Chrome OS, Linux, and Android OS.

3. SETUP INSTRUCTIONS

1. **Unpack the Keyboard:** Carefully remove the keyboard and the USB receiver (located in the battery compartment or a dedicated slot) from the packaging.
2. **Charge the Keyboard:** Before first use, fully charge the keyboard using the provided Type-C charging cable. Connect the Type-C end to the keyboard's charging port and the USB-A end to a power source (e.g., computer USB port, USB wall adapter). The charging indicator light will show charging status.



Image: Close-up of the keyboard's Type-C charging port.

3. **Connect the USB Receiver:** Insert the 2.4 GHz USB receiver into an available USB port on your computer, laptop, or compatible device. For devices with only Type-C ports (like some MacBooks), use the included USB-A to Type-C adapter.
4. **Power On:** Locate the ON/OFF switch on the keyboard (usually on the back or side) and slide it to the 'ON' position.

SMART SLEEP MODE

Helps extend battery life



2 mins
light off



30 mins
sleeps



Switch
ON/OFF



Image: View of the keyboard's underside, highlighting the foldable stand, ON/OFF switch, and anti-slip pads.

5. **Automatic Connection:** The keyboard should automatically connect to your device. No additional drivers are typically needed.

4. OPERATING INSTRUCTIONS

4.1 Backlight Control

- **Turn On/Off Backlight:** Press **Fn + Esc** to toggle the backlight on or off.
- **Switch Light Color:** Press **Fn + F1** to cycle through the 7 available backlight colors.
- **Adjust Brightness:** Press **Fn + ↑** (Up Arrow) to increase brightness and **Fn + ↓** (Down Arrow) to decrease brightness. There are 3 adjustable brightness levels.

4.2 Using the Phone/Tablet Holder

The integrated groove at the top of the keyboard serves as a convenient holder for your smartphone or tablet. Simply place your device in the groove to keep it upright and visible while you work.

4.3 Smart Sleep Mode

To conserve battery life, the keyboard will automatically enter a sleep mode after 30 minutes of inactivity, and the backlight will turn off after 2 minutes. To reactivate the keyboard, simply press any key.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the keyboard surface. For deeper cleaning, a slightly damp cloth can be used, ensuring no liquid enters the keys or internal components. Avoid harsh chemicals or abrasive materials.
- **Battery Care:** To maximize battery lifespan, avoid fully discharging the keyboard frequently. Recharge it when the low battery indicator appears. Store the keyboard in a cool, dry place if not in use for extended periods.
- **Spill-Resistant Design:** The keyboard features a spill-resistant design, offering protection against minor spills. However, it is not waterproof. In case of a spill, immediately power off the keyboard and allow it to dry completely before reuse.




Image: Close-up illustrating the keyboard's spill-resistant design with water droplets on the surface.

6. TROUBLESHOOTING

- **Keyboard Not Responding:**

- Ensure the keyboard is powered on.
 - Check if the USB receiver is securely plugged into your device. Try a different USB port.
 - Recharge the keyboard if the battery is low.
 - Restart your computer/device.
- **Backlight Not Working:**
 - Press **Fn + Esc** to ensure the backlight is not turned off.
 - Check battery level; low battery can affect backlight function.
 - Unplug and reconnect the USB receiver.
- **Keys Sticking or Unresponsive:**
 - Clean around the affected keys to remove any debris.
 - Ensure the keyboard is fully charged.
- **Connection Issues / Lag:**
 - Ensure the keyboard is within the 33-foot wireless range of the USB receiver.
 - Avoid placing the keyboard near strong electromagnetic interference sources (e.g., microwaves, Wi-Fi routers).
 - Try plugging the USB receiver into a different USB port.

7. SPECIFICATIONS

Feature	Detail
Brand	Trueque
Model	B0BNPBTJDP
Product Dimensions	16.6 x 8.42 x 1.53 inches
Item Weight	1.74 pounds
Connectivity Technology	2.4 GHz USB Wireless
Keyboard Description	Ergonomic, Backlit, Rechargeable, Silent Keys
Number of Keys	104
Backlighting Colors	7 Switchable Colors (RGB)
Brightness Levels	3
Special Features	Ergonomic, Backlit, Phone Holder, Wrist Rest, Rechargeable, Quiet, LED light up Keys

Compatible Devices	Laptop, PC, Windows, MacBook Pro, MacBook Air, iMac, Tablet, Television, Smartphone, Chromebook, Notebook
Country of Origin	China

8. WARRANTY AND SUPPORT

8.1 Warranty Information

This Trueque Wireless Keyboard comes with a **24-month warranty**. If you encounter any issues with your order or the product, please contact our customer support team for assistance. We are committed to providing sincere service and ensuring a meaningful product experience.

8.2 Customer Support

For any inquiries, technical support, or warranty claims, please reach out to us through the following channels:

- **Email Support:** Truequeservices@outlook.com
- **Phone Support (US):** 1-866-608-6766 (Monday - Friday, 9 AM - 6 PM PST, with a break from 1 PM - 2 PM)

CUSTOMER ONLINE SUPPORT

Email support:

Truequeservices@outlook.com

Call Us: 1-866-608-6766(US), Mon-Fri, 9am-6pm, 1pm-2pm(Rest)




Image: Visual representation of Trueque's customer online support, including email and phone contact details.