

[Manuals.plus](#) /

› [LUROON](#) /

› LUROON Key Safe Outdoor Waterproof Wall Mounted Super Security Extra Large Key Box Police Approved Lockbox 12-Digit Combination Key Storage Box with Weatherproof Cover for Home Garage Office School Black Instruction Manual

LUROON G19

LUROON Key Safe Instruction Manual

Model: G19

INTRODUCTION

Thank you for choosing the LUROON Key Safe. This outdoor waterproof wall-mounted key box provides a secure and convenient solution for storing keys and small items. Its robust construction and 12-digit combination lock ensure high security and durability for various applications, including homes, offices, garages, and schools.



Image: The LUROON Key Safe shown from two angles, one with the cover open revealing keys inside, and the other showing the 12-digit keypad.

SAFETY INFORMATION

Important Safety Precautions:

- The LUROON Key Safe is designed for keys and small items only. Do not store securities or large amounts of money.
- Ensure the key safe is installed in a secure location, whether indoors or outdoors.
- Contains small parts. Keep out of reach of children and do not swallow.

- Always remember your combination code. There is no recovery method if the code is forgotten.

! WARNING: Contains small parts inside, do not swallow. Do not forget the new password.

! WARNUNG: Enthält kleine Teile im Inneren, nicht verschlucken. Vergessen Sie das neue Passwort nicht.

! AVERTISSEMENT: Contenant de petites pièces à l'intérieur, ne pas avaler. N'oubliez pas le nouveau mot de passe.

! AVVERTENZA: Contiene piccole parti all'interno, non ingerirle. Non dimenticare la nuova password.

! ADVERTENCIA: Contiene piezas pequeñas en su interior, no ingerir. No olvide la nueva contraseña.

! WAARSCHUWING: Bevat kleine onderdelen binnenin, niet inslikken. Vergeet het nieuwe wachtwoord niet.

! VARNING: Innehåller små delar inuti, svälj inte. Glöm inte det nya lösenordet.

! OSTRZEŻENIE: Zawiera małe części wewnątrz, nie połykać. Nie zapomnij nowego hasła.

Image: A warning label in multiple languages, highlighting precautions such as 'Contains small parts inside, do not swallow' and 'Do not forget the new password'.

PRODUCT FEATURES

Super Security Lock Box

Constructed from high-grade rust and corrosion-resistant aluminum alloy and zinc alloy, this key safe is built to withstand hammering, sawing, and prying. Its robust design ensures long-term outdoor use, resisting wind and sun exposure.

12-Digit Code Combination

The 12-digit push-button keypad allows for a vast number of unique combinations, providing enhanced security. Instructions are provided to guide you through setting and resetting your access code at any time.



Image: A detailed view highlighting the 12-digit code keypad, the full cover protector that shields dials from weather, and the reinforced lock body designed to resist physical attacks.

Extra Large Key Safe

This wall-mounted key box offers ample storage, accommodating at least 5 house or car keys, as well as access cards, credit cards, and USB thumb drives. It is suitable for both outdoor and indoor use, ideal for emergency access or keyless

entry for family, pet sitters, and friends.



Image: An illustration showing the large internal storage capacity of the key safe, along with its dimensions and an upgraded hook for neat key organization.

Weatherproof Cover

Includes a protective cover designed to shield the combination dials from dust, rust, sunlight, rain, and snow, ensuring reliable operation in various weather conditions.

SETUP: INSTALLATION GUIDE

The LUROON Key Safe is designed for easy installation on a solid surface. All necessary mounting parts are provided.

Package Contents:

- 1 x LUROON Key Safe

- 4 x Screws
- 4 x Nylon Expansion Bolts
- 1 x User Guide
- 1 x Screwdriver (for setting the password)

Installation Steps:

1. **Mark Screw Location Holes:** Place the key safe against the desired mounting surface and use a pencil to mark the positions for the four pre-drilled holes.
2. **Drill Holes:** Using an appropriate drill bit for your wall type, drill four holes at the marked locations.
3. **Insert Expansion Bolts:** Gently tap the nylon expansion bolts into the drilled holes until they are flush with the surface.
4. **Install the Key Box:** Align the key safe with the holes, insert the screws through the key safe's mounting holes, and tighten them into the expansion bolts using a screwdriver until the key safe is securely fixed to the surface.



EASY TO USE

Wall-mounted Key Safe for Convenient Use




Image: A visual guide illustrating the four steps for installing the key safe on a wall, along with a depiction of the included package contents:

OPERATING INSTRUCTIONS

Setting Your Combination Code:

Refer to the detailed user guide included in your package for step-by-step instructions on how to set and reset your 12-digit combination code. It is crucial to record your password immediately after setting it, as there is no way to retrieve a forgotten code.

Opening the Key Safe:

To open the key safe, simply enter your correct 12-digit combination code using the push buttons. The key safe will then be easy to open.

Important Note:

If you find that the buttons are unresponsive or you have entered an incorrect code, press the 'C' button to clear the input, then re-enter your code.

MAINTENANCE

To ensure the longevity and optimal performance of your LUROON Key Safe, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the exterior of the key safe with a dry cloth to remove dust and debris. Avoid using abrasive cleaners or solvents that could damage the finish or internal mechanisms.
- **Mechanism Care:** Periodically check the push buttons and internal locking mechanism for any obstructions. Keep the mechanism free from dirt or grime to ensure smooth operation.
- **Weather Protection:** Ensure the weatherproof cover is properly closed when not in use to protect the dials from environmental elements.

TROUBLESHOOTING

Buttons Unresponsive or Incorrect Code:

If the buttons feel stiff or unresponsive, or if the key safe does not open after entering the code, press the 'C' button to clear any previous input. Then, carefully re-enter your combination code. Ensure each button is fully pressed.

Stiffness in Cold Weather:

In extremely cold temperatures, the internal mechanism or buttons might become stiff. If this occurs, try warming the lockbox gently (e.g., with warm air, not direct heat) or wait for temperatures to rise. Ensure the weatherproof cover is always used to minimize exposure to extreme conditions.

Difficulty Closing the Safe:

Ensure no items inside the safe are obstructing the closing mechanism. Check that the internal hook is not preventing the door from fully seating.

SPECIFICATIONS

Model Number	G19
Product Dimensions	12.5 x 9.7 x 6.5 cm
Item Weight	360 Grams
Finish Type	Powder Coated
Special Features	Weatherproof, Lockable, Fire Resistant
Recommended Use	Emergency access, key storage for family, caregivers, friends, key organization

WARRANTY & SUPPORT

LUROON is committed to customer satisfaction. If you encounter any issues or are not satisfied with your key safe, please do not hesitate to contact us. We are ready to assist you.

- **Customer Support:** Enjoy 7x24 hours professional customer support.
- **Replacement Policy:** Your purchase is covered by a 2-year worryless replacement policy.

All your issues and suggestions will be highly valued and addressed promptly.



Image: A group of customer service representatives wearing headsets, symbolizing LUROON's commitment to customer support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question