

[Manuals.plus](#) /
› [CoBak](#) /
› CoBak Case for Surface Pro 2024 Copilot PC 11th Edition - for Microsoft 13 Inch Tablet, Fits Keyboard and Kickstand with Multiple Angle
(Black, Pro 11/10/9/8/X) Black Pro 11/10/9 User Manual

CoBak Pro 11/10/9

CoBak Case Instruction Manual

MODEL: PRO 11/10/9 CASE

Brand: CoBak

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your CoBak Case for Microsoft Surface Pro 11 / Pro 10 2024 and Surface Pro 9 2022 13-inch tablets. Designed for durability and functionality, this case offers robust protection and enhanced usability for your device.



Figure 1: CoBak Case providing comprehensive protection for your Surface Pro.

SETUP AND INSTALLATION

Ensure your tablet is compatible with the CoBak case before installation. This case is specifically designed for Microsoft Surface Pro 11 / Pro 10 2024 and Surface Pro 9 2022 13-inch models. It is not compatible with Surface Pro 7 Plus/7/6/5/4 (12.3 inch) or Surface Go 3/Go2/Go (10.5 inch).

ONLY COMPATIBLE

Surface Pro 11 2024 13 inch
Surface Pro 9 2022 13 inch
Surface Pro 8 2021 13 inch
Surface Pro x 2021 / 2019 13 inch



NOT FIT FOR

Surface Pro 7 Plus/7/6/5/4 12.3 inch
Surface Go 3/Go2/Go 10.5 inch



Figure 2: Verify your Surface Pro model for compatibility.

Installation Steps:

1. Gently align your Microsoft Surface Pro tablet with the case, ensuring the ports and buttons match the cutouts.
2. Carefully press the tablet into the case, starting from one corner and working your way around until all edges are securely fitted. The soft rubber bezel will provide a snug fit.
3. Ensure the built-in kickstand of your Surface Pro is accessible and can be fully extended and retracted without obstruction from the case.

ALL-IN-ONE STAND CASE

Case with Pocket for Surface 13 Inch

- Surface Pro 11 Case (2024 Release)
- Surface Pro 9 Case (2022 Release)
- Surface Pro 8 / ProX Case(2021 Release)



Figure 3: The CoBak case is designed for easy installation and full access to tablet features.

Video 1: Visual guide demonstrating the installation process of the CoBak case onto a Microsoft Surface Pro tablet.

OPERATING INSTRUCTIONS

The CoBak case is designed to enhance the functionality of your Surface Pro, particularly its kickstand and keyboard compatibility.

Multi-Angle Viewing:

The case supports the original kickstand of your Surface Pro, allowing you to adjust the tablet to various viewing angles without removing the case. This feature is ideal for typing, watching videos, or presenting.



Figure 4: Enjoy versatile viewing angles for work or entertainment.

Keyboard Compatibility:

The case is designed to fit seamlessly with your Surface Pro's keyboard, allowing you to attach and detach it easily while the case is on. This ensures full productivity without compromising protection.




Figure 5: The case maintains full keyboard functionality and offers efficient heat dissipation.

MAINTENANCE

To ensure the longevity and appearance of your CoBak case, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the case regularly with a soft, damp cloth. For stubborn stains, a mild soap solution can be used. Avoid harsh chemicals or abrasive cleaners.
- **Protection:** The case features a special coating to effectively prevent smudges and fingerprints. While durable, avoid sharp objects that could scratch the surface.
- **Storage:** When not in use, store the case in a cool, dry place away from direct sunlight to prevent material degradation.

Vegan Leather Cover



Anti-stain



Anti-scratch



Full Protection



Easy Installation



Figure 6: The vegan leather cover is designed for durability and ease of maintenance.

TROUBLESHOOTING

If you encounter any issues with your CoBak case, please refer to the following common solutions:

- **Case does not fit:** Double-check the compatibility section to ensure your Surface Pro model is supported. Ensure the tablet is correctly aligned and gently pressed into place.
- **Difficulty accessing ports/buttons:** Verify that the tablet is fully seated within the case. The precise cutouts should allow full access. If not, remove and re-install the tablet.
- **Scratches on the clear back:** While the case offers scratch protection, excessive force or abrasive contact can still cause marks. Regular cleaning and careful handling are recommended.



Figure 7: The case provides significant protection against daily wear and tear.

SPECIFICATIONS

Feature	Detail
Brand	CoBak
Model	Pro 11/10/9
Compatible Devices	Microsoft Surface Pro 11 / Pro 10 2024, Surface Pro 9 2022 (13-inch)
Shell Type	Hard
Color	Black
Item Weight	3.53 ounces

Feature	Detail
Package Dimensions	11.73 x 8.86 x 1.14 inches
Special Features	Heavy Duty Protection, Multi-Angle Viewing, Keyboard Compatible

WARRANTY AND SUPPORT

CoBak is committed to providing high-quality products and an excellent shopping experience. Your CoBak case is built with superior quality and durability in mind.

For any questions, concerns, or support needs regarding your CoBak case, please contact CoBak Direct through the platform where you purchased the product. We are dedicated to ensuring customer satisfaction and will assist you with any inquiries.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question