

**fojep BX28**

# fojep Wireless Earbuds BX28 User Manual

Model: BX28

<a href="#">Introduction</a>	<a href="#">Package Contents</a>	<a href="#">Setup</a>	<a href="#">Operating Instructions</a>	<a href="#">Maintenance</a>	<a href="#">Troubleshooting</a>
		<a href="#">Specifications</a>	<a href="#">Warranty &amp; Support</a>		

## 1. INTRODUCTION

Thank you for choosing the fojep Wireless Earbuds BX28. These earbuds are designed to provide a high-quality audio experience with advanced features for daily use and sports activities. This manual will guide you through the setup, operation, and maintenance of your new earbuds.




Figure 1.1: fojep Wireless Earbuds BX28 with charging case. The earbuds feature an ergonomic design with earhooks for a secure fit, and the charging case has an LED digital display.

## 2. PACKAGE CONTENTS

Please verify that all items are present in your package:

- fojep Wireless Earbuds (Left and Right)
- Charging Case with LED Digital Display
- USB Type-C Charging Cable
- Eartips (3 sizes: S, M, L)
- User Manual



# Super Stable

Stay in place while moving around

## Sports Clamping Design

Wraparound Titanium Wireskeleton  
Resilient and Durable



Figure 2.1: Illustration of the items included in the fojep BX28 earbud package, showing the earbuds, charging case, charging cable, and various eartip sizes.

## 3. SETUP

### 3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. The charging case features an LED digital display that shows the battery percentage of the case and individual battery status bars for each earbud.

1. Place both earbuds into the charging case. Ensure they are correctly seated; the indicator lights on the earbuds will illuminate.
2. Connect the USB Type-C charging cable to the charging port on the case and the other end to a USB power source (e.g., wall adapter, computer USB port).
3. The LED display on the charging case will show the charging progress. A full charge typically takes approximately 1.5-2 hours.

# 75 Hours of Battery Life

100

digital display of charging case

68 Hrs

With Charging Case



Power Status of Wireless Earbuds

7 Hrs

Earbud Playtime



Figure 3.1: The charging case displays the battery percentage for the case and individual charge levels for the left and right earbuds. The earbuds offer up to 7 hours of playtime, extended to 75 hours with the charging case.

## 3.2 Pairing with a Bluetooth Device

The fojep BX28 earbuds feature one-step auto pairing for convenience.

1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, laptop), activate Bluetooth.
3. Search for available Bluetooth devices. Select "**BX28**" from the list.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.

The earbuds will automatically reconnect to the last paired device when removed from the case, provided Bluetooth is enabled on the device.

# ONE-STEP AUTO PAIRING

1. Remove the earbuds from charging case.
2. Activate Bluetooth setting, search & click "BX28" to connect.




Figure 3.2: Visual guide for the one-step auto pairing process. Simply remove the earbuds from the charging case, and they will appear as "BX28" in your device's Bluetooth settings for connection.

## 3.3 Wearing the Earbuds

For optimal sound quality and comfort, choose the correct size eartips and adjust the earhooks.

1. Select the eartips (S, M, L) that provide a snug and comfortable fit in your ear canal. A good seal enhances bass response and noise isolation.
2. Gently place the earbud into your ear, ensuring the earhook wraps securely around the back of your ear. The earhooks are flexible for a customized fit.

# ERGONOMIC DESIGN FOR SPORTS




Figure 3.3: The ergonomic design of the fojep BX28 earbuds, featuring flexible earhooks and multiple eartip sizes (S/M/L) to ensure a comfortable and secure fit, especially during sports activities.

## 4. OPERATING INSTRUCTIONS

The fojep BX28 earbuds feature intuitive touch controls on each earbud. The controls are mirrored on both earbuds, allowing for single-earbud use.

### 4.1 Music Playback Controls

Action	Left Earbud	Right Earbud
Play/Pause	Single Tap	Single Tap
Next Song	N/A	Double Tap

Action	Left Earbud	Right Earbud
Previous Song	Double Tap	N/A
Volume Up	N/A	Triple Tap
Volume Down	Triple Tap	N/A

## 4.2 Call Management Controls

Action	Left Earbud	Right Earbud
Answer Call	Single Tap	Single Tap
End Call	Single Tap	Single Tap
Reject Call	Long Press (2 seconds)	Long Press (2 seconds)

## 4.3 Voice Assistant

Activate your device's voice assistant (Siri, Google Assistant, etc.) by performing a specific tap gesture.

Action	Left Earbud	Right Earbud
Activate Voice Assistant	Long Press (2 seconds)	Long Press (2 seconds)



Figure 4.1: Detailed diagram of the touch controls for both left and right fojep BX28 earbuds, illustrating functions for music playback, call management, and voice assistant activation.

## 5. MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your fojep Wireless Earbuds BX28.

### 5.1 Cleaning

- Regularly clean the earbuds, especially the eartips and charging contacts, with a soft, dry, lint-free cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- Do not use harsh chemicals, alcohol, or abrasive materials.
- Ensure earbuds are completely dry before placing them back in the charging case.

## 5.2 Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place away from extreme temperatures and direct sunlight.

## 5.3 Water Resistance (IPX7)

The earbuds are rated IPX7 waterproof, meaning they can withstand submersion in up to 1 meter of water for 30 minutes. This makes them suitable for sweat resistance, rain, and splashes.

- **Note:** The charging case is **NOT** waterproof. Do not expose the charging case to water.
- After exposure to water or sweat, ensure the earbuds are completely dry before placing them back into the charging case to prevent damage to the charging contacts.



Figure 5.1: The fojep BX28 earbuds are IPX7 rated, providing protection against rain, sweat, and splashes, making them suitable for various activities.

## 6. TROUBLESHOOTING

If you encounter issues with your fojep Wireless Earbuds BX28, refer to the following common solutions:

Problem	Possible Cause	Solution
Earbuds not pairing/connecting	Bluetooth off, earbuds not in pairing mode, interference, previously paired device.	<ul style="list-style-type: none"><li>• Ensure Bluetooth is enabled on your device.</li><li>• Place earbuds back in case, close lid, then open to re-enter pairing mode.</li><li>• Forget "BX28" from your device's Bluetooth list and re-pair.</li><li>• Ensure earbuds are charged.</li></ul>
Only one earbud working	Low battery, not properly paired, earbud not connected to each other.	<ul style="list-style-type: none"><li>• Ensure both earbuds are charged.</li><li>• Place both earbuds back in the charging case, close the lid for 5 seconds, then open.</li><li>• Try resetting the earbuds (refer to manufacturer's website for specific reset instructions if needed).</li></ul>
Low volume or poor sound quality	Incorrect eartip size, earwax buildup, low device volume, poor connection.	<ul style="list-style-type: none"><li>• Try different eartip sizes for a better seal.</li><li>• Clean the eartips and earbud speaker mesh.</li><li>• Increase volume on both your device and the earbuds.</li><li>• Ensure no obstructions between earbuds and device.</li></ul>
Charging case not charging	Faulty cable, power source issue, dirty charging port.	<ul style="list-style-type: none"><li>• Try a different USB Type-C cable.</li><li>• Try a different USB power adapter or port.</li><li>• Clean the charging port on the case.</li></ul>

## 7. SPECIFICATIONS

Feature	Detail
Model Number	BX28
Bluetooth Version	V5.3
Earbud Playtime	Up to 7 hours (single charge)
Total Playtime (with charging case)	Up to 75 hours
Waterproof Rating	IPX7 (earbuds only)

Feature	Detail
Control Method	Touch Control
Microphone	Built-in, CVC Noise Cancelling
Charging Port	USB Type-C
Material	Plastic
Color	Deep Black



Figure 7.1: The fojep BX28 earbuds utilize advanced Bluetooth 5.3 technology, offering improved connection stability and efficiency compared to older versions.

# WIDE COMPATIBILITY



Figure 7.2: The fojep BX28 earbuds are widely compatible with various Bluetooth-enabled devices, including smartphones, tablets, laptops, and smartwatches.


## 8. WARRANTY & SUPPORT

fojep products are designed with quality and reliability in mind. For warranty information and customer support, please refer to the following:


- **Warranty:** Specific warranty terms and duration may vary by region and retailer. Please retain your proof of purchase for warranty claims.
- **Customer Support:** If you experience any issues or have questions not covered in this manual, please contact fojep customer support through the platform where you purchased the product (e.g., Amazon Message Center).
- **Online Resources:** For the latest information, FAQs, and additional support, visit the official fojep store page on Amazon: [fojep Amazon Store](#).

Your satisfaction is important to us. We are committed to providing excellent service and support.

## Related Documents

	<p><a href="#"><u><b>BX28 Stereo Wireless Noise-Cancelling Earbuds User Manual</b></u></a></p> <p>This manual provides instructions for the BX28 stereo wireless noise-cancelling earbuds, covering product overview, specifications, operating instructions, and pairing.</p>
---	--

Documents - fojep – BX28



### [\*\*BX28 Stereo Wireless Noise-Cancelling Earbuds User Manual\*\*](#)

This manual provides instructions for the BX28 stereo wireless noise-cancelling earbuds, covering product overview, specifications, operating instructions, and pairing.

lang: **score:17** filesize: 4.55 M page\_count: 1 document date: 2022-09-28