

[Manuals.plus](#) /

› [HORLAT](#) /

› HORLAT 5G WiFi Bluetooth Full HD Projector User Manual

HORLAT B0BNQ2GDNM

HORLAT 5G WiFi Bluetooth Full HD Projector User Manual

Model: B0BNQ2GDNM

INTRODUCTION

This manual provides detailed instructions for the HORLAT 5G WiFi Bluetooth Full HD Projector. Designed for home cinema, this projector supports 4K video input, features 550 ANSI lumens brightness, and a native 1080P resolution. It incorporates advanced features such as automatic 4P/4D keystone correction and 50% zoom function, ensuring a perfect image from various projection angles. With dual-band 5G/2.4G WiFi and bidirectional Bluetooth 5.2, it offers versatile connectivity for iOS, Android devices, laptops, and more.



An overview of the HORLAT projector, highlighting its compact design, prominent lens, and ventilation grilles. The top panel features intuitive controls for navigation and settings.

SETUP

1. Unpacking and Placement

Carefully remove the projector and all accessories from the packaging. Place the projector on a stable, flat surface or mount it according to your preference. Ensure adequate ventilation around the device.

2. Power Connection

Connect the power cable to the projector's power input and then plug it into a wall outlet.

3. Initial Power On and Basic Settings

Press the power button on the projector or remote control to turn on the device. Follow the on-screen prompts for initial language and network settings.

4. Connecting External Devices

- **HDMI:** Connect your game console, laptop, or other HDMI-enabled devices to the projector's HDMI port.
- **USB:** Insert a USB drive into the USB port to play media files or present documents (Excel, Word, PDF).

5. WiFi Connection and Screen Mirroring

The projector supports dual-band 5G/2.4G WiFi.

1. Navigate to the WiFi settings menu.
2. Select your desired 5G or 2.4G network and enter the password.
3. For screen mirroring (Eshare system), ensure your iOS/Android device is connected to the same WiFi network. Select the screen mirroring option on the projector and follow the instructions on your mobile device.

Note: Copyright-protected content from streaming services like Netflix requires a TV stick or HDMI cable connection for viewing.

6. Image Adjustment

- **Keystone Correction:** The projector supports digital $\pm 50^\circ$ 4D/4P and automatic keystone correction. Use the remote control to adjust the four corners of the image individually to eliminate distortion caused by projector placement.
- **Zoom Function:** Adjust the screen size from 100% to 50% using the remote control without moving the projector.

OPERATING INSTRUCTIONS

1. Bluetooth Connectivity

The projector features bidirectional Bluetooth 5.2, allowing it to connect wirelessly to external Bluetooth speakers for enhanced audio. It can also function as a standalone Bluetooth speaker when connected to your mobile phone.

2. Audio Output

The integrated dual 5W Hi-Fi stereo speakers provide clear and immersive sound. For private listening, connect headphones to the audio output port (if available, not explicitly mentioned in specs but common).

3. USB Presentation

Directly present Excel, Word, and PDF files from a USB flash drive. Insert the USB drive into the designated port and navigate to the file browser to select your document.

4. Remote Control Usage

Use the provided remote control to navigate menus, adjust settings, control playback, and utilize features like zoom and keystone correction. Some applications may benefit from the "mouse" option on the remote.

MAINTENANCE

1. Dust Prevention

The projector features a fully sealed optical engine designed to effectively block dust, reducing black spots and light leakage.

2. Cleaning

- **Lens:** Use a soft, lint-free cloth specifically designed for optical lenses. Do not use abrasive cleaners.
- **Exterior:** Wipe the projector's exterior with a soft, dry cloth. For stubborn marks, slightly dampen the cloth with water. Avoid harsh chemicals.
- **Vents:** Periodically clean the ventilation grilles to ensure proper airflow and prevent overheating. Use a soft brush or compressed air.

3. Storage

When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No image displayed	Power cable loose, incorrect input source, device not connected.	Check power connection. Ensure correct input source (HDMI, USB) is selected. Verify external device connection.
Image distorted or blurry	Incorrect keystone settings, out of focus, projector not perpendicular to screen.	Adjust keystone correction (4P/4D). Adjust focus. Reposition projector.
No sound	Volume too low, external speaker not connected, incorrect audio output.	Increase volume. Check Bluetooth connection to external speakers. Ensure audio output is set correctly.
WiFi connection unstable	Weak signal, interference, incorrect password.	Move projector closer to router. Check for interference. Re-enter WiFi password. Try 2.4G band if 5G is unstable.
Remote control not working	Dead batteries, obstruction, out of range.	Replace batteries. Remove obstructions. Ensure you are within effective range.

For further assistance, please refer to the support section or contact customer service.

SPECIFICATIONS

Brand	HORLAT
Model	B0BNQ2GDNM
Color	Grey
Product Type	Portable Projector
Native Resolution	1920 x 1080p Full HD
Max Display Resolution	3840 x 2160 (4K Supported)
Brightness	550 ANSI Lumens (16000 Lumens)
Contrast Ratio	15000:1
Display Type	LCD or DLP
WiFi Connectivity	Dual-band 5G/2.4G
Bluetooth	Bidirectional Bluetooth 5.2
Internal Memory	1G RAM + 8G Storage
Connections	HDMI, USB
Special Features	Sleep timer, 4P/4D Auto Keystone Correction, 100%-50% Zoom, Sealed Optical Engine
Compatible Devices	Game console, Speaker, Laptop, Smartphone
Product Dimensions	22.2L x 25.4W x 11.5H cm
Mounting Type	Table Mount

WARRANTY AND SUPPORT

For any questions regarding your HORLAT projector, please do not hesitate to contact our customer service team. We offer 24/7 online support and provide free spare parts if needed. Please email us at the address provided in your product packaging or visit our official website for contact information.

© 2023 HORLAT. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question