

[Manuals.plus](#) /

› [slochi](#) /

› slochi 12-Inch 28W LED Flush Mount Ceiling Light Fixture Instruction Manual

slochi CL02MA-2-WT

slochi 12-Inch 28W LED Flush Mount Ceiling Light Fixture

Model: CL02MA-2-WT

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before installation and retain this manual for future reference. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- **Always turn off the main power supply** at the circuit breaker or fuse box before beginning installation, maintenance, or cleaning.
- Consult a qualified electrician if you are unsure about the installation process.
- Ensure the voltage supply matches the requirements of the fixture.
- Handle the fixture with care to avoid damage.
- Ensure proper grounding according to local electrical codes.
- Do not modify the fixture in any way.

2. PRODUCT OVERVIEW

The slochi 12-Inch 28W LED Flush Mount Ceiling Light Fixture is designed to provide efficient and versatile lighting for various indoor spaces. Its low-profile, round design integrates seamlessly with modern interiors.



Image: The slochi 12-Inch LED Flush Mount Ceiling Light Fixture.

Key Features:

- **Adjustable Color Temperature:** Easily switch between 3000K (Warm White), 4500K (Natural White), and 6000K (Cool White) to suit your preference.
- **Dimmable:** Compatible with most standard dimmer switches for adjustable brightness.
- **Ultra-Thin Design:** With a thickness of approximately 0.9 inches (2.3 cm), it offers a sleek, low-profile appearance.
- **High Brightness & Energy Efficiency:** Provides 3200 lumens of light output with only 28W power consumption, equivalent to a much higher wattage incandescent bulb.
- **No Flicker:** Designed to provide stable, flicker-free illumination.
- **Durable Construction:** Features moisture-proof, dustproof, and mosquito-repellent properties for extended lifespan and reduced maintenance.



Image: Ultra-thin design of the slochi ceiling light, highlighting its slim profile.



Image: Energy-saving design illustrating the efficiency of the LED light.

3. SPECIFICATIONS

Specification	Detail
Brand	slochi
Model Number	CL02MA-2-WT
Wattage	28W
Brightness	3200 Lumens
Color Temperature	3000K / 4500K / 6000K (Adjustable)
Diameter	12 Inches
Thickness	Approx. 0.9 Inches (2.3 cm)
Material	Plastic, Shell

Specification	Detail
Installation Type	Flush Mount
Special Features	Adjustable Color Temperature, Dimmable, Energy Efficient, Moisture-proof, Dustproof, Mosquito Repellent
Lifespan	Up to 25,000 hours
Indoor/Outdoor Usage	Indoor
Certification	CE Listed

4. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- slochi 12-Inch LED Flush Mount Ceiling Light Fixture (x2)
- Mounting Hardware (screws, expansion screws)
- Instruction Manual

5. INSTALLATION GUIDE

Follow these steps for safe and proper installation. This fixture is compatible with most standard junction boxes.

1. **Turn Off Power:** Locate the circuit breaker controlling the light fixture's location and turn off the power supply. Verify power is off using a voltage tester.
2. **Install Mounting Bracket:** Secure the mounting bracket to the ceiling or wall using the provided screws and expansion screws. Ensure the bracket is firmly attached.
3. **Connect Wires:** Connect the electrical wires from the ceiling to the corresponding wires on the light fixture. Typically, this involves connecting the live (black), neutral (white), and ground (green/bare copper) wires. Use wire nuts to secure connections.
4. **Mount Light Fixture:** Carefully align the light fixture with the mounting bracket. Place the wiring ports into appropriate locations within the fixture and rotate the lamp body onto the holder until it is securely fastened.
5. **Restore Power:** Once the fixture is securely installed, turn the power back on at the circuit breaker.



Image: Visual guide for installing the slochi LED ceiling light.

6. OPERATING INSTRUCTIONS

Adjusting Color Temperature

The slochi LED ceiling light offers three color temperature options. To change the color temperature:

- Locate the small toggle switch on the back of the ceiling lamp body.
- Slide the switch to select your desired color temperature:
 - **3000K:** Warm White for a cozy ambiance.
 - **4500K:** Natural White for balanced, everyday lighting.
 - **6000K:** Cool White for bright, task-oriented illumination.




Image: Illustration of the color temperature toggle switch and its effects.

Dimming Function

This fixture is designed to be dimmable. To adjust the brightness, use a compatible LED dimmer switch (not included) installed on your wall switch circuit.

7. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your light fixture.

- **Cleaning:** Always turn off the power before cleaning. Wipe the fixture with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish or electrical components.
- **Inspection:** Periodically check the fixture for any signs of damage or loose connections. If any issues are found, turn off the power and consult a qualified electrician.

8. TROUBLESHOOTING

If you encounter any issues with your slochi LED ceiling light, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on	No power supply, loose wiring, faulty switch	Check circuit breaker. Ensure all wire connections are secure. Test the wall switch.
Light flickers	Loose wiring, incompatible dimmer switch	Ensure all wire connections are tight. If using a dimmer, verify it is compatible with LED fixtures.
Incorrect color temperature	Toggle switch set incorrectly	Adjust the toggle switch on the back of the fixture to the desired color temperature.



Image: The slochi LED light is designed for flicker-free operation.

If the problem persists after attempting these solutions, please contact customer support.

9. WARRANTY AND SUPPORT

slochi is committed to providing high-quality products and customer satisfaction.

- **365 Days Support Guarantee:** Your purchase is backed by a 365-day support guarantee.
- **30 Days Free Return & Exchange:** Enjoy a 30-day period for free returns and exchanges.



Image: slochi's commitment to after-sales support.

For any product-related inquiries, technical assistance, or warranty claims, please contact slochi customer service through the retailer's platform where you purchased the product.

© 2023 slochi. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0BNQ63493>

More documents and user manuals: <https://manuals.plus/>