Bosch MMB6384M

Bosch VitaPower Serie 4 MMB6384M Blender User Manual

Model: MMB6384M

1. Introduction

Thank you for choosing the Bosch VitaPower Serie 4 MMB6384M Blender. This appliance is designed for blending various ingredients, preparing smoothies, crushing ice, and more. Please read this manual carefully before first use to ensure safe and optimal operation. Keep these instructions for future reference.

2. Safety Instructions

Always observe the following safety precautions to prevent injury or damage:

- Read all instructions before operating the appliance.
- Do not immerse the motor base in water or other liquids.
- Keep hands and utensils out of the container while blending to reduce the risk of severe injury to persons or damage to the blender. A scraper may be used but only when the blender is not running.
- Blades are sharp. Handle with care during assembly, disassembly, and cleaning.
- Ensure the lid is securely locked in place before operating the blender.
- Do not blend hot liquids that exceed the maximum fill line to avoid overflow and scalding.
- Unplug the appliance from the outlet when not in use, before assembling or disassembling parts, and before cleaning.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. Product Components

Familiarize yourself with the parts of your Bosch VitaPower Serie 4 MMB6384M Blender:



Image: The Bosch VitaPower Serie 4 MMB6384M Blender showing the motor base, ThermoSafe glass jug, lid, ToGo bottle, blade assembly, and tamper.

- **Motor Base:** The main unit containing the 1200W motor and control panel.
- **ThermoSafe Glass Jug (1.5 L):** A durable glass container for blending, resistant to temperature changes.
- **Lid with Pouring Spout:** Secures the jug during operation and allows for easy pouring.
- **ProEdge Stainless Steel Blade Assembly:** High-performance blades for efficient blending, featuring an EasyClick system for removal.
- **Tamper:** Used to push ingredients towards the blades during blending, especially for thick mixtures.
- **ToGo Bottle (0.6 L):** A portable, unbreakable bottle for blending directly and taking your drinks on the go.



Image: Close-up of the blender accessories: the ProEdge blade assembly, the 0.6L ToGo bottle with its lid, and the tamper.

4. Setup

Follow these steps to set up your blender for first use:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash all removable parts (glass jug, lid, blade assembly, ToGo bottle) in warm soapy water, rinse thoroughly, and dry. The motor base can be wiped with a damp cloth.
3. **Position:** Place the motor base on a clean, dry, and stable surface. Ensure the power cord is not obstructed.
4. **Assemble Jug:** Attach the ProEdge stainless steel blade assembly to the bottom of the ThermoSafe glass jug by twisting it securely.
5. **Place Jug:** Place the assembled glass jug onto the motor base. Ensure it is seated correctly and locked into position.



Image: A hand holding the ProEdge blade assembly, highlighting the 'Made in Germany Solingen' inscription, demonstrating the EasyClick system for removal.

5. Operating Instructions

Operating your Bosch VitaPower Serie 4 MMB6384M Blender is straightforward:

1. **Add Ingredients:** Place your desired ingredients into the ThermoSafe glass jug. Do not exceed the maximum fill line.
2. **Secure Lid:** Place the lid firmly onto the jug. Ensure the pouring spout is closed or properly positioned.
3. **Plug In:** Connect the power cord to a suitable electrical outlet.
4. **Select Program/Speed:** Use the control dial on the motor base to select one of the automatic programs (Clean, Smoothie, Ice Crush) or to manually adjust the blending speed.
5. **Start Blending:** Press the start button or turn the dial to activate the blender.
6. **Use Tamper (Optional):** For thick mixtures, remove the small cap from the lid and use the tamper to push ingredients towards the blades. **Never use the tamper without the lid in place.**
7. **Stop Blending:** Turn the dial to the 'Off' position or press the stop button.
8. **Pour:** Carefully remove the lid and pour your blended mixture.



Image: The blender in operation on a kitchen counter, filled with fruit, alongside a ToGo bottle and glasses containing prepared smoothies.

Using the ToGo Bottle

The ToGo bottle allows for convenient blending and portability:

1. **Add Ingredients:** Fill the ToGo bottle with your ingredients.
2. **Attach Blade:** Screw the ProEdge blade assembly directly onto the ToGo bottle.
3. **Blend:** Invert the ToGo bottle and place it onto the motor base. Select your desired program or speed and blend.
4. **Enjoy On-the-Go:** Once blended, remove the bottle, unscrew the blade assembly, and attach the ToGo bottle lid.



Image: A hand carefully placing the ToGo bottle, filled with ingredients, onto the motor base of the blender for direct blending.



Image: The ToGo bottle, containing a blended smoothie, conveniently packed inside a gym bag, ready for transport.

6. Cleaning and Maintenance

Proper cleaning ensures the longevity and hygiene of your blender:

- **Unplug:** Always unplug the blender before cleaning.
- **Dishwasher Safe Parts:** The ThermoSafe glass jug, lid, ProEdge blade assembly, and ToGo bottle are dishwasher safe. Place them on the top rack of your dishwasher.
- **Manual Cleaning:** For manual cleaning, wash these parts in warm soapy water using a brush for the blades. Rinse thoroughly and dry.
- **EasyClick System:** The blade assembly can be easily detached from the jug for thorough cleaning.
- **Motor Base:** Wipe the motor base with a damp cloth. Never immerse it in water.
- **Storage:** Store the blender in a dry place. The power cord can be stored inside the motor base for convenience.

7. Troubleshooting

If you encounter issues with your blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not start.	Not plugged in; jug not correctly assembled/locked; power outage.	Check power connection; ensure jug is securely placed on the motor base; check household circuit breaker.

Problem	Possible Cause	Solution
Ingredients not blending smoothly.	Too little liquid; too many ingredients; ingredients too large.	Add more liquid; reduce ingredient quantity; cut ingredients into smaller pieces; use the tamper.
Leakage from the jug.	Blade assembly not tightened; lid not properly secured; jug overfilled.	Ensure blade assembly is tightly screwed onto the jug; secure the lid firmly; do not exceed the maximum fill line.
Unusual noise or odor.	Overloading; foreign object in blades; motor overheating.	Reduce load; unplug and check for obstructions (carefully); allow motor to cool down. If problem persists, contact support.

8. Specifications

Key technical details for the Bosch VitaPower Serie 4 MMB6384M Blender:

- **Model Number:** MMB6384M
- **Power:** 1200 W
- **Voltage:** 220 Volts
- **Motor Speed:** Up to 30,000 RPM
- **Jug Capacity:** 1.5 Litres (ThermoSafe Glass)
- **ToGo Bottle Capacity:** 0.6 Litres
- **Blade Material:** Stainless Steel (ProEdge)
- **Dimensions (L x W x H):** 23 x 19.5 x 41 cm
- **Weight:** 4.43 Kilograms
- **Control Type:** Push button or rotary knob
- **Dishwasher Safe Parts:** Yes (Jug, lid, blade assembly, ToGo bottle)
- **Special Features:** Mix directly in ToGo bottle, safety lid with pouring opening, cable storage inside housing.

9. Warranty and Support

Your Bosch VitaPower Serie 4 MMB6384M Blender comes with a manufacturer's warranty:

- **Motor Warranty:** Enjoy a 10-year motor warranty, ensuring long-lasting performance thanks to Bosch Motor Technology.
- **General Warranty:** Please refer to the separate warranty card included with your product for full terms and conditions regarding other components.
- **Customer Support:** For technical assistance, spare parts, or warranty claims, please contact Bosch customer service in your region. Contact details can typically be found on the Bosch official website or in the product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question