

[Manuals.plus](#) /

› [TENGA](#) /

› TENGAPuffy Mint Green Instruction Manual

TENGA PUF-002

TENGA Puffy Mint Green Instruction Manual

Model: PUF-002

Brand: TENGA

1. INTRODUCTION

The TENGA Puffy Mint Green is a reusable male pleasure device engineered to provide a unique, pillowy-soft sensation. Its innovative design focuses on comfort and a gentle, enveloping experience, making it suitable for extended use and varied stimulation.





Figure 1: Overview of the TENGA Puffy Mint Green device.

2. KEY FEATURES

- **Pillow-Soft Pleasure:** Features an ultra-soft spongy internal material and a silky-smooth silicone cover designed to provide a gentle, enveloping sensation.
- **Unique Interior Design:** The internal structure incorporates small beads and long ribs intertwined with larger beads, creating a compound stimulation. The fluffy insertion point enhances the initial experience.
- **Luxurious Sensation:** A marshmallow-like texture allows users to adjust pressure during use through its flexible body and soft coating.
- **Reusable Design:** Engineered for multiple uses with proper care and maintenance.
- **Made in Japan:** Designed, engineered, and manufactured in Japan, ensuring quality and craftsmanship.








Figure 2: Internal structure of the TENGA Puffy, highlighting its unique texture.

3. SETUP AND PREPARATION

Before the first use, and for each subsequent use, ensure the device is clean and properly lubricated.

1. **Initial Cleaning:** Although new, it is recommended to rinse the internal sleeve with lukewarm water before first use.
2. **Lubrication:** Apply a generous amount of water-based lubricant to the internal sleeve and around the insertion point. This is crucial for optimal comfort and performance.

4. OPERATING INSTRUCTIONS

The TENGA Puffy is designed for intuitive manual use. Its flexible body allows for a customizable experience.

1. **Insertion:** Gently insert into the device.
2. **Pressure Adjustment:** The soft, flexible exterior allows you to squeeze and manipulate the device to vary the internal pressure and sensation. Experiment with different grip strengths and angles to find your preferred level of stimulation.
3. **Airflow Control:** The cap on the bottom of the device can be slightly unscrewed to allow air to escape, which may affect suction and sound. Adjust as desired for a quieter experience or increased suction.



Figure 3: Demonstrating the flexibility and usage of the TENGA Puffy.

5. MAINTENANCE AND CLEANING

Proper cleaning and maintenance are essential for the longevity and hygiene of your TENGA Puffy device.

1. **Disassembly:** Unscrew the top and bottom caps to separate the internal sleeve from the outer casing.
2. **Rinsing:** Thoroughly rinse the internal sleeve and outer casing with lukewarm water.
3. **Cleaning Agent:** If desired, use a mild, pH-neutral soap or a specialized toy cleaner. Gently rub the surfaces to remove any residue.
4. **Final Rinse:** Rinse all components thoroughly under running water to ensure no soap residue remains.
5. **Drying:** Allow all parts to air dry completely before reassembly. You can place them on a clean, dry surface or use a soft, lint-free cloth. Ensure the internal sleeve is fully dry to prevent moisture buildup.



Figure 4: Step-by-step guide for cleaning and drying the TENGA Puffy.

6. STORAGE

Once completely dry, reassemble the TENGA Puffy device. Store it in a cool, dry place away from direct sunlight, extreme temperatures, and dust. Keeping it in its original casing or a dedicated storage bag will help protect the material and maintain hygiene.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device feels too tight.	Insufficient lubrication; individual preference.	Ensure a generous amount of water-based lubricant is applied. The flexible body can be gently squeezed to adjust the internal sensation.
Not enough sensation.	Insufficient lubrication; incorrect pressure application.	Apply more lubricant. Experiment with different grip pressures and angles on the flexible exterior to find optimal stimulation.
Device is loud during use.	Air trapped inside; cap position.	Try slightly unscrewing the bottom cap to allow air to escape, which may reduce noise and create a more consistent suction.
Device is damaged (e.g., torn).	Wear and tear; improper handling.	Discontinue use if the device is damaged to prevent further tearing or potential injury. Consider replacing the product.

8. PRODUCT SPECIFICATIONS

Model Name: TENGA Puffy Mint Green

Item Model Number: PUF-002

Brand: TENGA

Material: Silicone

Color: Mint Green

Product Dimensions: 3.42 x 3.34 x 6.49 inches (8.69 x 8.48 x 16.48 cm)

Item Weight: 12.35 ounces (350 grams)

Manufacturer: TENGA

9. WARRANTY INFORMATION

Specific warranty details for the TENGA Puffy Mint Green device are not provided in this manual. For information regarding product warranty, please refer to the official TENGA website or contact their customer support directly.

10. CUSTOMER SUPPORT

For further assistance, product inquiries, or support, please visit the official TENGA website or contact their customer service department. You may also find additional resources, including a Certificate of Compliance, on the product's listing page or the manufacturer's website.

Official TENGA Website: www.tenga.co.jp/en/

Certificate of Compliance (PDF): [Download PDF](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BNSVY2JW>

More documents and user manuals: <https://manuals.plus/>