Spilay P013

Spilay Fuchun Resort DIY Miniature Dollhouse Kit Instruction Manual

Model: P013

1. Introduction

Thank you for choosing the Spilay Fuchun Resort DIY Miniature Dollhouse Kit. This kit provides a challenging and rewarding experience to construct a detailed 1:24 scale miniature model. It includes all necessary wooden, cloth, and paper components, along with a dust cover and a music box, to create a beautiful and intricate display piece.



Image 1.1: The fully assembled Spilay Fuchun Resort miniature dollhouse kit, showcasing its intricate design and illuminated interior.

2. Safety Information

- **Age Recommendation:** This kit is intended for individuals aged 14 years and older. It contains small parts and requires precision assembly, making it unsuitable for young children.
- **Ventilation:** Ensure adequate ventilation when using adhesives (not included).
- **Small Parts:** Keep all small components away from children and pets to prevent choking hazards.
- **Sharp Edges:** Exercise caution when handling wooden pieces, as some edges may be sharp.
- **Electrical Components:** Handle LED lights and wiring carefully. Do not expose to water.

3. Package Contents

Your Spilay Fuchun Resort kit includes the following items:

- Pre-cut wooden pieces for structure and furniture
- Fabric and paper components for decoration
- LED lighting components and wiring
- Music box mechanism
- Dust cover
- English instruction manual

- Various small accessories and decorative elements

Note: Adhesives (glue) and tools (scissors, tweezers, ruler) are not included and must be purchased separately.



Image 3.1: Overview of product information including dimensions, materials, and included components.

4. Assembly Instructions

Assembly of the Fuchun Resort dollhouse is a detailed process that requires patience and attention. Follow the included

English manual step-by-step. The manual provides diagrams and instructions for identifying parts and their fabrication.

1. **Preparation:**
    - Unpack all components and organize them by their designated packages (e.g., Package C, Package D).
    - Familiarize yourself with the instruction manual, paying close attention to the part identification charts.
    - Gather necessary tools: precision scissors, tweezers, a ruler, and appropriate adhesive (e.g., quick-drying craft glue or wood glue).
2. **Part Identification:**
   The manual categorizes parts by package and provides detailed illustrations with dimensions. For example, you will find sections for "Package D" and "Package C" with specific wood pieces and their corresponding codes (e.g., D1, C15).
3. **Step-by-Step Fabrication:**
   Each step in the manual outlines the assembly of specific sections or furniture pieces. Follow the diagrams carefully. For instance, step 12 might instruct you to "Find J82 and J57 and fabricate two. Stick one in the place and another to the cupboard."



Image 4.1: A family engaged in the assembly process, demonstrating the hands-on nature of the kit.

4. **Wiring and Lighting:**
   Integrate the LED lighting as instructed. Ensure all connections are secure before final assembly of walls or ceilings to allow for testing.
5. **Final Touches:**
   Once the main structure and furniture are complete, add the decorative elements, music box, and dust cover. The music box adds a romantic touch, and the dust cover protects your finished creation.

Assembly Video Guide

For a visual guide on the assembly process and the finished product, please refer to the official video below:

Your browser does not support the video tag.

Video 4.2: Official Spilay video demonstrating the assembly and features of the Fuchun Resort miniature dollhouse kit.

5. Operating Instructions

5.1. LED Lighting

The LED lights are powered by batteries (not included) and are typically controlled by a small switch. Ensure batteries are correctly inserted according to polarity. Turn the switch ON to illuminate the dollhouse and OFF when not in use to conserve battery life.

5.2. Music Box

The music box is integrated into the base of the dollhouse. To activate the music, gently wind the mechanism located on the side or bottom of the base. Do not overwind to prevent damage.



Image 5.1: The illuminated dollhouse serving as an elegant bedside nightlight.

6. Maintenance

- **Cleaning:** Use a soft, dry cloth or a small brush to gently remove dust from the dollhouse and its components. Avoid using water or cleaning solutions, as they may damage the materials.
- **Dust Cover:** Always use the provided dust cover to protect the finished dollhouse from dust and environmental elements.
- **Storage:** Store the dollhouse in a dry place away from direct sunlight and extreme temperatures to prevent warping or fading of materials.
- **Battery Replacement:** Replace LED light batteries as needed. Dispose of old batteries responsibly.

7. Troubleshooting

Problem	Possible Cause	Solution
Missing or broken parts	Manufacturing defect or shipping damage.	Contact Spilay customer support immediately with details of the missing/broken part(s). The kit is checked for completeness before delivery.
LED lights not working	Incorrect battery installation, dead batteries, loose wiring, or faulty switch.	Check battery polarity, replace batteries, ensure all wire connections are secure, and verify the switch is in the ON position.

Problem	Possible Cause	Solution
Music box not playing	Not wound, overwound, or internal mechanism issue.	Gently wind the music box. If it's overwound, do not force it. If it remains unresponsive, contact customer support.
Difficulty with assembly steps	Instructions unclear, complex step, or incorrect part identification.	Review the manual diagrams carefully. Search for video tutorials online (e.g., YouTube) for visual guidance. Contact customer support for clarification.

8. Specifications

Feature	Detail
Brand	Spilay
Model Number	P013
Product Name	Fuchun Resort DIY Miniature Dollhouse Kit
Scale	1:24
Finished Dimensions (L x W x H)	29.7 cm x 27.2 cm x 24.5 cm (approx. 11.69" x 10.7" x 9.64")
Weight	Approx. 2.4 KG (5.3 lbs)
Materials	Wood, Cloth, Paper
Included Components	All furniture, Dust Cover, Music Box, English Manual
Assembly Required	Yes
Recommended Age	14+ years

9. Warranty and Support

Spilay ensures that all DIY dollhouse kits are carefully checked before delivery to ensure completeness and quality. If you encounter any issues during assembly, such as missing or damaged parts, or have questions regarding the instructions, please do not hesitate to contact Spilay customer support.

Contact Information: Refer to the packaging or the official Spilay website for the most current customer support contact details.

We are committed to resolving any problems as quickly as possible to ensure your satisfaction with your Spilay product.

© 2023 Spilay. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question