

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [c cattleya](#) /

› [C Cattleya CA2018-W Large 2-Light Brass Modern Outdoor Wall Lantern Instruction Manual](#)

c cattleya CA2018-W

C Cattleya CA2018-W Large 2-Light Brass Modern Outdoor Wall Lantern Instruction Manual

Model: CA2018-W

1. INTRODUCTION

This manual provides essential information for the safe installation, operation, and maintenance of your C Cattleya CA2018-W Large 2-Light Brass Modern Outdoor Wall Lantern. Please read these instructions thoroughly before beginning installation and retain them for future reference.

The C Cattleya CA2018-W wall sconce is designed to provide illumination for outdoor spaces such as patios, doorways, porches, and garages. It features a solid brass frame and clear tempered glass panels, offering a modern aesthetic and durable construction.



Image 1.1: Front view of the C Cattleya CA2018-W Outdoor Wall Lantern.

2. SAFETY INFORMATION

WARNING: Risk of electric shock. Disconnect power at the fuse or circuit breaker before installation or servicing.

- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC). Contact a qualified electrician if you are unfamiliar with proper electrical wiring connections.
- This fixture is intended for outdoor use and is ETL Listed for safety.
- Ensure the mounting surface is structurally sound and can support the weight of the fixture.
- Do not exceed the maximum wattage specified for the bulbs.
- Wear safety glasses and gloves during installation.
- Keep flammable materials away from the light fixture when in operation.

3. PACKAGE CONTENTS


Verify that all components are present before beginning installation:


- 1 x C Cattleya CA2018-W Outdoor Wall Lantern
- 1 x Mounting Hardware Kit (includes screws, wire nuts, and mounting plate)

Note: E26 base bulbs are not included and must be purchased separately.

4. SPECIFICATIONS


Feature	Specification
Brand	c cattleya
Model Number	CA2018-W
Color	Dark Bronze
Material	Brass, Tempered Glass
Style	Modern
Fixture Form	Sconce
Product Dimensions	7"L x 5"W x 20"H
Indoor/Outdoor Usage	Outdoor
Power Source	Corded Electric
Installation Type	Wall Mount
Light Source Type	Incandescent (compatible with LED, CFL)
Number of Light Sources	2
Voltage	120 Volts
Bulb Base	E26
Max Wattage per Bulb	60 Watts
Water Resistance Level	Waterproof
Certifications	ETL Listed





FRONT VIEW

SIDE VIEW



TOP VIEW

Image 4.1: Dimensional drawing of the C Cattleya CA2018-W Outdoor Wall Lantern.

5. SETUP AND INSTALLATION

Tools Required (not included): Screwdriver, wire strippers, electrical tape, ladder, safety glasses, gloves.

1. Prepare for Installation:

- Turn off power at the circuit breaker or fuse box to avoid electrical shock.
- Ensure the wall surface is clean and dry.

2. Mounting Plate Installation:

- Attach the mounting plate (from the hardware kit) to the junction box on the wall using the provided screws. Ensure it is securely fastened.

3. Wiring Connections:

- Connect the fixture's black wire to the house's black (hot) wire.
- Connect the fixture's white wire to the house's white (neutral) wire.
- Connect the fixture's ground wire (usually bare copper or green) to the house's ground wire and to the mounting plate's ground screw.
- Secure all connections with wire nuts and wrap with electrical tape for added safety.

4. Attach the Fixture:

- Carefully align the fixture with the mounting plate and secure it using the provided screws. Ensure the fixture is flush against the wall and stable.

5. Install Bulbs:

- Open the glass door of the fixture using the special handle.
- Screw two E26 base bulbs (max 60W each, not included) into the sockets.
- Close the glass door securely.

6. Restore Power:

- Turn the power back on at the circuit breaker or fuse box.
- Test the light fixture to ensure proper operation.



Image 5.1: Close-up of the fixture's internal components, showing bulb holders and the handle for accessing bulbs.

6. OPERATING INSTRUCTIONS

The C Cattleya CA2018-W Outdoor Wall Lantern operates via a standard wall switch (not included). Once installed and wired correctly, simply use the wall switch to turn the light fixture on or off.

- Ensure bulbs are securely tightened in their sockets.
- For optimal performance and energy efficiency, consider using LED bulbs compatible with E26 bases.



Image 6.1: Example of the wall lantern installed on a modern home exterior.

7. MAINTENANCE

Regular maintenance helps ensure the longevity and appearance of your outdoor wall lantern.

- **Cleaning:** Periodically clean the fixture with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish or glass.
- **Bulb Replacement:** Before replacing bulbs, ensure the power is turned off at the circuit breaker. Open the glass door using the handle, unscrew the old bulb, and screw in a new E26 base bulb (max 60W). Close the door securely.
- **Inspection:** Annually inspect the wiring and connections for any signs of wear or damage. Ensure all screws and mounting hardware remain tight.
- **Weather Resistance:** The fixture is waterproof. However, ensure no water accumulates around the base or electrical connections.

8. TROUBLESHOOTING

If you encounter issues with your wall lantern, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Light does not turn on	No power to the fixture Loose wire connection Faulty bulb Faulty wall switch	Check circuit breaker/fuse. Verify all wire connections are secure (power off). Replace bulb with a known working one. Test or replace wall switch (consult electrician).
Light flickers	Loose bulb Loose wire connection Incorrect bulb type/wattage	Tighten bulb. Check wire connections (power off). Ensure bulb is E26 base and within 60W limit.
Glass panels are foggy/dirty	Environmental residue	Clean with a soft, damp cloth.

9. WARRANTY AND SUPPORT

This C Cattleya CA2018-W Outdoor Wall Lantern comes with a **1-Year Warranty** from the date of purchase, covering defects in materials and workmanship under normal use.

For technical assistance, warranty claims, or to purchase replacement parts, please contact Cattleya Lighting directly. Refer to your purchase documentation for specific contact information or visit the official C Cattleya store on Amazon.





Seller: Cattleya Lighting

Amazon Store Link: [Visit the C Cattleya Store](#)

© 2023 C Cattleya. All rights reserved.

Related Documents - CA2018-W

	<p>ZEVNI L3QNARVIW4639S67 Wall Sconce Installation Guide & Safety Information</p> <p>Comprehensive installation guide for the ZEVNI L3QNARVIW4639S67 wall sconce. Includes safety warnings, parts list, step-by-step assembly instructions, wiring diagrams, and cleaning recommendations.</p>

	<p><u>Edvivi EW4885BK Wall Sconce Installation Instructions and Mounting Guide</u></p> <p>Detailed installation and mounting instructions for the Edvivi EW4885BK 1-Light Matte Black Indoor Contemporary Wall Sconce. Includes safety warnings, part list, wiring diagram, and assembly steps.</p>
	<p><u>CA2308-W Outdoor Wall Lantern Assembly and Installation Instructions</u></p> <p>Step-by-step guide for assembling and installing the Cattleya CA2308-W outdoor wall lantern, including wiring instructions and safety precautions.</p>
	<p><u>Azfenro A04969W1 Wall Sconce Installation Guide and Safety Instructions</u></p> <p>Detailed installation manual and safety warnings for the Azfenro A04969W1 wall sconce. Includes parts list, assembly steps, wiring instructions, and cleaning guidelines.</p>
	<p><u>Cattleya LA2143-W Outdoor Wall Lantern Sconce Assembly and Installation Instructions</u></p> <p>Detailed assembly and installation guide for the Cattleya LA2143-W outdoor wall lantern sconce, including wiring instructions and safety precautions.</p>