Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY L5B83H

ALLIMITY L5B83H 2nd Gen Voice Remote Control User Manual

Model: L5B83H

1. Product Overview

The ALLIMITY L5B83H 2nd Gen Voice Remote Control is designed to provide seamless navigation and control for compatible Amazon TV devices. It features voice command capabilities, power control, and volume adjustments for an enhanced user experience.



Image 1.1: Front view of the ALLIMITY L5B83H 2nd Gen Voice Remote Control.

2. Product Features

- **Voice Control:** Easily find, launch, and control content using voice commands.
- **Power Control:** Dedicated button for turning compatible Amazon TV devices on and off.
- **Volume Control:** Buttons for increasing, decreasing, and muting audio volume.
- **Navigation:** Intuitive navigation ring and select button for menu interaction.

- **Dedicated Buttons:** Includes Home, Back, Menu, Rewind, Play/Pause, and Fast Forward buttons.



Image 2.1: Illustration of the voice control button and its function.

3. Compatibility

This remote control is compatible with the following Amazon TV devices:

- Amazon TV Stick (2nd Gen) LY73PR
- Amazon TV Stick (3rd Gen) S3L46N
- Amazon TV Stick Lite S3L46N
- Amazon TV Stick 4K E9L29Y
- Amazon TV Stick 4K Max K2R2TE
- Amazon TV (3rd Gen) LDC9WZ
- Amazon TV Cube (1st Gen) EX69VW
- Amazon TV Cube (2nd Gen) A78V3N

Not Compatible With:

- Amazon TV Stick (1st Gen)
- Amazon TV (1st Gen)
- Amazon TV (2nd Gen)
- All other brand Amazon TV Edition Smart TVs

4. Setup and Pairing

4.1. Battery Installation

The remote requires 2 AAA batteries (not included). To install batteries:

1. Open the battery compartment cover on the back of the remote.
2. Insert two AAA batteries, ensuring correct polarity (+ and -).

3. Close the battery compartment cover securely.



Image 4.1: View of the battery compartment, indicating placement for 2 AAA batteries.

4.2. Pairing Your Remote

To pair the ALLIMITY L5B83H remote with your Amazon TV device:

1. Ensure your Amazon TV device is powered on and displaying the home screen.
2. Press and hold the **Home** button ( ) on the remote for approximately 10-15 seconds.
3. Release the button when the LED indicator on the remote begins to flash rapidly.
4. Wait for about 30-60 seconds. The remote should automatically pair with your device.



Image 4.2: Visual guide for locating and pressing the Home button during the pairing process.

5. Operating Instructions

5.1. Remote Button Functions

Familiarize yourself with the functions of each button on your ALLIMITY L5B83H remote control:



Image 5.1: Detailed diagram labeling each button on the L5B83H remote control and its corresponding function.

- **Power Button:** Turns the connected Amazon TV device on or off.
- **Microphone / Voice Button:** Activates voice control for searching and commands.
- **Navigation Ring:** Used to move up, down, left, and right within menus.
- **Select Button:** Confirms selections or plays content.
- **Back Button:** Returns to the previous screen or menu.
- **Home Button:** Returns to the main home screen of the Amazon TV device.
- **Menu Button:** Accesses additional options or context menus.
- **Rewind Button:** Rewinds playback.
- **Play/Pause Button:** Plays or pauses media playback.
- **Fast Forward Button:** Fast forwards playback.
- **Increase Volume Button:** Increases the audio volume.
- **Decrease Volume Button:** Decreases the audio volume.
- **Mute Button:** Mutes or unmutes the audio.

6. Troubleshooting

If you encounter issues with your remote control, try the following steps:

1. **Restart Device:** Unplug your Amazon TV device from its power source, wait a few seconds, then plug it back in. Allow the device to fully boot up to the home screen.
2. **Check Batteries:** Remove and reinsert the remote's batteries. Ensure they are correctly oriented and have sufficient charge.
3. **Re-pair Remote:** If the remote is not discovered or responsive, press and hold the**Home** button for 10 seconds to initiate the pairing process again.
4. **Obstruction Check:** Ensure there are no obstructions between the remote and your Amazon TV device.

If problems persist after following these steps, please refer to the support section for further assistance.

7. Specifications

Feature	Detail
Model Number	L5B83H
Product Dimensions	5.51 x 1.97 x 0.39 inches
Item Weight	1.41 ounces
Power Source	2 x AAA Batteries (not included)
Special Features	Ergonomic, Voice Search
Color	Black
Max Number of Supported Devices	1
Compatible Devices	Amazon TV Stick/Box/Cube

8. Support and Contact Information

For any questions, issues, or further assistance regarding your ALLIMITY L5B83H Voice Remote Control, please contact our customer service team.

- If the remote you received does not work, please contact our after-sale customer service. They will reply within 24 hours.
- If you have problems with pairing, contact us for detailed pairing steps.

Please refer to the packaging or product listing for specific contact details for ALLIMITY customer support.

© 2023 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BNV88KPX

More documents and user manuals: **https://manuals.plus/**